Yaheetech YA-00130226

Yaheetech 181.5 cm Multi-Level Cat Tree Instruction Manual

Model: YA-00130226

INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your Yaheetech 181.5 cm Multi-Level Cat Tree. Designed to offer a versatile and engaging environment for your feline companions, this cat tree features multiple platforms, cozy cat houses, a comfortable hammock, and durable scratching posts. Please read these instructions carefully before assembly and use to ensure safe and correct installation.

SAFETY INSTRUCTIONS

- Always assemble the cat tree on a flat, stable surface.

- Ensure all screws and fasteners are securely tightened before allowing pets to use the product.

- Regularly check all connections for tightness and re-tighten if necessary to maintain stability.

- Utilize the included anti-tipping device to secure the cat tree to a wall for enhanced stability, especially if you have active or multiple cats.

- Keep small parts and packaging materials away from children and pets during assembly.

- Do not allow children to climb on the cat tree.

- Inspect the cat tree periodically for any signs of wear or damage. Replace worn parts immediately.

PARTS LIST

Before beginning assembly, verify that all components listed below are present. Refer to the illustrated assembly diagram for visual identification of parts.

- Baseboard (1)

- Platforms (various sizes)

- Cat Houses/Condos (2)

- Hammock (1)

- Perches/Beds (2)
- Sisal Scratching Posts (various lengths)
- Ramp (1)
- Plush Balls (attached)
- Assembly Hardware (screws, bolts, washers, Allen key)
- Anti-Tipping Device (wall anchor, strap)

Image: Detailed diagram illustrating the dimensions and individual components of the cat tree, including platforms, houses, and scratching posts.

ASSEMBLY INSTRUCTIONS (SETUP)

Follow these steps carefully to assemble your cat tree. An illustrated manual is included with your product for detailed visual guidance.

1. **Step 1: Prepare the Base.** Place the largest baseboard on a flat, stable surface.

2. **Step 2: Attach Lower Posts.** Screw the first set of sisal scratching posts into the designated holes on the baseboard. Ensure they are tightened securely.

3. **Step 3: Install First Level Platforms and Houses.** Attach the first level of platforms and cat houses to the posts. Follow the numbering or letter coding in your included manual to match parts correctly.

4. **Step 4: Add Middle Posts and Hammock.** Continue by attaching the next set of scratching posts and then secure the hammock between appropriate posts or platforms as indicated in the manual.

5. **Step 5: Assemble Upper Levels.** Proceed with attaching the remaining platforms, cat houses, and perches, working your way upwards.

6. **Step 6: Install Ramp.** Secure the ramp between the specified platforms.

7. **Step 7: Attach Top Perches.** Fasten the top viewing platforms/perches to the uppermost posts.

8. **Step 8: Final Tightening.** Once all components are in place, go back and re-tighten all screws and bolts to ensure maximum stability.

9. **Step 9: Secure with Anti-Tipping Device.** Attach the anti-tipping strap to the top of the cat tree and secure it to a wall stud using the provided wall anchor. This step is crucial for safety.

Stable Durable
Protect the safety of the cat

Image: Illustration demonstrating the proper installation of the anti-tipping device, securing the cat tree to a wall for enhanced stability.

OPERATING INSTRUCTIONS

The Yaheetech Multi-Level Cat Tree is designed to provide a stimulating and comfortable environment for your cats. No specific 'operation' is required beyond providing access to your pets.

- **Encourage Use:** Place the cat tree in an area where your cats spend time. You can encourage initial use by placing treats or toys on different levels.

- **Scratching:** The sisal-wrapped posts are intended for scratching. This helps maintain your cat's claws and protects your furniture.

- **Playing:** The attached plush balls provide interactive play opportunities. Cats can bat, pounce, and play with these toys.

- **Resting:** The various platforms, enclosed cat houses, and hammock offer multiple options for resting, napping, and observing surroundings from different heights.

Image: A collage showcasing cats comfortably utilizing the different features of the cat tree, such as sleeping in the padded beds, exploring the cat houses, and climbing the ramp.

MAINTENANCE

Regular maintenance will extend the life of your cat tree and ensure a hygienic environment for your pets.

- **Cleaning:** Use a lint roller or vacuum cleaner to remove loose fur and dust from the plush surfaces. For spot cleaning, use a damp cloth with mild soap and water, then air dry thoroughly. Avoid harsh chemicals.

- **Sisal Posts:** The sisal rope can be cleaned with a stiff brush to remove debris. If the sisal becomes heavily frayed, consider replacing the post if possible, or wrapping new sisal rope around it.

- **Stability Check:** Periodically check all screws and connections for tightness. Re-tighten any loose parts to prevent wobbling and ensure safety.

- **Damage Inspection:** Inspect the entire structure for any signs of damage, such as cracked boards, torn fabric, or loose components. Address any issues promptly.

Green Materials
Natural Sisal Scratcher
E1-compliant Particle Board

STABLE

Image: A visual representation of the durable materials used in the cat tree's construction, including E1-grade particle board for structural integrity, natural sisal rope for scratching, and soft plush fabric for comfort.

TROUBLESHOOTING

Issue: Cat tree feels wobbly after assembly.
Solution: Ensure all screws and bolts are fully tightened. Re-check each connection point. If the wobbling persists, ensure the cat tree is placed on a completely flat and level surface. Always use the provided anti-tipping device to secure the tree to a wall for maximum stability.

Issue: Cats are not using the scratching posts.
Solution: Try sprinkling catnip on the sisal posts to attract your cats. You can also gently guide your cat's paws to the posts to demonstrate their purpose. Ensure the cat tree is in a prominent location your cat frequents.

Issue: Plush fabric is shedding or tearing.
Solution: Minor shedding is normal initially. If tearing occurs, it may be due to excessive scratching on plush areas. Encourage your cat to use the sisal posts. Small tears can be repaired with fabric glue or by sewing. For significant damage, consider contacting the manufacturer for replacement parts.

SPECIFICATIONS

Feature	Detail
Brand	Yaheetech
Model Number	YA-00130226
Product Dimensions (L x W x H)	60 x 48.5 x 181.5 cm
Product Weight	18.55 kg
Material	E1-grade Particle Board, Plush Fabric, Sisal Rope
ASIN	B0CKHLWCTJ

WARRANTY AND SUPPORT

Specific warranty information for this product is not provided in the available data. For details regarding warranty coverage, returns, or technical support, please contact Yaheetech customer service directly or refer to the purchase documentation provided by your retailer.

When contacting support, please have your model number (YA-00130226) and purchase date available.