

[Manuals.plus](#) /

› [HOMCOM](#) /

› HOMCOM Rollator Walker User Manual

HOMCOM 712-053V00LB

HOMCOM Rollator Walker User Manual

Model: 712-053V00LB

PRODUCT OVERVIEW

The HOMCOM Rollator Walker is a mobility aid designed for seniors and adults, offering stability, comfort, and convenience. It features a durable aluminum frame, a cushioned seat with backrest, and adjustable handles to accommodate various user heights. The walker is equipped with 9.75-inch front wheels and 7.75-inch rear wheels for smooth movement, and a dual-hand braking system for safety. A spacious storage bag is included for personal belongings.



Image: The HOMCOM Rollator Walker, showcasing its blue frame, black seat, backrest, and storage bag. It features four wheels and hand brakes.

Key Features:

- **Integrated Seat and Backrest:** Provides a comfortable resting spot during extended use.
- **Adjustable Height Handles:** Customizable height from 34.25" to 41" to suit users between 4.9 and 6.4 feet tall.

- **Smooth-Rolling Wheels:** Two 9.75" front wheels and two 7.75" rear wheels for stable outdoor navigation.
- **Dual-Hand Brake System:** Allows for controlled stopping and locking the walker in place.
- **Foldable Design:** Facilitates easy transport and compact storage.
- **Storage Pouch:** Conveniently holds personal items.

SETUP AND ASSEMBLY

The HOMCOM Rollator Walker requires minimal assembly. Follow these steps to prepare your walker for use:

1. **Unfold the Walker:** Carefully remove the walker from its packaging. Unfold the frame until it locks securely into place.
2. **Attach Front Wheels:** Insert the front wheels into their designated slots on the walker frame. Ensure they click into place or are secured with the provided fasteners.
3. **Attach Backrest and Seat:** Position the backrest and seat according to the illustrations in the manual. Secure them firmly.
4. **Adjust Handle Height:** Locate the height adjustment knobs on the handle posts. Press or loosen the knobs and slide the handles up or down to your desired height. The ideal height allows your arms to bend slightly at the elbow when gripping the handles, with your shoulders relaxed. Ensure both handles are set to the same height and are securely locked before use.



ADJUSTABLE HANDLE HEIGHT



Image: A close-up view illustrating how to adjust the handle height of the rollator walker, showing the mechanism for raising and lowering the handles.

No additional tools are typically required for assembly.

OPERATING INSTRUCTIONS

Walking with the Rollator:

- **Positioning:** Stand upright with your feet slightly apart, centered behind the walker. Ensure your weight is evenly distributed.
- **Grip:** Hold the handles firmly with both hands.
- **Movement:** Push the walker forward a comfortable distance, then step forward with one foot, followed by the other. Maintain a steady pace.
- **Braking:** The walker is equipped with dual-hand brakes. To slow down or stop, gently squeeze the brake levers towards the handles.
- **Parking Brake:** To lock the wheels in place (e.g., when sitting), push the brake levers down until they click into the

locked position. Pull them up to release.



Image: A detailed view of the ergonomic hand brake lever, designed for easy grip and operation to control the walker's movement.

Using the Seat:

- Ensure the walker is on a flat, stable surface.
- Engage both parking brakes by pushing the levers down. Verify the wheels are locked.
- Turn around and slowly lower yourself onto the seat, using the handles for support if needed.
- Lean back against the backrest for comfort.
- To stand up, push off the seat using your arms and the walker handles for support. Release the parking brakes before resuming walking.

Folding for Storage and Transport:

The rollator can be easily folded for compact storage or transportation in a car trunk or travel case.

1. Ensure the storage bag is empty.

2. Lift the seat or pull the folding mechanism (refer to your specific model's folding instructions if different).
3. Gently push the sides of the walker together until it folds compactly.



FOLDING DESIGN



Easy Storage



Easy to
Transport

Image: The rollator walker shown in its compact, folded state, highlighting its portability and ease of storage.

Using the Storage Bag:

The integrated storage bag is located under the seat. It can be used to carry personal items such as a wallet, keys, or small groceries. Ensure items are securely placed and do not interfere with the walker's operation or folding mechanism.



STORAGE COMPARTMENT



Image: A view of the storage bag attached to the rollator walker, demonstrating its capacity to hold items.

MAINTENANCE

Regular maintenance ensures the longevity and safe operation of your HOMCOM Rollator Walker.

- **Cleaning:** Wipe down the frame, seat, and backrest with a damp cloth and mild soap as needed. Avoid abrasive cleaners.
- **Wheel Inspection:** Periodically check the wheels for wear and tear. Ensure they spin freely and are free of debris. Clean any hair or lint that may accumulate around the axles.
- **Brake Check:** Regularly test the brakes to ensure they engage properly and hold the walker securely. If the brakes feel loose or do not engage effectively, they may need adjustment by a qualified technician.
- **Fastener Check:** Ensure all screws, bolts, and fasteners are tight. Do not overtighten.
- **Storage:** Store the walker in a dry place, away from extreme temperatures and direct sunlight, when not in use.



Image: A detailed shot of one of the rollator's wheels, showing its durable construction and attachment to the aluminum frame.

TROUBLESHOOTING

If you encounter issues with your rollator walker, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Brakes not engaging or too loose.	Brake cable tension is incorrect or worn brake pads.	Check brake cable tension. If adjustment is needed, consult a qualified technician. If pads are worn, replacement may be necessary.
Wheels not rolling smoothly.	Debris caught in wheels or axles, or worn bearings.	Remove any debris (hair, lint) from around the wheels and axles. If the issue persists, bearings may need inspection or replacement by a professional.

Problem	Possible Cause	Solution
Walker feels unstable or wobbly.	Loose fasteners or improper assembly.	Check all visible screws, bolts, and locking mechanisms to ensure they are securely tightened. Re-verify assembly steps.
Difficulty folding the walker.	Obstruction or mechanism not fully disengaged.	Ensure the storage bag is empty and nothing is obstructing the folding mechanism. Apply gentle, even pressure. Do not force.

If the problem persists after attempting these solutions, please contact HOMCOM customer support for further assistance.

SPECIFICATIONS

Feature	Detail
Model Number	712-053V00LB
Product Dimensions (Unfolded)	22.5"D x 22.5"W x 41"H (max height)
Adjustable Handle Height	34.25" - 41"
Item Weight	19 Pounds
Material	Aluminum
Color	Light Blue
Front Wheel Size	9.75 inches
Rear Wheel Size	7.75 inches
Weight Capacity	300 lbs
Manufacturer	Aosom LLC



Image: A dimensional diagram of the rollator walker, providing key measurements for height, width, and depth in both unfolded and folded states.

SAFETY INFORMATION

Always prioritize safety when using your rollator walker. Adhere to the following guidelines:

- **Weight Capacity:** Do not exceed the maximum weight capacity of 300 lbs.
- **Brake Usage:** Always engage the parking brakes when sitting on the seat or when the walker is stationary.
- **Surface Awareness:** Use the walker on stable, level surfaces. Exercise caution on uneven terrain, inclines, or slippery surfaces.
- **Obstacles:** Be aware of obstacles such as rugs, thresholds, or uneven flooring that could cause the walker to tip or snag.
- **Adjustments:** Ensure all adjustable parts (e.g., handle height) are securely locked before use.
- **Medical Advice:** This walker is a mobility aid. Consult with a healthcare professional or physical therapist for proper usage techniques and to determine if this device is suitable for your specific needs.

- **Legal Disclaimer:** Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

WARRANTY AND SUPPORT

For information regarding warranty coverage, parts replacement, or technical support, please contact HOMCOM customer service. Keep your purchase receipt and model number (712-053V00LB) readily available when contacting support. Visit the official HOMCOM website for additional resources and contact information: [HOMCOM Official Store](#)

© 2023 HOMCOM. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question