Silvercrest SBL TW10 A1

Silvercrest SBL TW10 A1 Outdoor Bluetooth Speaker User Manual

Model: SBL TW10 A1

1. INTRODUCTION

Thank you for choosing the Silvercrest SBL TW10 A1 Outdoor Bluetooth Speaker. This manual provides essential information for the safe and efficient operation of your device. Please read it thoroughly before use and keep it for future reference.

The SBL TW10 A1 is a robust, waterproof Bluetooth speaker designed for outdoor use, offering high-quality audio and versatile connectivity options, including True Wireless Stereo (TWS) functionality for an enhanced sound experience.

2. SAFETY INSTRUCTIONS

- Do not expose the speaker to extreme temperatures, direct sunlight, or open flames.
- Ensure the charging port cover is securely closed when not charging to maintain IPX7 waterproof rating.
- Do not attempt to disassemble, repair, or modify the speaker. This will void the warranty and may cause damage or injury.
- Keep the speaker away from children and pets.
- Use only the provided charging cable or a certified equivalent.
- Avoid prolonged listening at high volume levels to prevent hearing damage.

3. PACKAGE CONTENTS

Please check the package for the following items:

- 1 x Silvercrest SBL TW10 A1 Outdoor Bluetooth Speaker
- 1 x Micro-USB Charging Cable
- 1 x 3.5mm AUX-in Cable
- 1 x User Manual (this document)

4. PRODUCT FEATURES

- Integrated rechargeable battery for up to 10 hours of music playback.

- True Wireless Stereo (TWS) function for wireless stereo sound between two SBL TW10 A1 speakers.

- 3.5 mm AUX input for connecting external audio devices.

- Compatible with all common smartphones and tablets.

- Dedicated Bluetooth button for easy device connection.

- Mobile charging via Micro-USB charging port.

- Waterproof according to IPX7 standard.

5. PRODUCT OVERVIEW

Figure 1: Front view of the Silvercrest SBL TW10 A1 Outdoor Bluetooth Speaker, showing its compact design and integrated handle.

Figure 2: Angled view of the speaker, highlighting the top-mounted control buttons for power, volume, and Bluetooth pairing.

Figure 3: Close-up of the rear panel, showing the protected Micro-USB charging port and 3.5mm AUX-in port. Ensure the cover is sealed for waterproofing.

6. Setup

6.1 Charging the Speaker

1. Open the protective cover on the back of the speaker.
2. Connect the Micro-USB end of the charging cable to the speaker's charging port.
3. Connect the USB-A end of the charging cable to a suitable USB power adapter (e.g., 5V/1A, not included) or a computer's USB port.
4. The charging indicator LED will illuminate (color may vary, refer to quick start guide for specifics).
5. Once fully charged, the LED indicator will change or turn off. Disconnect the charging cable and securely close the protective cover to maintain waterproofing.

6.2 Powering On/Off

- **To Power On:** Press and hold the Power button () for approximately 3 seconds until you hear an audible prompt and the LED indicator lights up.
- **To Power Off:** Press and hold the Power button () for approximately 3 seconds until you hear an audible prompt and the LED indicator turns off.

6.3 Bluetooth Pairing

1. Ensure the speaker is powered on and within 10 meters of your Bluetooth device (smartphone, tablet, etc.).
2. The speaker will automatically enter Bluetooth pairing mode, indicated by a flashing blue LED. If not, press the Bluetooth button ( ) to activate pairing mode.
3. On your Bluetooth device, enable Bluetooth and search for available devices.

4. Select "SBL TW10 A1" from the list of found devices.

5. Once successfully paired, the LED indicator will turn solid blue, and you will hear a confirmation sound.

6.4 True Wireless Stereo (TWS) Pairing

The TWS function allows you to connect two SBL TW10 A1 speakers for a true stereo sound experience.

Figure 4: Two individual Silvercrest SBL TW10 A1 speakers, ready for TWS pairing to create a stereo sound system.

1. Ensure both SBL TW10 A1 speakers are powered on and not connected to any other Bluetooth device.

2. On one speaker (this will be the primary speaker), press and hold the TWS button (often combined with the Bluetooth button or a dedicated TWS icon) for approximately 3 seconds. The speaker will enter TWS pairing mode.

3. The second speaker (secondary speaker) will automatically search for the primary speaker.

4. Once successfully paired, both speakers will emit a confirmation sound, and their LED indicators will show a stable connection (e.g., primary speaker flashing blue for device pairing, secondary speaker solid blue).

5. Now, connect your Bluetooth device to the primary speaker as described in section 6.3. Audio will play through both speakers in stereo.

6.5 AUX Connection

1. Open the protective cover on the back of the speaker.

2. Connect one end of the 3.5mm AUX-in cable to the speaker's AUX port.

3. Connect the other end of the 3.5mm AUX-in cable to the audio output jack of your external audio device (e.g., MP3 player, computer).

4. The speaker will automatically switch to AUX mode.

5. Adjust volume using the speaker's controls or your connected device.

6. Remember to close the protective cover when not using the AUX port to maintain waterproofing.

7. OPERATING

7.1 Basic Controls

Button/Action	Function
Power Button ( )	Press and hold for 3 seconds to Power On/Off.
Volume Up (+)	Short press to increase volume. Long press for next track.
Volume Down (-)	Short press to decrease volume. Long press for previous track.
Play/Pause Button ( )	Short press to Play/Pause music.
Bluetooth Button ( )	Short press to enter Bluetooth pairing mode. Long press for TWS pairing (if applicable).

7.2 LED Indicators

- **Flashing Blue LED:** Bluetooth pairing mode.
- **Solid Blue LED:** Bluetooth connected.
- **Red LED (Charging):** Speaker is charging.
- **LED Off (Charging):** Speaker is fully charged.

8. MAINTENANCE

8.1 Cleaning

- Wipe the speaker with a soft, damp cloth. Do not use abrasive cleaners, alcohol, or chemical solvents.
- Ensure the charging and AUX ports are dry before opening their protective covers.

8.2 Storage

- Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- If storing for an extended period, charge the battery to approximately 50% every 3-6 months to prolong battery life.

8.3 Battery Care

- Avoid fully discharging the battery frequently.
- Do not leave the speaker connected to power for extended periods after it is fully charged.

9. TROUBLESHOOTING

| Problem	Possible Cause	Solution
Speaker does not power on.	Battery is depleted.	Charge the speaker fully.
No sound from speaker.	Volume is too low. Incorrect input mode. Device not connected.	Increase speaker and device volume. Ensure correct mode (Bluetooth/AUX). Reconnect Bluetooth device or AUX cable.

| Problem	Possible Cause	Solution
Bluetooth connection fails.	Speaker is too far from device. Speaker is already connected to another device. Bluetooth on device is off.	Move speaker closer to device. Disconnect from other devices. Enable Bluetooth on your device. Try forgetting and re-pairing.
TWS pairing fails.	Speakers are too far apart. One speaker is already connected to a Bluetooth device.	Ensure speakers are within close proximity. Disconnect any Bluetooth devices from both speakers before TWS pairing.

10. SPECIFICATIONS

Feature	Specification
Model Name	SBL TW10 A1
Output Power	2 x 10 W RMS
Battery	Li-Ion 3.7 V, 2000 mAh
Bluetooth Version	v5.0
Bluetooth Range	Up to 10 meters (33 feet)
Waterproof Rating	IPX7
Connectivity	Bluetooth, 3.5mm AUX, Micro-USB (charging)
Audio Output Mode	Stereo
Product Dimensions	12 x 9 x 10 cm (approx.)
Material	Plastic
Compatible Devices	Smartphones, Tablets, Laptops, TVs, MP3 Players
Controller Type	Button

11. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the warranty card included with your purchase or contact Silvercrest customer service through their official website or the retailer where you purchased the product. Please have your model number (SBL TW10 A1) and proof of purchase ready when contacting support.

Related Documents - SBL TW10 A1

	Silvercrest SBL TW10 A1 Outdoor Bluetooth Speaker User Manual User manual for the Silvercrest SBL TW10 A1 Outdoor Bluetooth Speaker, detailing features like Bluetooth 5.0, IPX7 splash-proofing, and TWS pairing. Includes setup, operation, safety instructions, technical specifications, troubleshooting, and warranty information from Lidl US, LLC.
	MBJ Barlight Series Technical Data and Operating Manual Technical specifications, operating instructions, and safety notes for the MBJ Barlight Series LED lighting, including mechanical integration, electrical connections, and application examples.
	Tarsafe TW10/TW10 SB Automotive Alarm System Manual Comprehensive manual for the Tarsafe TW10 and TW10 SB automotive alarm systems, covering installation, features, programming, and troubleshooting.
	SilverCrest Bluetooth Speaker SBL 5WL A1 User Manual and Safety Information Comprehensive user manual and safety notes for the SilverCrest Bluetooth Speaker SBL 5WL A1, distributed by Lidl US, LLC. Includes operation instructions and safety guidelines in English and Spanish.
	SilverCrest SBL 3 D2 Bluetooth Bathroom Speaker: Operating and Safety Instructions User manual for the SilverCrest SBL 3 D2 Bluetooth Bathroom Speaker, providing comprehensive operating instructions, safety guidelines, technical specifications, and troubleshooting tips for optimal use.
	groov-e GV-TW10 Ultra Buds: Active Noise Cancelling True Wireless Earbuds Quick Start Guide Get started with your groov-e GV-TW10 Ultra Buds. This guide provides instructions on setup, pairing, charging, features, and specifications for these Active Noise Cancelling True Wireless Earbuds.

Documents - Silvercrest – SBL TW10 A1

Silvercrest SBL TW10 A1 Outdoor Bluetooth Speaker User Manual
User manual for the Silvercrest SBL TW10 A1 Outdoor Bluetooth Speaker, detailing features like Bluetooth 5.0, IPX7 splash-proofing, and TWS pairing. Includes setup, operation, safety instructions, technical specifications, troubleshooting, and warranty information from Lidl US, LLC.
lang:en score:25 filesize: 1.18 M page_count: 44 document date: 2021-03-14