

[Manuals.plus](#) /

› [KEiID](#) /

› KEiID 2.1 Bluetooth Computer Speakers User Manual

KEiID KD-C02 2.1CH

KEiID 2.1 Bluetooth Computer Speakers User Manual

Model: KD-C02 2.1CH

OVERVIEW

The KEiID 2.1 computer speaker system is designed to provide a high-quality audio experience for various devices, including desktops, laptops, TVs, phones, and tablets. It features a sleek, modern design with advanced functionalities like wireless connectivity and multiple EQ modes. The system includes two satellite speakers, a wireless subwoofer, and a wireless touchpad for convenient control.



Image: Complete KEiiD 2.1 speaker system including satellite speakers, wireless subwoofer, and wireless touchpad.

WHAT'S IN THE BOX

- L+R Speakers
- Wireless Subwoofer
- Wireless Touchpad
- 12V2A Power Adapter (x2)
- 3.5mm Audio Cable (59 inch)
- L-R Speaker Cable (71 inch)
- User Manual

Packing List:



- 1 L+R Speakers
Wireless subwoofer
Wireless touchpad



- 3 12V2A DC adapter
x2



- 2 L-R speaker cable
(71 inch)



- 4 3.5mm audio cable
(59 inch)

Image: Visual representation of all components included in the KEiD 2.1 speaker system package.

SETUP GUIDE

Physical Connections

1. Connect the left and right satellite speakers using the provided L-R speaker cable.
2. Connect the 12V2A power adapters to the speakers and plug them into a power outlet.
3. For wired connection, connect your device (PC, TV, etc.) to the speakers using the 3.5mm audio cable.

Wireless Pairing

- **Wireless Subwoofer:** The subwoofer connects wirelessly to the main speaker system automatically upon power-on. Ensure both the speakers and subwoofer are powered on.
- **Bluetooth Connection:** To connect your computer, phone, or tablet wirelessly, activate Bluetooth on your device and select 'KEiD KD-C02' from the available devices list.
- **Wireless Touchpad:** The touchpad is pre-paired with the system for immediate wireless control.



Triple WIRELESS

- 1 Wireless connection, Connects speaker system to your computer wirelessly via Bluetooth.
- 2 Wireless subwoofer, The connect between subwoofer and the R & L speaker is wireless.
- 3 Wireless touchpad control., easily control the system within a simple touch.

IMPORTANT: Important: Some users mistakenly complain that the subwoofer is not working, please understand that all subwoofers are only used to boost bass with frequencies below 250Hz, it does not produce treble and midrange, please research the relevant knowledge online before submitting any complaints..

Image: Illustration of the triple wireless connectivity: main speakers to computer via Bluetooth, wireless subwoofer, and wireless touchpad control.

OPERATING INSTRUCTIONS

Wireless Touchpad Control

The innovative wireless touchpad allows for easy control of the speaker system from anywhere in the room. Functions include:

- Power On/Off
- Volume Up/Down
- Play/Pause

- Mode Selection (Bluetooth/Auxiliary)
- EQ Mode Switching

EQ Modes

The KEiD KD-C02 offers four distinct EQ modes to optimize your listening experience:

- **News Mode:** Enhances vocal clarity for news broadcasts and podcasts.
- **Music Mode:** Provides a balanced sound profile for general music listening.
- **Movie Mode:** Offers a more immersive audio experience with enhanced dynamics for films.
- **Game Mode:** Delivers a 3D surround sound effect for an enhanced gaming experience.



Image: The speaker system in a desktop setup, illustrating the four available EQ modes for various audio content.

Connectivity Options

The speaker system supports multiple ways to connect your audio sources:

- **Wireless Bluetooth:** For seamless audio streaming from Bluetooth-enabled devices.

- **Wired 3.5mm Connection:** For traditional audio input from devices with a 3.5mm audio jack.



All types of desktops/laptops can be easily connected

- Wireless connect via Bluetooth
- Wired connect via audio cable

Image: A KEiiD speaker positioned next to a laptop, highlighting the flexibility of both wireless Bluetooth and wired audio cable connections.

MAINTENANCE

To ensure the longevity and optimal performance of your KEiiD speaker system, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe down the speaker surfaces. Avoid using abrasive cleaners or solvents, which can damage the finish.
- **Placement:** Place speakers on a stable, flat surface away from direct sunlight, heat sources, and excessive moisture. Ensure adequate ventilation around the subwoofer.
- **Cable Management:** Keep cables organized and untangled to prevent damage and ensure proper

connection.

- **Storage:** If storing the speakers for an extended period, disconnect them from power and store them in a cool, dry place.

TROUBLESHOOTING

If you encounter issues with your KEiiD speaker system, please refer to the following common solutions:

- **No Power:** Ensure both power adapters are securely connected to the speakers and plugged into a working power outlet. Check if the power indicator light on the touchpad is on.
- **No Sound:** Verify that the volume is turned up on both the speakers and your connected device. Check that the correct input mode (Bluetooth or Aux) is selected. For wired connections, ensure the 3.5mm audio cable is fully inserted into both the speaker and the device.
- **Bluetooth Pairing Issues:** Make sure the speakers are in Bluetooth pairing mode (indicated by a flashing light). Turn off and on Bluetooth on your device, then try re-pairing. Ensure no other devices are currently connected to the speakers.
- **Subwoofer Not Working / Low Bass:** It is important to understand that subwoofers are designed to boost bass frequencies below 250Hz and do not produce high or mid-range sounds. If you perceive the subwoofer as 'defective', ensure it is powered on and wirelessly connected. Adjust the EQ mode to 'Movie' or 'Game' for enhanced bass output. If the issue persists, ensure the subwoofer is placed on a solid surface and not obstructed.
- **Distorted Sound:** Reduce the volume on both the speakers and your device. Check for any physical obstructions or damage to the speaker cones. Ensure the audio source is of good quality.

If these steps do not resolve the issue, please contact KEiiD customer support for further assistance.

TECHNICAL SPECIFICATIONS

Feature	Specification
Model Name	C02.1
Speaker Type	Surround Sound 2.1 with Subwoofer
Mounting Type	Tabletop Mount
Material	Plastic, Metal
Product Dimensions	3.7"D x 3.7"W x 6.7"H
Item Weight	9 Pounds
Speaker Size	2.5 Inches
Subwoofer Diameter	4 Inches

Tweeter Diameter	1 Inches
Speaker Maximum Output Power	40 Watts
Frequency Response	20 KHz
Connectivity Technology	Bluetooth, Auxiliary
Bluetooth Range	50 Meters
Controller Type	Wireless Touchpad, Buttons
Color	Gray




Image: Detailed view of speaker dimensions and internal components, including the 1-inch dome-silk tweeter and 2.5-inch mid-range speaker, and the 4-inch subwoofer.

WARRANTY AND SUPPORT

KEiID prioritizes quality and customer satisfaction. Your KEiID speaker system comes with:

- **24-Month Protection Plan:** You can register for a free 24-month protection plan upon receiving your product.
- **24/7 Online After-Sales Support:** For any questions or issues, KEiID offers continuous online support.

For support, please refer to the contact information provided in your product packaging or visit the official KEiID website.

© 2025 KEiID. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question