Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Hot Wheels HXM94

Hot Wheels Action Loop Cyclone Challenge Track Set

Model: HXM94

Introduction

Welcome to the Hot Wheels Action Loop Cyclone Challenge Track Set instruction manual. This dynamic track set offers two exciting ways to play, featuring thrilling boomerang loops and a challenging jump-and-score target. Designed for high-speed action and easy storage, this set provides hours of engaging play. Please read this manual carefully to ensure proper assembly, operation, and maintenance of your new Hot Wheels track set.



The Hot Wheels Action Loop Cyclone Challenge Track Set, fully assembled and ready for play.

Safety Information

Please observe the following safety guidelines to ensure a safe play experience:

- **Adult Supervision:** Adult supervision is recommended during assembly and play, especially for younger children.
- **Age Recommendation:** This product is suitable for children aged 4 years and up.
- **Small Parts:** The set may contain small parts before assembly. Keep away from children under 3 years to prevent choking hazards.
- **Flat Surface:** Always assemble and operate the track set on a flat, stable surface to prevent tipping and ensure optimal performance.

Package Contents

Verify that all components are present in your package:

- 1 x Hot Wheels Loop Cyclone Challenge Track Set (unassembled components)
- 1 x Hot Wheels 1:64 Scale Toy Car



The Hot Wheels Action Loop Cyclone Challenge Track Set as it appears in its retail packaging.

Setup: Assembly Instructions

Follow these steps to assemble your Hot Wheels Action Loop Cyclone Challenge Track Set:

1. **Unpack Components:** Carefully remove all track pieces, supports, and the launcher from the packaging.
2. **Connect Base Pieces:** Identify the main base sections and connect them securely. Ensure all connection points click into place.
3. **Attach Supports:** Insert the blue support pillars into their designated slots on the track base to provide stability for the elevated sections.
4. **Assemble Loops:** Connect the orange and blue loop sections according to the arrows and guides on the pieces. Ensure they form complete, stable loops.
5. **Integrate Launcher:** Attach the light blue launcher mechanism to the designated starting point of the track.

6. **Final Connections:** Connect any remaining track segments to complete the full circuit, ensuring all pieces are firmly interlocked.



The fully assembled track set, ready for play.

Operating Instructions: How to Play

The Hot Wheels Action Loop Cyclone Challenge Track Set offers two primary modes of play:

1. Boomerang Loops for Repeat Racing

Place the included 1:64 scale Hot Wheels car at the starting point of the launcher. Slam the launcher to send the car through the thrilling boomerang loops. The track is designed to return the car to the starting point, allowing for continuous, repeat racing action. Experiment with different launch forces to master the loops.



A child engaging in continuous racing by launching a car through the track's loops.



The blue ramp can be lifted to allow the car to continue racing through the loops.

2. Jump and Score Challenge

For a different challenge, flip over the designated ramp section. This reconfigures the track to create a jump target. Aim to launch your car with just the right amount of power to land it perfectly on the scoring zone, accumulating points. Practice your launching skills to achieve the highest score!



Slam launch the car with precision to hit the scoring zone.



The impressive 18-inch (45 cm) tall loop is a central feature of the track set.

Maintenance

Cleaning

To clean the track set, wipe surfaces with a slightly damp cloth. Do not immerse the track in water or use harsh chemicals, as this may damage the plastic components or decals.

Storage

The Hot Wheels Action Loop Cyclone Challenge Track Set is designed for easy and convenient storage. The set collapses by flipping the track pieces and folding it up. It also features a built-in carrying handle for portability.



The track set folds compactly for easy storage, such as under a bed.

Troubleshooting

If you encounter any issues with your Hot Wheels Action Loop Cyclone Challenge Track Set, please refer to the table below for common problems and solutions:

Problem	Possible Cause	Solution
Car does not complete the loop.	Insufficient launch force; track not fully connected.	Slam the launcher with more force. Ensure all track pieces are securely connected and on a flat surface.
Car veers off track.	Track not level; loose connections; car not aligned.	Place the track set on a completely flat and stable surface. Check all track connections for tightness. Ensure the car is placed correctly on the starting line.
Launcher mechanism is stiff or not working.	Debris in mechanism; improper assembly.	Check for any obstructions in the launcher. Re-check the assembly of the launcher to ensure it is correctly attached and aligned.

Product Specifications

Feature	Detail
Product Dimensions (L x W x H)	30.5 x 26.6 x 18.8 inches
Item Weight	2.22 pounds
Item Model Number	HXM94
Manufacturer Recommended Age	4 years and up
Manufacturer	Mattel

Warranty and Support

Warranty Information

This Hot Wheels product is covered by a manufacturer's warranty against defects in materials and workmanship. Please refer to the packaging or the official Hot Wheels website for specific warranty terms and conditions.

Customer Support

For further assistance, troubleshooting not covered in this manual, or to inquire about replacement parts, please contact Hot Wheels customer support. Visit the official Hot Wheels website for contact information and frequently asked questions.

© 2023 Mattel. All Rights Reserved. Hot Wheels and associated trademarks are owned by Mattel.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CKJ6WGWW

More documents and user manuals: **https://manuals.plus/**