

[Manuals.plus](#) /

› [YUYIU](#) /

› YUYIU Switch Pro Controller Gamepad for Nintendo Switch, Switch Lite, and Switch OLED - User Manual

YUYIU Switch Pro Controller

YUYIU Switch Pro Controller User Manual

Wireless Gamepad for Nintendo Switch, Switch Lite, and Switch OLED

1. PRODUCT OVERVIEW

The YUYIU Switch Pro Controller is a versatile wireless gamepad designed for an enhanced gaming experience across multiple platforms. It features dual vibration motors, a turbo function, and a 6-axis sensor system for precise control. Its ergonomic design ensures comfort during extended play sessions.



This image displays the YUYIU Switch Pro Controller in a vibrant red color. The controller features two analog joysticks, a D-pad with a checkered pattern, and the standard ABXY action buttons. Central function buttons, including Home, Share, and Menu, are also visible. The ergonomic design includes textured grips on the handles for enhanced comfort and control.

Key Features:

- High compatibility with Nintendo Switch, Switch Lite, Switch OLED, and Windows PC (wired connection only).
- Integrated dual vibration motors for immersive feedback.
- Automatic and manual turbo function with 3 adjustable speeds.
- 6-axis sensor system for precise motion control.
- Ergonomic and anti-slip design for comfortable, long-duration gaming.
- Built-in 550 mAh rechargeable battery for extended playtime.

2. SETUP AND CONNECTION

2.1 Connecting to Nintendo Switch / Switch Lite / Switch OLED

1. Ensure your Nintendo Switch console is powered on and updated to the latest system version.
2. From the HOME Menu, select "Controllers" > "Change Grip/Order".
3. On the controller, press and hold the SYNC button (usually a small button on the top or back) for a few seconds until the LED indicators start flashing rapidly.
4. Once the controller is successfully paired, the player LED(s) on the controller will light up solid.
5. You can now use your YUYIU Switch Pro Controller wirelessly with your Nintendo Switch console.

2.2 Connecting to PC (Windows)

Note: Wireless connection to PC is not supported. The controller must be connected via a Type-C USB cable.

1. Connect one end of the provided Type-C USB cable to the controller.
2. Connect the other end of the USB cable to an available USB port on your Windows PC.
3. Your PC should automatically detect and install the necessary drivers. This may take a few moments.
4. Once installed, the controller will be ready for use with compatible PC games.

3. OPERATING INSTRUCTIONS

3.1 Turbo Function

- **Setting Turbo:** Press and hold the button you wish to set for turbo, then press the Turbo button once. The button will now repeatedly activate as long as it's held down.
- **Adjusting Turbo Speed:** While holding the Turbo button, move the right analog stick up or down to cycle through 3 different turbo speeds (slow, medium, fast).
- **Clearing Turbo:** Press and hold the turbo-enabled button, then press the Turbo button twice. Alternatively, press and hold the Turbo button for 5 seconds to clear all turbo settings.

3.2 Dual Vibration

The controller features dual motors that provide haptic feedback, enhancing immersion in games that support vibration. The intensity of the vibration is typically controlled by the game itself.

3.3 6-Axis Motion Control

The built-in 6-axis sensor system allows for precise motion control in games that utilize this feature, providing an intuitive way to interact with the game environment.

4. CHARGING AND BATTERY LIFE

The controller is equipped with a 550 mAh rechargeable battery.

- **Charging Time:** Approximately 2-3 hours for a full charge.
- **Playtime:** A full charge provides approximately 6-8 hours of gameplay. With 3.5 hours of charging, it can provide up to 10 hours of playtime.
- **Charging Method:** Connect the controller to a USB power source (e.g., Switch dock, PC, USB wall adapter) using the provided Type-C USB cable. The LED indicators will show charging status.

5. MAINTENANCE

To ensure the longevity and optimal performance of your YUYIU Switch Pro Controller, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the controller. For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals or abrasive cleaners.
- **Storage:** Store the controller in a cool, dry place away from direct sunlight, extreme temperatures, and excessive moisture.
- **Handling:** Avoid dropping the controller or subjecting it to strong impacts, as this can damage internal components.

- **Battery Care:** Do not attempt to replace the internal battery. If the controller will not be used for an extended period, charge it periodically to maintain battery health.

6. TROUBLESHOOTING

If you encounter issues with your YUYIU Switch Pro Controller, please refer to the following common solutions:

- **Controller Not Connecting:**
 - Ensure the controller is charged.
 - Verify the console is powered on and within range.
 - Repeat the pairing process as described in Section 2.1.
 - If connecting to PC, ensure the Type-C cable is securely connected and try a different USB port.
- **Buttons or Joysticks Unresponsive:**
 - Restart the controller by holding the Home button for 10 seconds, then pressing it again to turn it back on.
 - Ensure the controller's firmware is up to date (check the manufacturer's website if updates are available).
 - Test the controller in a different game or on another compatible device to isolate the issue.
- **Vibration Not Working:**
 - Check in-game settings to ensure vibration is enabled.
 - Ensure the controller is fully charged.
- **Charging Issues:**
 - Try a different Type-C USB cable and a different power source.
 - Ensure the charging port on the controller is clean and free of debris.

7. SPECIFICATIONS

Feature	Detail
Model	YUYIU Switch Pro Controller
Compatibility	Nintendo Switch, Switch Lite, Switch OLED, Windows PC (wired)
Connectivity	Wireless (Bluetooth for Switch), Wired (USB Type-C for PC)
Battery Capacity	550 mAh
Charging Time	Approx. 2-3 hours
Playtime	Approx. 6-8 hours (up to 10 hours with 3.5h charge)
Vibration	Dual Motors
Motion Control	6-axis sensor

8. WARRANTY AND SUPPORT

YUYIU is committed to providing a quality gaming experience. If you encounter any problems during use, please contact YUYIU customer service via email. Our customer service team is dedicated to resolving your issues as quickly as possible.

Please refer to your purchase documentation or the official YUYIU website for specific warranty terms and contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question