

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Lexibook](#) /

› [Lexibook Disney Stitch Educational Night Companion RLT100D User Manual](#)

Lexibook RLT100D

Lexibook Disney Stitch Educational Night Companion RLT100D User Manual

INTRODUCTION

The Lexibook Disney Stitch Educational Night Companion RLT100D is designed to assist with sleep routines and morning awakenings. This device functions as an alarm clock, night light, dawn simulator, and storyteller. It features adjustable alarm tones and volume, a nap timer, and a unique eye-closing/opening mechanism to signal sleep and wake times. Both analog and digital time displays are included for easy learning.

Safety Warning: The battery must not be exposed to excessive heat (sunlight, fire, etc.).

SETUP

Package Contents

- 1 Stitch Night Companion Alarm Clock
- 1 USB-C Cable
- 1 User Manual

Powering the Device

Connect the provided USB-C cable to the device's charging port and to a suitable USB power adapter (not included). The device includes a rechargeable 1200mAh battery. A CR2032 battery is also required for certain functions (e.g., memory backup).



Image: Rear view of the Lexibook Disney Stitch Night Companion, showing the USB-C port, speaker, and control buttons.

OPERATING INSTRUCTIONS

General Controls

The device features intuitive controls, primarily located on the back and through interaction with Stitch's ears. Pressing Stitch's ears allows you to change melodies, light ambiance, or set the alarm.



Image: Front view of the Stitch Night Companion, displaying both analog and digital time.

Setting the Alarm

1. Locate the alarm setting buttons on the device.
2. Follow the on-screen prompts or refer to the specific button functions to set your desired alarm time.
3. Choose from a variety of gentle or fun alarm tones.
4. Adjust the alarm volume to your preference.

Night Light and Mood Lighting

Activate the night light feature to create a soothing environment. The device offers personalized melodies and adjustable light ambiance, playing for 15 to 120 minutes.



Image: The Stitch Night Companion providing a gentle glow in a dark room, observed by a child and adult.

Dawn Simulator

Program a progressive lighting feature that simulates the sunrise, providing a gentle awakening. Select from 14 relaxing melodies to accompany the dawn simulation.



Image: A child stretching in bed, with the Stitch Night Companion on the bedside table, suggesting a gentle morning wake-up.

Storyteller Function

The device can captivate with exciting stories, transforming bedtime into an adventure. Refer to the specific controls for activating and selecting stories.

Nap Timer

Set a nap timer for 15 to 120 minutes to ensure perfect rest periods.

Time Display

The device features both analog and digital time displays, aiding in learning to read time.

MAINTENANCE

To ensure the longevity of your Lexibook Disney Stitch Night Companion, follow these maintenance guidelines:

- **Cleaning:** Wipe the device with a soft, dry cloth. Do not use abrasive cleaners or immerse the device in water.
- **Battery Care:** Recharge the internal 1200mAh battery regularly. If the device will not be used for an

extended period, fully charge it before storage and recharge periodically to maintain battery health.

- **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

If you encounter issues with your Lexibook Disney Stitch Night Companion, please refer to the following common solutions:

Problem	Possible Cause	Solution
Device does not power on.	Low or depleted internal battery; power cable not connected.	Ensure the USB-C cable is securely connected and the device is charging. Allow sufficient time for the internal rechargeable battery to charge.
Difficulty setting time or alarm.	Incorrect button sequence; unfamiliarity with controls.	Refer to the "Operating Instructions" section for detailed steps on setting each function. Practice using the ear buttons and rear controls.
Alarm or night light not activating.	Feature not properly set or activated.	Double-check the settings for the alarm, night light, or dawn simulator to ensure they are enabled and configured correctly.
Stories are not playing or are inappropriate.	Story selection error; content specific to region.	Verify the story selection. Note that story content may vary by region or language.

If the problem persists after attempting these solutions, please contact customer support.

SPECIFICATIONS

Model Number	RLT100D
Product Dimensions (L x W x H)	13 x 8 x 13.5 cm
Weight	280 Grams
Power Source	USB-C (cable included)
Battery Type	Rechargeable 1200mAh (included), 1 CR2032 (for backup)
Components Included	1 Night Companion Alarm Clock, 1 USB-C Cable, 1 User Manual
Manufacturer	Lexibook
Country of Origin	China

WARRANTY AND SUPPORT

This Lexibook product comes with a **2-year warranty**. For warranty claims or technical support, please refer to the contact information provided on the product packaging or the official Lexibook website. Keep your proof of purchase for warranty validation.

