Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Sunbeam /
- Sunbeam Cordless 1.7 litre Stainless Steel Kettle SDK-011A

Sunbeam SDK-011A

Sunbeam Cordless 1.7 Litre Stainless Steel Kettle

Model: SDK-011A

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions before using the kettle.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and injury to persons, do not immerse cord, plugs, or electric base in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
- · Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- The kettle must only be used with the stand provided.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

PRODUCT OVERVIEW



Image: The Sunbeam Cordless 1.7 Litre Stainless Steel Kettle, featuring a brushed stainless steel body, black handle, lid, and spout. A clear water level indicator with markings for MIN, 0.5L, 1.0L, 1.5L, and MAX 1.7L is visible on the side. The Sunbeam logo is printed near the base.

The Sunbeam SDK-011A is a cordless 1.7 litre stainless steel kettle designed for efficient water boiling. It features a concealed heating element for safety and easy cleaning, a hinged lid for convenient filling, and a large water window for clear visibility of water levels. The kettle also includes an automatic shut-off function and boil-dry protection for enhanced safety.

SETUP

- 1. **Unpacking:** Carefully remove the kettle and its power base from the packaging. Retain packaging for future storage or disposal.
- 2. **First Use Cleaning:** Before first use, fill the kettle with clean water to the MAX level. Boil the water, then discard it. Repeat this process two to three times to remove any manufacturing residues.
- 3. Placement: Place the power base on a flat, stable, heat-resistant surface. Ensure the power cord is not dangling or

in contact with hot surfaces.

4. Connecting to Power: Plug the power cord into a suitable wall outlet (230 Volts).

OPERATING INSTRUCTIONS

- 1. **Filling the Kettle:** Open the hinged lid and fill the kettle with the desired amount of water. Ensure the water level is between the MIN (0.5L) and MAX (1.7L) markings on the water level indicator. Do not overfill or underfill.
- 2. Placing on Base: Place the kettle securely onto its cordless power base.
- 3. **Switching On:** Press the ON/OFF switch located near the handle downwards. An indicator light will illuminate, signifying that the kettle is heating.
- 4. **Automatic Shut-off:** The kettle will automatically switch off once the water has boiled. The indicator light will extinguish, and the switch will return to the UP position.
- 5. **Pouring:** Carefully lift the kettle from the base and pour the hot water. The heat-resistant handle ensures safe handling.
- 6. **Re-boiling:** If you need to re-boil, wait a few moments for the automatic switch to reset before pressing it down again.

Note: The kettle features boil-dry protection. If the kettle is accidentally switched on without sufficient water, it will automatically switch off to prevent damage. Allow it to cool down before refilling and operating again.

MAINTENANCE

Cleaning the Exterior

- Always unplug the kettle from the power outlet and allow it to cool completely before cleaning.
- Wipe the exterior of the kettle with a soft, damp cloth. Do not use abrasive cleaners or scouring pads, as they may scratch the stainless steel finish.
- Never immerse the kettle or its power base in water or any other liquid.

Descaling

Over time, mineral deposits (limescale) may build up inside the kettle, especially in hard water areas. Regular descaling will help maintain performance and extend the life of your kettle.

- Fill the kettle with a mixture of one part white vinegar and two parts water. Alternatively, use a commercial descaling solution following the product's instructions.
- Bring the mixture to a boil and then let it stand for at least 30 minutes, or longer for heavy scale build-up.
- Empty the kettle and rinse thoroughly with fresh water several times to remove any residue and vinegar smell.
- If necessary, repeat the process until all scale is removed.

Storage

When not in use, store the kettle and its power base in a dry, safe place, away from direct sunlight and out of reach of children.

TROUBLESHOOTING

Problem Possible Cause	Solution
------------------------	----------

Problem	Possible Cause	Solution
Kettle does not switch on.	Not plugged in. No power at outlet. Kettle not properly seated on base. Boil-dry protection activated.	Ensure plug is firmly in the wall outlet. Check household fuse/circuit breaker. Ensure kettle is correctly placed on the power base. Allow kettle to cool down for 10-15 minutes, then refill and try again.
Water not boiling.	Kettle not switched on. Insufficient water.	Press the ON/OFF switch down. Ensure water level is above MIN mark.
Kettle switches off before boiling.	Limescale build-up. Boil-dry protection activated (if water level is low).	Descale the kettle as per maintenance instructions. Ensure water level is above MIN mark.
Water tastes strange or has particles.	New kettle residue. Limescale build-up.	Perform first use cleaning again. Descale the kettle.

SPECIFICATIONS

Model:	SDK-011A
Brand:	Sunbeam
Capacity:	1.7 Liters
Power / Wattage:	2000 Watt-hours
Voltage:	230 Volts
Material:	Stainless Steel, Plastic
Colour:	Silver
Item Weight:	1 kg
Product Dimensions (L x W x H):	12 x 12 x 22 cm
Special Features:	Heat Resistant Handle, Auto Shutoff, Concealed Heating Element, Boil Dry Function, Hinged Lid, Large Water Window

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included with your purchase or contact Sunbeam customer service directly. Keep your proof of purchase for any warranty claims.

*Note: Spare part information is not available or provided with this product.

© 2023 Sunbeam. All rights reserved.



Sunbeam Rise Up 1.7L Kettle KEP0007WH User Guide

Official user guide for the Sunbeam Rise Up 1.7L Kettle (model KEP0007WH). Learn about features, safe operation, care, cleaning, and the 3-way safety system.



Sunbeam 1L Maestro Kettle User Guide and Safety Instructions

Comprehensive user guide for the Sunbeam 1L Maestro Kettle (KEM1100), covering safety precautions, features, operation, cleaning, and warranty information for optimal use.



Sunbeam Maestro Kettle Quiet Shield KE6451 User Guide

Official user guide for the Sunbeam Maestro Kettle Quiet Shield (Model KE6451). Provides detailed information on safety precautions, product features, operating instructions, care and cleaning procedures, and warranty details.



Sunbeam Cafe Series® QT Kettle User Guide KE9650

User guide for the Sunbeam Cafe Series® QT Kettle (Model KE9650), covering safety precautions, features, operating instructions, tea brewing tips, care and cleaning, and warranty information.



Sunbeam

Sunbeam Express Kettle KE1600 User Guide - Features, Safety, and Operation

Comprehensive user guide for the Sunbeam Express Kettle KE1600, covering safety precautions, product features, operating instructions, care and cleaning, and warranty information.



Sunbeam BLACK CLASSICS GLASS KETTLE

Sunbeam Black Classics Glass Kettle User Guide

User guide for the Sunbeam Black Classics Glass Kettle (Model KE6450K), including safety precautions, features, usage instructions, and care and cleaning information.