

Volkano X-Python Series

Volkano X-Python Series Bluetooth Speaker

User Instruction Manual

1. INTRODUCTION

Thank you for purchasing the Volkano X-Python Series Bluetooth Speaker. This manual provides detailed instructions for the proper setup, operation, and maintenance of your device. Please read this manual thoroughly before use to ensure optimal performance and safety.

2. SAFETY INFORMATION

- Do not expose the speaker to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping or subjecting the speaker to strong impacts.
- Do not disassemble, repair, or modify the speaker yourself. Refer all servicing to qualified personnel.
- Keep the speaker away from water and liquids, despite its IPX6 rating, to prevent damage.
- Use only the provided charging cable or a certified equivalent.
- Do not operate the speaker near medical devices or in environments where wireless devices are restricted.

3. PACKAGE CONTENTS

Please ensure all items are present in your package:

- Volkano X-Python Series Bluetooth Speaker
- USB Charging Cable
- AUX Cable
- Shoulder Strap
- Instruction Manual

4. PRODUCT OVERVIEW

Familiarize yourself with the components and controls of your Volcano X-Python Series Bluetooth Speaker.



Figure 4.1: Front view of the Volcano X-Python Series Bluetooth Speaker, showcasing the control panel and speaker grille.



Figure 4.2: The Volcano X-Python Series Bluetooth Speaker shown with its detachable shoulder strap, highlighting its portability.



Figure 4.3: Side view of the Volkano X-Python Series Bluetooth Speaker, showing the illuminated Volkano logo on the end cap.

Control Panel Layout:

1. **Power Button:** Press and hold to turn on/off.
2. **Play/Pause Button:** Play or pause audio.
3. **Mode Button (M):** Switch between Bluetooth, FM Radio, USB, and AUX modes.
4. **Volume Down / Previous Track:** Short press for volume down, long press for previous track.

5. **Volume Up / Next Track:** Short press for volume up, long press for next track.
6. **RGB Light Button:** Control RGB lighting effects.
7. **TWS Button:** Activate True Wireless Stereo pairing.
8. **Charging Port:** USB-C input for charging.
9. **USB Port:** For USB flash drive playback (up to 32GB).
10. **AUX Input:** 3.5mm audio jack for wired connection.

5. SETUP

5.1 Charging the Speaker

Before first use, fully charge the speaker. Connect the provided USB charging cable to the speaker's charging port and the other end to a USB power adapter (not included) or a computer's USB port.

- Charging Time: Approximately 4 hours.
- Battery Indicator: LEDs on the control panel will indicate charging status.

5.2 Powering On/Off

Press and hold the **Power Button** for 3 seconds to turn the speaker on or off.

6. OPERATING INSTRUCTIONS

6.1 Bluetooth Pairing

1. Turn on the speaker. It will automatically enter Bluetooth pairing mode, indicated by a flashing LED.
2. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
3. Select "Volkano X-Python" from the list.
4. Once paired, the LED indicator will stop flashing and remain solid. You can now play audio wirelessly.

6.2 USB Playback

Insert a USB flash drive (up to 32GB) containing MP3 audio files into the USB port. The speaker will automatically switch to USB mode and begin playing music.

6.3 FM Radio Mode

Press the **Mode Button (M)** to switch to FM Radio mode. To auto-scan and save stations, press and hold the **Play/Pause Button**. Use the **Previous/Next Track Buttons** to navigate between saved stations.

6.4 AUX Input Mode

Connect an external audio device (e.g., MP3 player, computer) to the speaker's AUX input using the provided 3.5mm audio cable. Press the **Mode Button (M)** to switch to AUX mode. Audio will be played through the wired connection.

6.5 True Wireless Stereo (TWS) Function

The TWS function allows you to pair two Volcano X-Python Series speakers together for a true stereo sound experience.

1. Ensure both speakers are turned on and not connected to any Bluetooth device.
2. On one speaker, press the **TWS Button**. It will emit a tone and begin searching for the second speaker.
3. The two speakers will automatically pair with each other. A confirmation tone will sound once connected.
4. Now, connect your Bluetooth device to one of the paired speakers (the master speaker) as described in section 6.1. Audio will play through both speakers in stereo.

6.6 RGB Lighting Control

Press the **RGB Light Button** to cycle through different lighting modes or turn the lights off.

7. MAINTENANCE

7.1 Cleaning

Wipe the speaker with a soft, dry cloth. Do not use abrasive cleaners, alcohol, or chemical solvents, as these may damage the surface.

7.2 Storage

When not in use for extended periods, store the speaker in a cool, dry place away from direct sunlight and extreme temperatures. It is recommended to charge the battery at least once every three months to maintain its lifespan.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not turn on.	Battery is depleted.	Charge the speaker fully.
No sound.	Volume is too low; device not paired; incorrect mode.	Increase volume; re-pair Bluetooth; switch to correct input mode (Bluetooth, USB, AUX, FM).
Bluetooth connection unstable.	Device is out of range; interference.	Move device closer to speaker (within 10m); avoid obstacles; turn off other Bluetooth devices.
USB playback not working.	USB drive not formatted correctly; unsupported file type; drive size too large.	Ensure USB is FAT32 formatted; use MP3 files; ensure drive is 32GB or less.
TWS pairing fails.	Speakers are already connected to another device; too far apart.	Disconnect speakers from any Bluetooth devices; ensure they are close to each other.

9. SPECIFICATIONS

- **Brand:** Volkano
- **Model:** X-Python Series
- **Connectivity Technology:** Wired, Wireless (Bluetooth V5.0)
- **Audio Output Mode:** Stereo
- **Maximum Speaker Output Power:** 17 Watts
- **RMS Power Output:** 14 Watts (7W x 2)
- **Drivers:** Two 4 Ohm 3-inch drivers
- **Frequency Response:** 100Hz - 20kHz
- **Sensitivity:** 86dB ± 3dB
- **Bluetooth Range:** Up to 10 meters
- **Battery:** 3.7V, 3600mAh
- **Playtime:** 3.5 - 6.5 hours (depending on volume and usage)
- **Charging Time:** Up to 4 hours
- **USB Compatibility:** Up to 32GB flash drive
- **Water Resistance Rating:** IPX6
- **Color:** Black
- **Compatible Devices:** Android, iPhone
- **Mounting Type:** Tabletop
- **Special Feature:** Portable, RGB Lighting, TWS Function, FM Radio, AUX Input, Voice Assistant Compatibility
- **Shipping Dimensions:** 28.6 x 14.8 x 14 cm
- **Weight:** 2.04 kg

10. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the warranty card included with your product or contact Volkano customer service through their official website. Please retain your proof of purchase for any warranty claims.

© 2024 Volkano. All rights reserved.

Model: X-Python Series | ASIN: B0CKLPZ11J