

[Manuals.plus](#) /

› [Bed Bath & Beyond](#) /

› Instruction Manual for Bed Bath & Beyond Outdoor 3-Piece Cushioned Rattan Patio Furniture Conversation Set

Bed Bath & Beyond B0CKLS8BBS

Bed Bath & Beyond Outdoor 3-Piece Cushioned Rattan Patio Furniture Conversation Set

Model: B0CKLS8BBS

INTRODUCTION

Thank you for choosing the Bed Bath & Beyond Outdoor 3-Piece Cushioned Rattan Patio Furniture Conversation Set. This set is designed to provide a comfortable and stylish seating solution for your outdoor living space. It includes two club chairs with plush cushions and a side table with a tempered glass top, constructed with a rust-resistant steel frame and durable PE rattan wicker.

This manual contains important information regarding the assembly, safe use, and maintenance of your new furniture. Please read it thoroughly before assembly and retain it for future reference.

IMPORTANT SAFETY INFORMATION

- Always assemble the furniture on a soft, non-abrasive surface to prevent damage.
- Ensure all bolts and screws are securely tightened before use. Periodically check and re-tighten fasteners.
- Do not exceed the weight capacity: Chairs 360 pounds (163 kg) each, Table 70 pounds (31.7 kg).
- Keep children away from the assembly area. Small parts can be a choking hazard.
- Do not stand or jump on the furniture.
- Avoid placing hot items directly on the tempered glass tabletop without a protective coaster.
- In adverse weather conditions (strong winds, heavy rain), consider covering or storing the furniture to prolong its lifespan.

PACKAGE CONTENTS

Please verify that all parts are present before beginning assembly. If any parts are missing or damaged, do not proceed with assembly and contact customer support.

- 2 x Patio Club Chairs (Rattan frame)
- 1 x Side Table (Rattan frame with tempered glass top)

- 2 x Seat Cushions (Polyester, high-density sponge fill)
- 2 x Back Cushions (Polyester, high-density sponge fill)
- Assembly Hardware Kit (bolts, washers, Allen wrench)

SETUP AND ASSEMBLY

Tools Required

- Included Allen Wrench
- Optional: Phillips Head Screwdriver (not typically needed, but useful for some fasteners)

Step-by-Step Assembly

Follow these steps carefully to assemble your patio furniture. It is recommended to have two people for easier assembly.

1. Unpack all components and lay them out on a clean, soft surface to prevent scratches. Identify all parts against the package contents list.
2. Begin with the club chairs. Attach the backrest to the seat frame using the provided bolts and washers. Do not fully tighten bolts yet.
3. Attach the armrests to the seat and backrest frames. Ensure all holes align.
4. Once all chair components are loosely assembled, gently rock the chair to ensure it sits level, then fully tighten all bolts using the Allen wrench.
5. Repeat steps 2-4 for the second club chair.
6. Assemble the side table. Attach the legs to the tabletop frame. Ensure stability before tightening.
7. Carefully place the tempered glass top into the designated area on the side table frame.
8. Place the seat and back cushions onto the assembled chairs. The cushion covers are removable and washable.


◀ *Size*



Image: Detailed dimensions of the patio chair and side table, illustrating the size and proportions of each component for assembly reference.

Details about Wicker Sofa


Curved &
Ergonomic Backrest



Raised Feet
Protect Bottom
Rattan



Wide &
Comfortable Armrest



Anti-rust & Premium Screws




Image: Close-up view highlighting key construction details of the wicker sofa, such as the curved and ergonomic backrest, raised feet to protect the rattan, wide and comfortable armrests, and anti-rust premium screws, providing insight into the quality and design.

OPERATING AND USAGE GUIDELINES

This patio furniture set is designed for outdoor use, providing a comfortable area for relaxation and conversation. To ensure optimal performance and longevity, please observe the following guidelines:

- Place the furniture on a flat, stable surface to prevent wobbling or tipping.
- Distribute weight evenly on chairs and the table.
- Avoid dragging the furniture, as this can damage the legs or frame. Lift and move it instead.
- The cushions are designed for comfort and are suitable for outdoor conditions, but prolonged exposure to heavy rain or direct sunlight may affect their lifespan. Consider storing them indoors or using a cover when not in use.



Image: The complete 3-piece patio conversation set, showcasing the two club chairs with beige cushions and the matching side table, ready for use in an outdoor setting.



Image: The patio conversation set arranged in an indoor setting, illustrating its potential use in sunrooms or covered patios, with

CARE AND MAINTENANCE

Cleaning

- **Rattan Frame:** Wipe clean with a damp cloth and mild soap. Rinse thoroughly and dry completely to prevent water spots or mildew. Avoid harsh chemicals or abrasive cleaners.
- **Cushions:** The polyester cushion covers are removable and washable. Machine wash cold with mild detergent on a gentle cycle. Air dry only; do not tumble dry. For spot cleaning, use a mild soap solution and a soft brush.
- **Tempered Glass Top:** Clean with a glass cleaner and a soft, lint-free cloth. Avoid abrasive materials that could scratch the surface.

Storage

- During off-season or extended periods of non-use, store the furniture in a cool, dry place to protect it from extreme weather conditions.
- If storing outdoors, use a breathable, waterproof furniture cover to protect against moisture, dust, and UV rays.
- Ensure cushions are completely dry before storing to prevent mold or mildew growth.

TROUBLESHOOTING

If you encounter any issues with your patio furniture, please refer to the following common problems and solutions:

Problem	Solution
Furniture wobbles after assembly.	Loosen all bolts slightly, gently rock the furniture on a flat surface to allow it to settle, then re-tighten all bolts evenly. Ensure it is placed on a level surface.
Cushions appear flattened or misshapen.	Fluff cushions regularly. High-density sponge may compress over time but should regain some shape. Ensure proper storage when not in use.
Rattan appears faded or brittle.	This can be due to prolonged exposure to direct sunlight. Use a furniture cover when not in use to protect against UV damage. Regular cleaning can also help maintain its appearance.
Water spots on glass tabletop.	Clean with a glass cleaner and a microfiber cloth. For stubborn spots, a mixture of vinegar and water can be effective. Dry immediately.

PRODUCT SPECIFICATIONS

Feature	Detail
Set Includes	2 Patio Club Chairs, 1 Side Table
Frame Material	Rust-resistant Steel

Feature	Detail
Wicker Material	PE Rattan
Cushion Material	Polyester fabric with high-density sponge fill
Tabletop Material	Tempered Glass
Chair Dimensions (W x D x H)	26.5 inches x 26.5 inches x 30 inches
Table Dimensions (W x D x H)	19.5 inches x 19.5 inches x 19.5 inches
Armrest Height	23 inches
Seat Height	14 inches
Chair Weight Capacity	360 pounds (163 kg)
Table Weight Capacity	70 pounds (31.7 kg)
Assembly Required	Yes

WARRANTY AND SUPPORT

Bed Bath & Beyond stands behind the quality of its products. While specific warranty details may vary, this product is typically covered by a limited manufacturer's warranty against defects in materials and workmanship under normal use.

For warranty claims, missing parts, or any other product-related inquiries, please contact Bed Bath & Beyond customer support. Have your purchase receipt and model number (B0CKLS8BBS) ready when contacting support.

For the most up-to-date contact information, please visit the official Bed Bath & Beyond website or refer to your purchase documentation.