

**Lenco DAR-017**

# **Lenco DAR-017WH DAB+ FM Bluetooth Radio User Manual**

Model: DAR-017WH

## **1. INTRODUCTION**

Thank you for purchasing the Lenco DAR-017WH DAB+ FM Bluetooth Radio. This manual provides essential information for the safe and efficient operation of your device. Please read it thoroughly before use and retain it for future reference.

The Lenco DAR-017WH is a compact digital radio featuring DAB+ and FM reception, Bluetooth 5.0 connectivity, dual alarm functions, and a stylish wooden casing. It offers versatile audio entertainment and serves as a practical alarm clock.

## **2. IMPORTANT SAFETY INSTRUCTIONS**

- Do not expose this appliance to dripping or splashing water. Do not place objects filled with liquids, such as vases, on the appliance.
- Ensure adequate ventilation. Do not block any ventilation openings.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Only use attachments/accessories specified by the manufacturer.
- Unplug this appliance during lightning storms or when unused for long periods.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
- The battery compartment should be securely closed during operation.

## **3. PACKAGE CONTENTS**

Please check that all items are present and in good condition:

- Lenco DAR-017WH DAB+ FM Bluetooth Radio
- AC Power Adapter
- User Manual (this document)

*Note: 4 x AA batteries are required for portable use and are not included in the package.*

## 4. PRODUCT OVERVIEW

### 4.1 Front Panel



Image: Front view of the Lenco DAR-017WH radio, showing the speaker grille on the left, the 2.4-inch TFT LCD display on the right, and various control buttons and a rotary knob below the display. The casing is light wood.

- 1. Display:** 2.4" TFT LCD screen for information display.
- 2. Power Button:** Turns the unit on or off.
- 3. Mode Button:** Switches between DAB+, FM, Bluetooth, and AUX modes.
- 4. Alarm Button:** Accesses alarm settings.
- 5. Sleep Button:** Sets the sleep timer.
- 6. Menu Button:** Accesses system settings and mode-specific options.
- 7. OK / Play/Pause Button:** Confirms selections or plays/pauses in Bluetooth mode.
- 8. Preset Button:** Stores or recalls preset radio stations.

9. **Rotary Knob (Volume / Select):** Adjusts volume or navigates menus. Press to select.
10. **Previous/Next Station/Track Buttons:** Navigates radio stations or Bluetooth tracks.

## 4.2 Rear Panel




Image: Rear view of the Lenco DAR-017WH radio, showing the telescopic antenna, DC 9V IN port, AUX IN port, headphone output, a USB port labeled 'UPGRADE', an ON/OFF switch, and the battery compartment.

11. **Telescopic Antenna:** For DAB+ and FM radio reception.
12. **DC 9V IN:** Power input for the AC adapter.
13. **AUX IN:** 3.5mm input for external audio devices.
14. **Headphone Output:** 3.5mm output for private listening.
15. **UPGRADE Port:** USB port for firmware updates (for service use only).
16. **ON/OFF Switch:** Main power switch.
17. **Battery Compartment:** Holds 4 x AA batteries for portable use.

## 5. SETUP

### 5.1 Power Connection

The Lenco DAR-017WH can be powered by the included AC adapter or by batteries.

- **AC Power:** Connect the AC adapter to the DC 9V IN port on the rear of the radio and plug the

adapter into a wall outlet.

- **Battery Power:** Open the battery compartment on the rear. Insert 4 x AA batteries (not included), ensuring correct polarity (+/-). Close the compartment securely.

*Note: When using batteries, ensure the main ON/OFF switch on the rear is in the 'ON' position.*

## 5.2 Antenna Adjustment

Extend the telescopic antenna fully for optimal DAB+ and FM radio reception. Adjust its position for the best signal quality.

## 5.3 Initial Power On

After connecting power, ensure the main ON/OFF switch on the rear is set to 'ON'. Press the **Power** button on the front panel to turn on the radio. The display will light up.

# 6. OPERATING INSTRUCTIONS

---

## 6.1 Mode Selection

Press the **Mode** button repeatedly to cycle through available modes: DAB+, FM, Bluetooth, and AUX.

## 6.2 DAB+ Radio Operation

1. Switch to DAB+ mode using the **Mode** button.
2. Upon first use, the radio will automatically perform a full scan for available DAB+ stations. This may take a few minutes.
3. Once the scan is complete, use the **Previous/Next Station** buttons or rotate the **Rotary Knob** to browse the list of stations. Press the **OK** button to select a station.
4. **Storing Presets:** To save a station, press and hold the **Preset** button. Use the **Rotary Knob** to select a preset number (1-10), then press **OK** to confirm.
5. **Recalling Presets:** Briefly press the **Preset** button. Use the **Rotary Knob** to select the desired preset, then press **OK**.

## 6.3 FM Radio Operation

1. Switch to FM mode using the **Mode** button.
2. **Auto Scan:** Press and hold the **OK** button to automatically scan for and store available FM stations.
3. **Manual Tuning:** Briefly press the **Previous/Next Station** buttons to fine-tune the frequency.
4. **Storing Presets:** To save a station, press and hold the **Preset** button. Use the **Rotary Knob** to select a preset number (1-10), then press **OK** to confirm.
5. **Recalling Presets:** Briefly press the **Preset** button. Use the **Rotary Knob** to select the desired preset, then press **OK**.

## 6.4 Bluetooth Pairing

1. Switch to Bluetooth mode using the **Mode** button. The display will show "Bluetooth Pairing" or similar, and an indicator will flash.
2. On your Bluetooth-enabled device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
3. Select "Lenco DAR-017WH" from the list.
4. Once paired, the radio will indicate a successful connection, and you can stream audio from your

device.

5. Use the **OK / Play/Pause** button and **Previous/Next Track** buttons on the radio to control playback.

## 6.5 Alarm and Snooze Function

The DAR-017WH features a dual alarm function.

1. Press the **Alarm** button to enter alarm settings.
2. Use the **Rotary Knob** to select Alarm 1 or Alarm 2, then press **OK**.
3. Follow the on-screen prompts to set the alarm time, source (DAB+, FM, or Buzzer), and volume. Press **OK** to confirm each setting.
4. When an alarm sounds, press the **Sleep** button to activate the snooze function. The alarm will sound again after a set interval.
5. To turn off an alarm, press the **Power** button.

## 6.6 Auxiliary Input (AUX IN)

Connect an external audio device (e.g., MP3 player) to the AUX IN port on the rear of the radio using a 3.5mm audio cable (not included). Switch to AUX mode using the **Mode** button. Audio from the connected device will play through the radio's speaker.

## 7. MAINTENANCE

- **Cleaning:** Wipe the radio with a soft, dry cloth. Do not use abrasive cleaners, waxes, or solvents.
- **Battery Replacement:** If using batteries, replace all four AA batteries when the low battery indicator appears on the display or when performance degrades. Ensure correct polarity.
- **Storage:** If storing the radio for an extended period, remove the batteries to prevent leakage.

## 8. TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	AC adapter not connected; Main power switch off; Batteries depleted or incorrectly inserted.	Check AC adapter connection; Ensure main ON/OFF switch is 'ON'; Replace batteries or check polarity.
Poor radio reception (DAB+/FM)	Antenna not extended; Weak signal; Interference.	Fully extend and adjust the telescopic antenna; Try moving the radio to a different location; Perform a full scan for stations.
Bluetooth not connecting	Radio not in Bluetooth mode; Device not in pairing mode; Already paired with another device.	Ensure radio is in Bluetooth mode; Put your device in pairing mode; Disconnect from other Bluetooth devices.
No sound from AUX IN	Radio not in AUX mode; Cable not connected properly; Volume too low on radio or external device.	Switch to AUX mode; Check 3.5mm cable connection; Increase volume on both radio and external device.

## 9. SPECIFICATIONS

- **Model:** DAR-017WH
- **Display:** 2.4" TFT LCD (6.1 cm)
- **Radio Bands:** DAB+, PLL-FM
- **Presets:** 10 FM, 10 DAB+
- **Bluetooth Version:** 5.0
- **Output Power:** 3W RMS
- **Connections:** 3.5mm AUX IN, 3.5mm Headphone Output, DC 9V IN
- **Power Source:** AC adapter (included), 4 x AA batteries (not included)
- **Dimensions (H x W x D):** Approximately 10.5 x 17 x 9.5 cm
- **Weight:** Approximately 0.64 kg
- **Special Features:** Dual alarm, snooze function, wooden casing, portable design.

## 10. WARRANTY AND SUPPORT

This product comes with a **1-year warranty** from the date of purchase, covering manufacturing defects.

Please retain your proof of purchase for warranty claims.

For technical support, service, or warranty inquiries, please contact your retailer or the official Lenco customer service. Contact information can typically be found on the Lenco website or in the product packaging.

### Related Documents - DAR-017

 <p><b>Lenco</b> Model : DAR-081/DAR-281</p> <p>User manual - DAB / FM radio with CD player, USB and Bluetooth Gebruiksaanwijzing - DAB / FM radio met CD-speler, USB en Bluetooth Bedienungsanleitung - DAB / FM Radio mit CD-Player, USB und Bluetooth Manuel d'utilisation - Radio DAB / FM avec lecteur CD, USB et Bluetooth Manual de uso - radio DAB / FM con reproductor de CD, USB y Bluetooth Brugervejledning - DAB / FM radio med CD-spiller, USB og Bluetooth Användarhandbok - DAB / FM radio med CD-spelare, USB och Bluetooth</p> <p>1</p>	<p><a href="#">Lenco DAR-081/DAR-281 User Manual: DAB+/FM Radio with CD, USB &amp; Bluetooth</a></p> <p>This user manual provides comprehensive guidance for the Lenco DAR-081 and DAR-281 DAB+/FM radio. Learn about setup, operation, features including CD playback, USB, and Bluetooth connectivity, along with safety precautions and technical specifications.</p>
 <p><b>Lenco</b> Model : DAR-051/DAR-251</p> <p>User manual - DAB / FM radio with CD player, USB and Bluetooth Gebruiksaanwijzing - DAB / FM radio met CD-speler, USB en Bluetooth Bedienungsanleitung - DAB / FM Radio mit CD-Player, USB und Bluetooth Manuel d'utilisation - Radio DAB / FM avec lecteur CD, USB et Bluetooth Manual de uso - radio DAB / FM con reproductor de CD, USB y Bluetooth Brugervejledning - DAB / FM radio med CD-spiller, USB og Bluetooth Användarhandbok - DAB / FM radio med CD-spelare, USB och Bluetooth</p> <p>1</p>	<p><a href="#">Lenco DAR-051/DAR-251 DAB+/FM Radio with CD, USB, Bluetooth User Manual</a></p> <p>Comprehensive user manual for the Lenco DAR-051/DAR-251 audio system, detailing its DAB+/FM radio, CD player, USB, and Bluetooth functionalities. Includes setup, operation, and troubleshooting guidance.</p>

 <p><b>Lenco</b> Model : DAR-081/DAR-281</p> <p>User manual - DAB+/FM radio with CD player, USB and Bluetooth Gebruiksaanwijzing - DAB+/FM radio met cd-speler, USB en Bluetooth Bedienungsanleitung - DAB+/FM-Radio mit CD-Spieler, USB und Bluetooth Mode d'emploi - Radio DAB+/FM avec lecteur CD, USB et Bluetooth Manual de instrucciones - Radio DAB+/FM con reproductor de CD, USB y Bluetooth Brugervejledning - DAB+/FM-radio med CD-spiller, USB og Bluetooth Användarhandbok - DAB+/FM-radio med CD-spelare, USB och Bluetooth Håndbog: DAB+/FM-radio med CD-spiller, USB og Bluetooth</p>	<p><a href="#">Lenco DAR-081/DAR-281 User Manual: DAB+/FM Radio with CD, USB &amp; Bluetooth</a></p> <p>User manual for the Lenco DAR-081 and DAR-281 DAB+/FM radio. This guide covers setup, operation, safety, and features including CD playback, USB, and Bluetooth connectivity.</p>
 <p><b>Lenco</b> Model : DAR-051/DAR-251</p> <p>User manual - DAB+/FM radio with CD player, USB and Bluetooth Gebruiksaanwijzing - DAB+/FM radio met cd-speler, USB en Bluetooth Bedienungsanleitung - DAB+/FM-Radio mit CD-Spieler, USB und Bluetooth Mode d'emploi - Radio DAB+/FM avec lecteur CD, USB et Bluetooth Manual de instrucciones - Radio DAB+/FM con reproductor de CD, USB y Bluetooth Brugervejledning - DAB+/FM-radio med CD-spiller, USB og Bluetooth Användarhandbok - DAB+/FM-radio med CD-spelare, USB och Bluetooth Håndbog: DAB+/FM-radio med CD-spiller, USB og Bluetooth</p>	<p><a href="#">Lenco DAR-051/DAR-251 User Manual: DAB+/FM Radio with CD, USB &amp; Bluetooth</a></p> <p>Comprehensive user manual for the Lenco DAR-051/DAR-251 DAB+/FM radio. Learn how to use its CD player, USB playback, Bluetooth connectivity, alarm functions, wireless charging, and other features.</p>
 <p><b>Lenco</b> Model : DAR-017</p> <p>USER MANUAL GEbruiksaanwijzing BEDIENUNGSANLEITUNG MODE D'EMPLOI MANUAL DE INSTRUCCIONES BRUGERVEJLEDNING ANVÄNDARHANDBOK HÅNDBØG</p>	<p><a href="#">Lenco DAR-017 DAB+/FM Radio with Bluetooth User Manual</a></p> <p>Comprehensive user manual for the Lenco DAR-017 DAB+/FM radio with Bluetooth, covering setup, operation, features, safety precautions, and technical specifications.</p>
 <p><b>Lenco</b> Model : DAR-017</p> <p>USER MANUAL GEbruiksaanwijzing BEDIENUNGSANLEITUNG MODE D'EMPLOI MANUAL DE INSTRUCCIONES BRUGERVEJLEDNING ANVÄNDARHANDBOK HÅNDBØG</p>	<p><a href="#">Lenco DAR-017 User Manual: DAB+/FM Radio with Bluetooth</a></p> <p>Comprehensive user manual for the Lenco DAR-017 DAB+/FM radio with Bluetooth. Learn about setup, operation, features, safety precautions, and technical specifications.</p>