Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Pretty Love BI-014992HP

PRETTY LOVE Baird G-Spot Vibrator User Manual

Model: BI-014992HP

Introduction

Thank you for choosing the PRETTY LOVE Baird G-Spot Vibrator. This manual provides essential information for the safe and effective use, maintenance, and troubleshooting of your device. Please read it thoroughly before first use and retain it for future reference.



Image 1: The PRETTY LOVE Baird G-Spot Vibrator, showcasing its ergonomic curved design in pink.

Important Safety Information

- **For adult use only.** Keep out of reach of children.
- **Consult a healthcare professional** if you have any medical conditions or concerns before using this product.
- **Do not use on broken or irritated skin.** Discontinue use immediately if any discomfort or irritation occurs.

- **Clean the product thoroughly** before and after each use as described in the Maintenance section.
- **Use only water-based lubricants** with this product. Oil-based lubricants can damage silicone.
- **Do not immerse the product in water for extended periods** unless specified as fully waterproof. Refer to specifications for water resistance rating.
- **Do not expose to extreme temperatures** or direct sunlight.
- **Dispose of the product responsibly** according to local regulations for electronic waste.

Package Contents

Please check the package to ensure all items are present:

- 1 x PRETTY LOVE Baird G-Spot Vibrator (Model BI-014992HP)
- 1 x USB Charging Cable
- 1 x User Manual (this document)

Setup

1. Initial Charging

1. Before first use, fully charge the device. Locate the charging port, usually indicated by a small symbol or a discreet cover.
2. Insert the small end of the provided USB charging cable into the device's charging port.
3. Connect the larger end of the USB cable to a standard USB power adapter (not included) or a computer's USB port.
4. The indicator light on the device will typically illuminate or flash during charging. Refer to the device's specific light behavior for charging status (e.g., solid light when fully charged, flashing while charging).
5. A full charge usually takes 2-3 hours. Do not overcharge the device.



Image 2: Close-up of the device, showing the location of the charging port (often a small indentation or covered area).

2. Cleaning Before First Use

Clean the device thoroughly with warm water and a mild, toy-safe soap before its initial use. Rinse well and pat dry with a lint-free cloth. See the Maintenance section for detailed cleaning instructions.

Operating Instructions

1. Basic Operation

- **Power On/Off:** Press and hold the power button (often marked with or a similar icon) for 2-3 seconds to turn the device on or off.
- **Change Vibration Modes:** Once powered on, short press the power button to cycle through the 12 available vibration settings.
- **Explore Settings:** Experiment with different patterns and intensities to find your preferred experience.



Image 3: The device showing the power button, typically located on the base or handle.

2. App Connection (if applicable)

This device supports app control for enhanced functionality. Follow these steps to connect:

1. **Download the App:** Search for the "PRETTY LOVE" app (or specified app name) on your smartphone's app store (iOS App Store or Google Play Store).
2. **Enable Bluetooth:** Ensure Bluetooth is enabled on your smartphone.
3. **Power On Device:** Turn on your PRETTY LOVE Baird vibrator.
4. **Open App:** Launch the downloaded app and follow the on-screen instructions to pair your device. The app will typically guide you through the connection process.

5. **Explore App Features:** Once connected, you can control vibration patterns, intensities, and potentially create custom modes through the app interface.

Maintenance and Care

1. Cleaning

- Always clean your device before and after each use.
- Wash the device with warm water and a mild, toy-safe soap.
- Rinse thoroughly to remove all soap residue.
- Pat dry with a clean, lint-free cloth or allow to air dry completely before storing.
- Do not use harsh chemicals, alcohol, or petroleum-based cleaners, as these can damage the silicone material.

2. Storage

- Store the device in a clean, dry, and cool place, away from direct sunlight and extreme temperatures.
- Keep it separate from other toys made of different materials to prevent material degradation.
- Ensure the device is fully charged before long-term storage to maintain battery health.

Troubleshooting

Problem	Possible Cause	Solution
Device does not turn on.	Battery is depleted.	Charge the device fully using the provided USB cable.
Device does not charge.	Faulty cable or power source; charging port obstruction.	Try a different USB port or power adapter. Ensure the charging cable is securely connected. Check the charging port for debris.
Vibrations are weak or inconsistent.	Low battery; internal malfunction.	Recharge the device. If the issue persists after charging, contact customer support.
Cannot connect to the app.	Bluetooth off; device not powered on; app issues.	Ensure Bluetooth is enabled on your phone and the device is powered on. Restart the app and try pairing again. Check app store for updates.

Specifications

- **Model:** BI-014992HP
- **Brand:** Pretty Love
- **Material:** Silicone
- **Color:** Pink
- **Vibration Settings:** 12
- **Power Source:** Rechargeable (USB)
- **Dimensions (L x W x H):** 6.89 x 3.82 x 2.17 inches
- **App Control:** Yes

- **Manufacturer:** Geila
- **First Available:** August 2, 2023

Warranty and Support

For warranty information, product support, or to report any issues, please refer to the retailer where you purchased the product or visit the official Pretty Love website. Keep your proof of purchase for warranty claims.
Legal Disclaimer: Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition. This product is not a dietary supplement.

© 2023 Pretty Love. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CKLXF7SM

More documents and user manuals: **https://manuals.plus/**