

[Manuals.plus](#) /

› [AguaStella](#) /

› AguaStella AS60W Shiny White Kitchen Sink Faucet Instruction Manual

AguaStella AS60W

AguaStella AS60W Shiny White Kitchen Sink Faucet Instruction Manual

[Overview](#)[Setup](#)[Operating](#)[Maintenance](#)[Troubleshooting](#)[Specifications](#)[Warranty](#)[Support](#)

PRODUCT OVERVIEW

The AguaStella AS60W is a modern kitchen faucet featuring a sleek shiny white finish and a convenient pull-down sprayer. Designed for single-handle operation, it offers both stream and spray functions for versatile use. Constructed with durable materials, it includes a high-quality ceramic cartridge tested for 500,000 cycles to ensure drip-free performance and longevity. The faucet also incorporates Softpex connecting hoses for hygienic drinking water delivery. Its design prioritizes ease of installation, making it suitable for DIY projects.




Figure 1: General product view of the AguaStella AS60W Shiny White Kitchen Sink Faucet.

SETUP AND INSTALLATION

The AguaStella AS60W faucet is engineered for quick and straightforward DIY installation. With pre-installed motion and connecting hoses, along with a quick-connect system, setup can typically be completed in approximately 10 minutes.

Installation Steps:

1. **Prepare the Mounting Surface:** Ensure the sink or countertop has a single hole of the appropriate size (typically 1.38 inches diameter) and is clean and dry.
2. **Insert the Faucet:** Place the faucet body into the mounting hole.
3. **Secure the Faucet:** From underneath the counter, attach the mounting hardware and tighten securely to prevent movement.
4. **Connect Water Supply Lines:** Connect the pre-installed hot and cold water supply lines to your home's water supply valves. Ensure connections are tight to prevent leaks.
5. **Connect Sprayer Hose:** Attach the pull-down sprayer hose to the quick-connect fitting. Install the hose weight onto

the pull-down hose at the recommended position to ensure smooth retraction.

6. **Test for Leaks:** Turn on the water supply and check all connections for any signs of leakage. Operate the faucet and sprayer to ensure proper function.



Figure 2: Diagram showing dimensions of the AguaStella AS60W faucet, including height (16.50 inches) and spout reach (8.70 inches), and maximum deck thickness (2-1/2 inches).

OPERATING INSTRUCTIONS

Water Flow and Temperature Control:

The AguaStella AS60W faucet features a single handle for precise control over water temperature and flow. Move the handle:

- **Up/Down:** To adjust the water flow volume.
- **Left:** For hot water.
- **Right:** For cold water.

Pull-Down Sprayer Functions:

The integrated pull-down sprayer enhances functionality and reach. It offers two distinct water modes:

- **Stream Mode:** Provides a steady, aerated flow for filling pots and general washing.
- **Spray Mode:** Delivers a powerful, wide spray for rinsing dishes and cleaning the sink.

To switch between stream and spray modes, locate the button on the sprayer head and slide it up or down. The sprayer hose extends up to 20 inches for extended reach and is designed to retract smoothly back into the spout after use.




Figure 3: The faucet demonstrating stream mode (left) and spray mode (right).

MAINTENANCE AND CARE

Proper maintenance ensures the longevity and aesthetic appeal of your AguaStella AS60W kitchen faucet.

Cleaning the Faucet:

- To maintain the shiny white finish, clean the faucet regularly with a soft cloth or sponge and mild, non-abrasive soap.
- Avoid using abrasive cleaners, harsh chemicals, ammonia-based products, or scouring pads, as these can damage the finish and void the warranty.
- Rinse thoroughly with clean water after cleaning and dry with a soft cloth to prevent water spots.

Aerator Maintenance:

- If you notice reduced water flow or an irregular spray pattern, the aerator may be clogged with mineral deposits or debris.
- Unscrew the aerator from the tip of the sprayer head.
- Rinse the aerator under running water and gently scrub away any buildup with a soft brush. Soaking in a vinegar solution can help dissolve stubborn mineral deposits.
- Reattach the aerator, ensuring it is securely tightened.

Hose and Cartridge:

- The ceramic cartridge is designed for durability. If persistent drips or leaks occur from the handle, the cartridge may need inspection or replacement.
- The Softpex inner hose is designed for hygiene. Ensure the pull-down hose moves freely and is not kinked or obstructed under the sink.



Figure 4: Components for durability and hygiene: SPX inner hose (left) and Cosedal ceramic cartridge (right).

TROUBLESHOOTING

This section addresses common issues you might encounter with your AguaStella AS60W kitchen faucet.

1. Low Water Flow:

- **Check Aerator:** The most common cause is a clogged aerator. Unscrew it from the sprayer head and clean any mineral buildup or debris.
- **Check Supply Valves:** Ensure the hot and cold water supply valves under the sink are fully open.
- **Inspect Hoses:** Check for kinks or obstructions in the supply lines or the pull-down sprayer hose.

2. Leaks from Faucet Base or Handle:

- **Tighten Connections:** Ensure all mounting nuts and supply line connections are securely tightened.
- **Inspect O-Rings/Gaskets:** Over time, O-rings or gaskets can wear out. If a leak persists, these may need to be inspected and replaced.
- **Cartridge Issue:** A faulty ceramic cartridge can cause leaks from the handle. Contact support if this is suspected.

3. Sprayer Not Retracting Properly:

- **Hose Weight Position:** Ensure the hose weight is correctly positioned on the pull-down hose, allowing it to pull the sprayer back into place.
- **Obstructions:** Check for any items under the sink that might be obstructing the hose's movement.
- **Kinked Hose:** Straighten any kinks in the pull-down hose.

4. Inconsistent Water Temperature:

- **Supply Line Connections:** Verify that the hot and cold water supply lines are correctly connected to the corresponding inlets on the faucet.
- **Water Heater Settings:** Check your water heater settings to ensure it is functioning correctly.

PRODUCT SPECIFICATIONS

Feature	Specification
Brand	AguaStella
Model Name	AS60W

Feature	Specification
Color	Shiny White
Finish Type	Shiny White
Material	Spout: Stainless Steel; Body and Handle: Zinc Alloy; Sprayer Head: Brass
Mounting Type	Deck Mount
Number of Handles	1
Hole Count	1
Special Feature	Pull Down Sprayer
Installation Type	Single Hole
Maximum Flow Rate	1.8 Gallons Per Minute
Spout Height	8.3 Inches
Spout Reach	8.75 Inches
Hose Length	29.5 Inches
Item Weight	4.21 Pounds
Product Dimensions	8.7 x 2 x 16.5 inches
Included Components	1 x AguaStella Kitchen Faucet, 1 x User Manual

WARRANTY INFORMATION

The AguaStella AS60W Shiny White Kitchen Sink Faucet is backed by a limited warranty to ensure your satisfaction and product reliability.

- **Spray Head Warranty:** The spray head component is covered for a period of **2 years** from the date of purchase.
- **Faucet Body Warranty:** The main faucet body is covered for a period of **5 years** from the date of purchase.

This warranty covers manufacturing defects and material flaws under normal use. Please retain your proof of purchase for any warranty claims. For detailed terms and conditions, or to initiate a warranty claim, please contact AguaStella customer service.

CUSTOMER SUPPORT

For any questions, technical assistance, or support regarding your AguaStella AS60W Shiny White Kitchen Sink Faucet, please utilize the following resources:

- **Online Support:** Visit the official [AguaStella Store on Amazon](#) for product information, FAQs, and contact options.
- **Contact Manufacturer:** Refer to the packaging or included documentation for direct manufacturer contact details.

Our customer service team is dedicated to providing prompt and helpful support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question