

TIETI K01R

TIETI K01R Wireless Keyboard User Manual

Model: K01R (741421623088)

1. INTRODUCTION

Thank you for choosing the TIETI K01R Wireless Keyboard. This slim and compact keyboard is designed for efficiency and comfort, featuring a numeric keypad, long battery life, and lag-free 2.4G wireless connectivity. This manual provides essential information for setting up, operating, and maintaining your new keyboard to ensure optimal performance.

Please read this manual thoroughly before using the product and retain it for future reference.

2. PACKAGE CONTENTS

Verify that all items are present in your package:

- TIETI K01R Wireless Keyboard
- USB Receiver (2.4G)
- USB Charging Cable
- User Manual (this document)



Image: Contents of the TIETI K01R Wireless Keyboard package, including the keyboard, USB receiver, and USB charging cable, alongside the product box with dimensions.

3. PRODUCT OVERVIEW

Key Features:

- **2.4G Wireless Technology:** Provides a stable and lag-free connection up to 10 meters (33 feet).
- **Responsive Scissor Switch Keys:** Offers a quiet, soft, and precise typing experience.
- **Rechargeable Battery:** Built-in 500mAh Li-ion battery provides up to 180 days of continuous use on a single charge.
- **Energy Saving Mode:** Automatically enters sleep mode after 3 minutes of inactivity to conserve power.
- **Full-Size Layout:** Includes a numeric keypad, arrow keys, and 12 multimedia shortcuts for enhanced productivity.
- **Wide Compatibility:** Compatible with Windows, Mac, PC, Laptops, Desktops, Chromebooks, and Notebooks.
- **Slim and Lightweight Design:** Ergonomic and portable for comfortable use in various environments.

Product Components:




Image: The TIETI K01R Wireless Keyboard, showcasing its full-size layout and the compact USB receiver.

- **Keyboard Layout:** Standard QWERTY layout with a dedicated numeric keypad.
- **Function Keys (F1-F12):** Provide access to multimedia controls and system functions when used with the Fn key.
- **USB Receiver:** Small dongle for wireless connection to your device.
- **Charging Port:** USB-C port for recharging the keyboard's internal battery.

4. SETUP GUIDE

4.1 Initial Charging

Before first use, it is recommended to fully charge the keyboard. Connect the provided USB charging cable to the keyboard's charging port and the other end to a USB power source (e.g., computer USB port, USB wall adapter).



LIGHTWEIGHT

Comfortable touch and lightweight body, making people love it



POWER SAVING & FAST CHARGING

Adopting low-power wireless modules and large capacity battery cells, intelligent sleep, and more energy-efficient



Image: The keyboard connected to its USB-C charging cable, illustrating the power saving and fast charging capabilities.

The charging indicator light will typically show charging status and turn off or change color when fully charged.

4.2 Connecting the Keyboard (Plug & Play)

1. Locate the USB receiver. It is usually stored in a compartment on the keyboard or included separately in the packaging.
2. Plug the USB receiver into an available USB port on your desktop, laptop, or compatible device.
3. Turn on the keyboard using the power switch (if present). The keyboard should automatically connect to the receiver within a few seconds.
4. Your operating system will typically install the necessary drivers automatically. No additional software or drivers are usually required.



EASY PLUG & PLAY

2.4G Wireless Connection

Image: The TIETI K01R Wireless Keyboard in use with a laptop, demonstrating its easy plug-and-play 2.4G wireless connection.



2.4G WIRELESS CONNECTION

2.4Ghz wireless technology supports the connection more stable, whose effective wireless range is up to 10meters (33 feet)

Image: A detailed view of the keyboard and its USB receiver, emphasizing the stable 2.4G wireless connection with a range of up to 10 meters.

5. OPERATING INSTRUCTIONS

5.1 Basic Usage

Once connected, the keyboard functions like a standard full-size keyboard. You can begin typing immediately.



Image: A close-up of the numeric keypad, demonstrating the ultra-thin profile and responsive keys.

5.2 Multimedia Shortcuts (Fn Lock and Hotkeys)

The keyboard features 12 multimedia shortcuts accessible via the Function (Fn) key. Press and hold the **Fn** key, then press the corresponding F-key to activate the shortcut.



Image: A visual guide to the multimedia function keys (hotkeys) on the keyboard, indicating their respective actions when used with the Fn key.

Multimedia Function Key Reference

Key Combination	Function
Fn + F7	Previous Track
Fn + F8	Play/Pause
Fn + F9	Next Track
Fn + F10	Mute
Fn + F11	Volume Down
Fn + F12	Volume Up
Fn + Home Icon	Open Browser
Fn + Magnifying Glass Icon	Search Application (OS dependent)
Fn + Envelope Icon	Open Email Application
Fn + Calculator Icon	Open Calculator

5.3 Power Saving Mode

To conserve battery life, the keyboard will automatically enter sleep mode after approximately 3 minutes of inactivity. To wake it up, simply press any key. The keyboard will reconnect instantly.

6. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your keyboard.

- **Cleaning:** Use a soft, dry, lint-free cloth to wipe the keyboard surface. For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution. Avoid excessive moisture. Do not spray cleaners directly onto the keyboard.
- **Battery Care:**
 - Recharge the keyboard when the battery indicator (if present) signals low power.
 - Avoid fully discharging the battery frequently.
 - If storing the keyboard for an extended period, charge it to about 50% before storage and recharge every few months to prevent deep discharge.
- **Storage:** Store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Avoid dropping the keyboard or exposing it to strong impacts. Do not attempt to disassemble the keyboard.



Image: A detailed view of the scissor switch mechanism beneath a keycap, illustrating the design that contributes to quiet and comfortable typing.

7. TROUBLESHOOTING

If you encounter issues with your TIETI K01R Wireless Keyboard, please refer to the following common solutions:

Troubleshooting Guide

Problem	Possible Cause / Solution
Keyboard not responding / No connection	<ul style="list-style-type: none"> • Ensure the keyboard is turned on. • Check if the USB receiver is securely plugged into a working USB port on your computer. Try a different USB port. • Ensure the keyboard battery is charged. Recharge if necessary. • Move the keyboard closer to the USB receiver to rule out range issues (max 10 meters). • Restart your computer.
Keys are sticky or unresponsive	<ul style="list-style-type: none"> • Clean the keyboard surface and around the keys to remove any debris. • Ensure the keyboard is fully charged.
Lag or delayed input	<ul style="list-style-type: none"> • Reduce the distance between the keyboard and the USB receiver. • Ensure there are no major obstructions or sources of strong wireless interference (e.g., Wi-Fi routers, other 2.4GHz devices) nearby. • Ensure the keyboard battery is sufficiently charged.
Keyboard frequently enters sleep mode	<ul style="list-style-type: none"> • This is a normal power-saving feature. Press any key to wake it up. • Ensure the battery is not critically low, which might cause it to enter sleep mode more aggressively.

8. SPECIFICATIONS

Feature	Detail
Model Number	K01R (741421623088)
Connectivity Technology	2.4G Wireless (USB Receiver)
Wireless Range	Up to 10 meters (33 feet)
Keyboard Type	Slim, Full-Size with Numeric Keypad
Key Switch Type	Scissor Switch
Power Source	Rechargeable 500mAh Li-ion Battery
Battery Life	Up to 180 days (continuous use on single charge)
Charging Port	USB-C
Compatible Devices	Laptop, Desktop, PC, Chromebook, Notebook
Operating Systems	Windows, Mac, and other operating systems
Color	Wireless Keyboard-Black
Item Weight	1.57 pounds (approx. 0.71 kg)
Package Dimensions	17.63 x 6.46 x 1.14 inches

9. WARRANTY INFORMATION

TIETI products are designed and manufactured to the highest quality standards. For specific warranty terms and conditions, please refer to the warranty card included with your product or contact TIETI customer support. Keep your purchase receipt as proof of purchase for warranty claims.

10. CUSTOMER SUPPORT

If you have any questions, require technical assistance, or need further support regarding your TIETI K01R Wireless Keyboard, please contact our customer service team. You can typically find contact information on the product packaging, the official TIETI website, or through your retailer.

For the most up-to-date support information, please visit the official TIETI store page on Amazon:[TIETI Store](#)