

CDCASA PE206

CDCASA Dual Motor Lay Flat Lift Chair Recliner

Model: PE206

INTRODUCTION

Thank you for choosing the CDCASA Dual Motor Lay Flat Lift Chair Recliner. This manual provides essential information for the safe and efficient operation, assembly, and maintenance of your new recliner. Please read it thoroughly before use and retain it for future reference.

SAFETY INSTRUCTIONS

Always follow basic safety precautions when operating electrical appliances to reduce the risk of burns, fire, electric shock, or injury to persons.

- Ensure all connections are secure before plugging into a power outlet.
- Keep children and pets away from the chair's moving parts.
- Do not allow more than one person to sit on the chair at a time.
- Avoid placing objects under or around the chair that could obstruct its movement.
- Unplug the chair from the power outlet before cleaning or performing any maintenance.
- Do not operate the chair if the power cord or plug is damaged.
- Do not expose the chair to water or excessive moisture.

PACKAGE CONTENTS

Your CDCASA Dual Motor Lay Flat Lift Chair Recliner package includes the following items:

- 1 x Chair (delivered in 2 boxes)
- 2 x Remote Controls

SETUP

The recliner is designed for super easy assembly, typically taking 10-15 minutes with no tools required. It arrives in two separate boxes.

1. Unpack all components from both boxes.
2. Align the backrest with the base and slide it into place until it clicks securely.
3. Connect the power cables from the backrest to the base, ensuring a snug fit.
4. Connect the remote control cable to the designated port.
5. Plug the power adapter into a wall outlet.

GREAT GIFT

Show your love and appreciation with a thoughtful gift for mom and dad



Figure 1: Visual guide for recliner assembly, illustrating the connection points.

For a visual guide on assembly and initial setup, please refer to the official product video below:

Video 1: "CDCASA Dual Motor Lift Chairs Infinite Position - How to Use?" This video demonstrates the assembly process and basic operation of the recliner.

OPERATING INSTRUCTIONS

Your CDCASA recliner is equipped with dual OKIN motors and a user-friendly remote control for various functions.

Dual Motor Operation

The dual OKIN motors allow for independent control of the backrest and footrest. Use the remote control to adjust the chair to your desired position.

- **Backrest Adjustment:** The backrest can be adjusted from 100° (upright) to 180° (fully flat).
- **Footrest Adjustment:** The footrest can be adjusted from 90° (down) to 180° (fully extended).
- **Infinite Position:** The chair offers infinite position locking, allowing it to lay completely flat like a bed, suitable for sleeping.



Figure 2: Remote control layout, illustrating buttons for independent backrest and footrest adjustments.




Figure 3: The recliner in various positions, including fully reclined (180 degrees) and lift assist for standing.

Vibration Massage & Lumbar Heating

The electric recliner features an 8-point vibration massage system and lumbar heating for enhanced relaxation.

- **Massage Points:** 8 massage points target the back, lumbar, thighs, and legs.
- **Custom Settings:** Choose from 4 custom area settings and 5 vibration modes.
- **Lumbar Heating:** Activate the lumbar heating function for warmth and comfort.
- **Timed Control:** Use the remote control to set massage and heating durations.

MASSAGE (VIBRATION) & HEATED CONTROL



-  8 Point Massage
-  Massage Remote Control
-  Lumbar Heating
-  Time Setting



Figure 4: Illustration of the 8-point massage system and the massage remote control functions.

Lift Assist Function

The lift assist function is particularly beneficial for seniors or individuals with limited mobility, providing assistance when standing up from the chair.

- Press the designated button on the remote control to gently lift the chair, tilting it forward to assist in standing.
- The chair can also be lowered smoothly back into a seated position.

PRODUCT MORE DETAILS



Upgraded Faux Leather



Sturdy Steel Frame
& Dual OKIN Motor



2 Side Pockets



Vintage Copper Rivet



Convenient Pull Rope



Figure 5: The recliner supports various activities, including napping, watching TV, reading, and provides lift assistance.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your recliner.

Cleaning

- For daily cleaning, wipe the breathable faux leather with a soft, damp cloth.
- Avoid using harsh chemicals or abrasive cleaners, as they may damage the material.
- For spills, blot immediately with a clean, dry cloth.

General Care

- Regularly check all connections and fasteners to ensure they are tight.
- Keep the chair away from direct sunlight and heat sources to prevent material degradation.
- Ensure the area around the chair is clear to allow for full range of motion.

TROUBLESHOOTING

If you encounter any issues with your recliner, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Chair does not operate	Power cord unplugged; Remote control not connected; Power outlet malfunction.	Check power cord connection; Ensure remote control cable is securely plugged in; Test power outlet with another device.
Motor makes unusual noise	Obstruction in mechanism; Loose components.	Inspect for obstructions under the chair; Check for loose screws or connections.
Massage/Heat not working	Connection issue; System overload.	Ensure all cables are properly connected; Unplug and replug the chair to reset.

If the issue persists after attempting these solutions, please contact customer service for further assistance.

SPECIFICATIONS

Feature	Detail
Brand	CDCASA
Model Name	PE206
Color	Brown
Product Dimensions (D x W x H)	37.4"D x 40.2"W x 41.7"H
Maximum Weight Recommendation	400 Pounds
Reclining Position Count	Infinite Position (100° to 180° backrest, 90° to 180° footrest)
Special Features	Dual OKIN Motors, Massage (8-point vibration), Lumbar Heating, Lift Assist, Side Pockets, Remote Control
Fill Material	High-Density 26D Foam
Upholstery Material	Breathable Faux Leather
Frame Material	Sturdy Steel Frame
Item Weight	122 pounds
Included Components	Chair, 2 Remote Controls



Dual Motor Power Lift Recliner Chair





Figure 6: Comprehensive product dimensions for planning placement and ensuring fit.

WARRANTY AND SUPPORT

CDCASA provides comprehensive support for your product:

- **Warranty:** We offer 1 year technical support for the lift motor and steel frame.
- **Customer Service:** If you experience any shipping damage upon arrival or encounter defects during usage, please do not hesitate to contact us. We are committed to providing the best after-sales service to ensure your satisfaction.

For assistance, please refer to the contact information provided with your purchase or visit the official CDCASA store online.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question