

VGR V-075

VGR V-075 Professional Shaver User Manual

Model: V-075 | Brand: VGR

1. INTRODUCTION

Thank you for choosing the VGR V-075 Professional Shaver. This manual provides essential information for the safe and effective use of your new grooming device. Please read these instructions carefully before first use and keep them for future reference.

2. SAFETY INFORMATION

- Always keep the trimmer away from water sources. Do not use it near bathtubs, showers, basins, or other vessels containing water.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Exercise caution when using the shaver near sensitive areas such as the face and eyes.
- Follow recommended cleaning and maintenance procedures to prevent skin irritation or infection.
- Always unplug the trimmer when not in use and before cleaning. Do not charge it during use.
- Keep the charging cable away from water and heat sources to prevent damage.
- Do not use the appliance if the blades are damaged or broken, as this may cause injury.

3. PACKAGE CONTENTS

Your VGR V-075 Professional Shaver package includes the following items:

- VGR V-075 Trimmer Unit
- 4 Cutting Guide Combs (3mm, 6mm, 9mm, 12mm)
- Cleaning Brush
- Oil Bottle
- Type-C USB Charging Cable
- User Manual Book

A kit, Out of the Box



Figure 3.1: All items included in the VGR V-075 shaver kit.

4. PRODUCT FEATURES

- **Corded and Cordless Operation:** Enjoy the flexibility of using the shaver with or without the cord, providing convenience for travel and home use.
- **LED Display:** The integrated LED screen clearly shows the remaining battery life and charging status, ensuring you are always aware of the power level.
- **Type-C Charging:** Equipped with a Type-C USB charging port for fast and efficient power replenishment.
- **Powerful Motor:** Features a 5000 RPM heavy-duty motor for smooth, efficient, and effortless trimming.
- **Precision Stainless Steel Blade:** High-quality stainless steel blades ensure a sharp and precise cut.
- **Adjustable Taper Lever:** Fine-tune cutting lengths from 0.8mm to 2.0mm with a handy thumb lever, without needing to change blades.
- **4 Guide Combs:** Includes 3mm, 6mm, 9mm, and 12mm guide combs for achieving various hair lengths and styles.
- **Detachable Head:** The shaver head is detachable for easy cleaning and maintenance.



Figure 4.1: Key features of the VGR V-075 shaver.

5. SETUP

1. **Unpack:** Carefully remove all components from the packaging.
2. **Inspect:** Check the shaver and accessories for any signs of damage. Do not use if damaged.
3. **Initial Charge:** Before first use, fully charge the shaver. Refer to the 'Charging' section for details.
4. **Lubricate Blades:** Apply a small drop of the included oil to the blades before the first use and after each cleaning to ensure smooth operation and longevity.

6. CHARGING

The VGR V-075 shaver is equipped with a 600mAh Lithium-Ion battery, providing up to 120 minutes of runtime on a full charge.

1. Ensure the shaver is turned OFF.
2. Connect the Type-C USB charging cable to the charging port on the shaver.
3. Plug the other end of the USB cable into a compatible USB power adapter (not included) or a USB port on a computer.

4. The LED display will indicate the charging status and battery percentage.
5. A full charge typically takes approximately 2 hours.
6. Once fully charged, disconnect the charging cable. Do not overcharge the battery.



TYPE-C
USB Charging Cable
Impressively Super Fast
Charging in Just  2 Hours

5000RPM
HEAVY DUTY MOTOR
Unleash the Beast: Turbocharged
Motor for Effortless Trims



Figure 6.1: Type-C USB charging cable connection.



Figure 6.2: Battery specifications and charging time.

7. OPERATING INSTRUCTIONS

1. **Power On/Off:** Press the ON/OFF button to turn the shaver on or off. The LED display will illuminate when the device is active.
2. **Selecting a Guide Comb:** Choose the desired guide comb (3mm, 6mm, 9mm, or 12mm) based on your preferred hair length. Align the comb with the shaver head and push it firmly until it clicks into place.
3. **Adjusting Taper Length:** For fine adjustments without a guide comb, or to blend different lengths, use the taper lever located on the side of the shaver. Move the lever up or down to select cutting lengths between 0.8mm and 2.0mm.
4. **Trimming:** Hold the shaver with the blades flat against the skin or at a slight angle, depending on the area and desired result. Move the shaver slowly against the direction of hair growth for an even cut.
5. **Corded Use:** If the battery is low or you prefer continuous power, connect the charging cable to the shaver and a power source. The shaver can be operated while charging.



4 CUTTING

Guide Combs

Provides extreme Power for Smooth, No-Snag Cutting



3mm




6mm



9mm



12mm



3 DIFFERENT LENGTHS

0.8mm - 2.0mm

A handy thumb lever allows for texture and taper adjustments without changing blades.





Figure 7.1: Guide combs and taper lever adjustment.

8. MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure optimal performance and extend the lifespan of your shaver.

1. **Turn Off and Unplug:** Always ensure the shaver is turned off and unplugged from the power source before cleaning.
2. **Remove Guide Comb:** Detach any attached guide comb.
3. **Remove Detachable Head:** Gently push the shaver head to detach it from the main body.
4. **Clean Blades:** Use the provided cleaning brush to remove loose hairs from the blades and the shaver body. For a more thorough clean, rinse the detachable head and blades under running water. Ensure the head is completely dry before reattaching.
5. **Lubricate Blades:** After cleaning and drying, apply 1-2 drops of the included oil to the blades. Turn the shaver on for a few seconds to distribute the oil evenly. This helps maintain blade sharpness and prevents rust.
6. **Reassemble:** Reattach the shaver head to the body, ensuring it clicks securely into place.
7. **Storage:** Store the shaver and its accessories in a dry, cool place, away from direct sunlight and out of reach of children.



Figure 8.1: Cleaning the detachable head under running water.

9. TROUBLESHOOTING

Problem	Possible Cause	Solution
Shaver does not turn on.	Battery is depleted.	Charge the shaver fully.
Shaver runs slowly or pulls hair.	Blades are dirty or not lubricated.	Clean and oil the blades as per maintenance instructions.
Shaver is not charging.	Charging cable or adapter is faulty; connection is loose.	Ensure the cable is securely connected. Try a different USB port or adapter.
Excessive noise during operation.	Blades are not properly lubricated or there is debris.	Clean and lubricate the blades.

10. SPECIFICATIONS

Feature	Detail
Model Number	VL-075
Product Name	Hair Trimmer
Brand	VGR
Power Source	Battery Powered (Corded & Cordless)
Battery Type	1 Lithium Ion battery (Included)
Battery Capacity	600mAh
Charging Time	Approx. 2 hours
Runtime	Approx. 120 minutes
Motor Speed	5000 RPM
Blade Material	Stainless Steel
Body Material	ABS Plastic
Cutting Lengths (Taper Lever)	0.8mm, 1.4mm, 2.0mm
Guide Comb Lengths	3mm, 6mm, 9mm, 12mm
Product Dimensions	18 x 8 x 6 cm
Item Weight	200 grams
Color	Black
Manufacturer	Ningbo VGR Electric Appliance Co.,Ltd.

11. WARRANTY AND SUPPORT

The VGR V-075 Professional Shaver comes with a **one-year warranty** from the date of purchase, covering manufacturing defects. This warranty does not cover damage caused by misuse, accident, unauthorized modification, or normal wear and tear.

For warranty claims, technical support, or any product-related inquiries, please contact the manufacturer:

Email: customercare@vgrofficial.in

Phone: 9667796740

Website: www.vgrofficial.in

Support hours are from 10:00 AM to 6:00 PM, Monday to Saturday.