

[Manuals.plus](#) /

› [SoarFlash](#) /

› SoarFlash Velvet Dining Chairs (Set of 4, Grey with Silver Plated Legs) Instruction Manual

SoarFlash W1143-JCCY

SoarFlash Velvet Dining Chairs (Set of 4, Grey with Silver Plated Legs)

Model: W1143-JCCY

Brand: SoarFlash

1. INTRODUCTION

This manual provides instructions for the assembly, use, and maintenance of your SoarFlash Velvet Dining Chairs. These chairs are designed for dining room use, featuring a tall back, modern upholstered velvet, button tufting, and silver-plated legs. Please read this manual thoroughly before assembly and use to ensure proper function and safety.



Image 1.1: Assembled SoarFlash Velvet Dining Chairs.

2. SAFETY INFORMATION

Please observe the following safety guidelines to prevent injury or damage to the product:

- **Maximum Weight Limit:** This product has a maximum weight limit of 287 lbs. Do not exceed this limit to prevent tip-over risks.
- **Assembly:** Always assemble the product according to the provided instructions to ensure stability and safety.
- **Placement:** Ensure the chair is on a stable, level surface before use.
- **Heat Sources:** Keep the product away from heat sources.
- **Heavy Objects:** Do not place heavy objects on the chair to prevent damage.
- **Small Parts:** Keep small parts and tools away from children to prevent choking hazards during assembly.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly. The package includes:

- 4 x Chair Backrests (Velvet upholstered with button tufting and ring pull)
- 4 x Chair Seats (Velvet upholstered)
- 16 x Chair Legs (Silver-plated metal)
- Assembly Screws and Washers
- Assembly Tool (Allen wrench or similar)



Image 3.1: Exploded view of chair components with dimensions.

4. ASSEMBLY INSTRUCTIONS

Assembly is estimated to take approximately 67 minutes for the set of four chairs. All necessary screws and tools are included. It is recommended to assemble on a soft, clean surface to prevent damage to the chair or floor.

1. **Unpack Components:** Carefully remove all parts from the packaging. Locate the zippered compartment under the chair seat to find the legs and hardware.
2. **Attach Back Legs:** Align the back legs with the pre-drilled holes on the underside of the chair seat.

Secure them using the provided screws and washers. Ensure they are tightened firmly but do not overtighten.

3. **Attach Front Legs:** Similarly, attach the front legs to the underside of the chair seat. Pay attention to the distinction between front and back legs as indicated in the instructions or by their design.
4. **Attach Backrest:** Connect the upholstered backrest to the seat frame. Use the remaining screws and washers to secure it in place.
5. **Verify Stability:** Once all legs and the backrest are attached, gently place the chair upright. Check for any wobbling. If necessary, adjust the height of the feet caps on the legs to ensure stability.
6. **Repeat for Remaining Chairs:** Follow the same steps for the other chairs in the set.

Assembly Video Guide:

Your browser does not support the video tag.

Video 4.1: This video demonstrates the assembly process for the dining chairs, including attaching legs and securing the backrest. It provides a visual guide to complement the written instructions.

5. OPERATING INSTRUCTIONS

The SoarFlash Velvet Dining Chairs are designed for comfortable seating at a dining table. Ensure the chair is placed on a flat, stable surface before use. The high backrest provides support, and the upholstered seat offers comfort for extended periods.

- **Seating:** Sit centrally on the seat cushion to distribute weight evenly.
- **Movement:** When moving the chair, lift it rather than dragging it to prevent damage to the legs or floor. The back ring can be used to assist in pulling the chair out from the table.

PRODUCT DETAILS

TUFTED WINGBACK WITH NAILHEAD



Noble and elegant, refined luxury

CHIC PULLING RING



The shining back pulling ring is convenient to pull the chair out

Image 5.1: Detail of the tufted backrest and decorative pulling ring.

6. MAINTENANCE AND CARE

Proper care will extend the life and appearance of your dining chairs.

- **Fabric Care:** For the velvet upholstery, spot clean with a gentle brush. Avoid rubbing vigorously, as this can damage the fabric pile. Use a clean, damp cloth with mild soap for spills, then blot dry.
- **Leg Care:** The silver-plated metal legs can be wiped clean with a soft, dry cloth. Avoid abrasive cleaners.
- **Floor Protection:** The chairs are equipped with small anti-scratch feet on the bottom of each leg to prevent damage to your flooring. Periodically check these pads for wear and replace if necessary.
- **General Maintenance:** Periodically check all screws and connections to ensure they remain tight. Retighten if any looseness is detected.

STURDY & DURABLE

Dining chair



METAL CHAIR LEGS

Bright and sturdy metal legs have a longer service life and look more elegant.



ROUND NON-SLIP PADDED

Prevent the stool from sliding and scratching the floor



Image 6.1: Detail of the metal legs and non-slip pads for floor protection.

7. TROUBLESHOOTING

If you encounter any issues with your chairs, refer to the following common solutions:

- **Wobbly Chair:**
 - Ensure all leg attachment screws are securely tightened.
 - Check if the chair is on a level surface. Adjust the feet caps on the bottom of the legs if needed to compensate for uneven flooring.
- **Loose Screws:** If any screws become loose over time, retighten them using the provided tool. Do not overtighten.
- **Fabric Stains:** Refer to the "Maintenance and Care" section for spot cleaning instructions. For stubborn stains, professional upholstery cleaning may be required.

8. SPECIFICATIONS

Feature	Detail
Brand	SoarFlash
Model Name	W1143-JCCY
Color	Grey-silver Plated Leg
Product Dimensions (L x W x H)	19.7" x 24.4" x 37.5" (As per feature bullets) / 16.92"D x 20.07"W x 36.8"H (As per specifications)
Seat Depth	17.55 inches
Maximum Weight Recommendation	287 lbs (As per safety warning) / 300 Pounds (As per specifications)
Material	Velvet upholstery, Solid wood frame, High-rebound foam fill, Metal legs
Style	Modern, Tufted Back
Item Weight (per chair)	17 pounds
UPC	774947954527

Note: Dimensions and weight limits may vary slightly between product descriptions. Please adhere to the lower weight limit for safety.

9. WARRANTY AND SUPPORT

For warranty information or technical support, please contact SoarFlash customer service. Refer to your purchase documentation for specific warranty terms and contact details. You can also visit the official SoarFlash store on Amazon for further assistance: [SoarFlash Amazon Store](#).