

[manuals.plus](#) /› [iClever](#) /› [iClever Bluetooth Keyboard User Manual](#)

## iClever BK20 Clavier Bluetooth

# iClever Bluetooth Keyboard User Manual

Model: BK20 Bluetooth Keyboard

## 1. INTRODUCTION

Thank you for choosing the iClever BK20 Bluetooth Keyboard. This manual provides detailed instructions on how to set up, operate, maintain, and troubleshoot your new keyboard. Please read this manual thoroughly before use to ensure optimal performance and longevity of your device.

## 2. PACKAGE CONTENTS

Please check the package for the following items:

- iClever BK20 Bluetooth Keyboard
- USB-C Charging Cable
- User Manual

## 3. PRODUCT OVERVIEW

The iClever BK20 Bluetooth Keyboard is a versatile and compact wireless keyboard designed for multi-device use. It features a full-size layout with a numeric keypad, scissor-switch keys for comfortable and quiet typing, and a durable construction. Its slim profile and long-lasting rechargeable battery make it ideal for various computing environments.



Full layout of the iClever BK20 Bluetooth Keyboard, showcasing its compact design with a numeric keypad.

## Multi-appareils et multi-OS

Jumeler jusqu'à 3 appareils



The keyboard's ability to connect to up to three devices simultaneously, indicated by the Bluetooth channel keys (1, 2, 3) and compatible devices like iMac, MacBook, and iPad.



## USB-C RECHARGEABLE

Conception d'un environnement convivial



**2.5** heures  
de charge



**300mAh**



**90** jours de  
fonctionnement

Close-up view of the keyboard's USB-C charging port and power switch, highlighting its 300mAh battery and long operational time.

# Construction solide et durable

Matériau ABS de qualité technique offrant une grande résistance aux chocs, rigidité et résistance à la température



Image illustrating the solid and durable construction of the keyboard, made from quality ABS material for shock, rigidity, and temperature resistance.

# 75 % Conception compacte

Le clavier compact prend moins de place,  
vous pouvez travailler n'importe où

**75%** **25%**



Visual representation of the keyboard's 75% compact design, showing how it saves desk space compared to a full-size keyboard.

# Un confort de frappe digne d'un ordinateur portable

La conception de l'interrupteur à ciseaux garantit une frappe silencieuse et confortable



Close-up of the keyboard keys, emphasizing the silent and comfortable typing experience provided by the scissor-switch mechanism.

# Mince et élégant



Diagram showing the slim and elegant dimensions of the keyboard: 366mm length, 122mm width, and 14mm height.



The iClever BK20 Bluetooth Keyboard placed in a modern workspace alongside a laptop and smartphone, demonstrating its seamless integration into a multi-device setup.

## 4. SETUP

### 4.1 Charging the Keyboard

Before first use, fully charge the keyboard. Connect the supplied USB-C cable to the keyboard's charging port and the other end to a USB power source (e.g., computer USB port, USB wall adapter). The charging indicator light will show the charging status and turn off when fully charged. A full charge takes approximately 2.5 hours and provides up to 300 hours of operation.

### 4.2 Powering On/Off

Locate the power switch on the side of the keyboard. Slide it to the "ON" position to power on the keyboard. Slide it to the "OFF" position to power off the keyboard when not in use to conserve battery.

## 4.3 Bluetooth Pairing

The iClever BK20 keyboard can connect to up to three devices simultaneously.

1. Turn on the keyboard by sliding the power switch to "ON".
2. Press and hold the **Fn** key and one of the Bluetooth channel keys (**1**, **2**, or **3**) for 3-5 seconds until the corresponding indicator light above the key starts blinking rapidly. This indicates the keyboard is in pairing mode.
3. On your device (computer, tablet, smartphone), enable Bluetooth and search for new devices.
4. Select "iClever BK20" or a similar name from the list of available devices.
5. Follow any on-screen prompts to complete the pairing process. You may be asked to type a code on the keyboard and press Enter.
6. Once successfully paired, the indicator light will stop blinking and remain solid for a few seconds before turning off.
7. Repeat these steps for other devices using different Bluetooth channel keys (2 or 3).

## 5. OPERATING INSTRUCTIONS

### 5.1 Switching Between Devices

To switch between paired devices, simply press the **Fn** key along with the corresponding Bluetooth channel key (**1**, **2**, or **3**) that your device is paired to. The keyboard will connect to the selected device within a few seconds.

### 5.2 Multimedia and Function Keys

The top row of keys (F1-F12) on the iClever BK20 keyboard serves dual purposes: standard function keys and multimedia shortcuts. By default, these keys operate as multimedia shortcuts. To use them as standard function keys (F1, F2, etc.), press the **Fn** key simultaneously with the desired F-key.

Key	Function
Fn + F1	Brightness Down
Fn + F2	Brightness Up
Fn + F3	Mission Control / Task View
Fn + F4	Launchpad / Search
Fn + F5	Keyboard Backlight Down (if applicable)
Fn + F6	Keyboard Backlight Up (if applicable)
Fn + F7	Previous Track
Fn + F8	Play/Pause
Fn + F9	Next Track

Key	Function
Fn + F10	Mute Volume
Fn + F11	Volume Down
Fn + F12	Volume Up

Note: Some function key behaviors may vary slightly depending on your operating system (macOS, Windows, iOS, Android).

### 5.3 Operating System Compatibility

The iClever BK20 keyboard is universally compatible with various operating systems. It supports:

- Apple macOS
- Apple iOS (iPad, iPhone)
- Windows 8/10/11
- Android

The keyboard features dual-labeled keys (e.g., Win/Alt and Cmd/Opt) to accommodate both Windows and macOS layouts. The keyboard automatically adapts to the connected OS, or you can manually switch layouts if needed (refer to your device's OS settings for keyboard layout adjustments).

## 6. MAINTENANCE

To ensure the longevity and optimal performance of your iClever BK20 Bluetooth Keyboard, follow these maintenance guidelines:

- **Cleaning:** Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution to wipe the keyboard surface. Avoid excessive moisture. Do not use harsh chemicals, abrasives, or solvents.
- **Dust Removal:** Use compressed air to remove dust and debris from between the keys.
- **Storage:** When not in use for extended periods, store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Spills:** Keep liquids away from the keyboard to prevent damage to internal components. In case of a spill, immediately power off the keyboard and disconnect it, then allow it to dry completely before attempting to use it again.
- **Handle with Care:** Avoid dropping the keyboard or subjecting it to strong impacts.

## 7. TROUBLESHOOTING

If you encounter issues with your iClever BK20 Bluetooth Keyboard, please refer to the following common problems and solutions:

- **Keyboard not connecting or frequently disconnecting:**

- Ensure the keyboard is charged.
- Make sure Bluetooth is enabled on your device.
- Ensure the keyboard is within the effective range (up to 15 meters).
- Try re-pairing the keyboard with your device (refer to Section 4.3).
- Remove any previous pairings of the keyboard from your device's Bluetooth settings and try pairing again.
- Restart both the keyboard and your device.

- **Keys not responding or typing incorrectly:**

- Check if the keyboard is connected to the correct device channel (1, 2, or 3).
- Ensure the keyboard is fully charged.
- Clean any debris or dust from under the keys.
- If specific keys like the spacebar feel stiff or squeaky, gentle cleaning around the keycap might help.
- Verify your operating system's keyboard layout settings match the AZERTY layout.

- **Keyboard slow to wake from sleep:**

- This can sometimes occur due to power-saving features. Press any key and wait a few seconds for the keyboard to reconnect.
- Ensure your device's Bluetooth drivers are up to date.

- **Numeric keypad point/comma issue:**

- The behavior of the numeric keypad's decimal key (point or comma) is often determined by your operating system's regional settings. Adjust your OS language and region settings to match your preference for decimal separators.

- **Short Shift key or unusual key placement:**

- The compact design may result in some key placements differing from standard full-size keyboards. This is by design and requires user adaptation.

If the problem persists after trying these solutions, please contact iClever customer support for further assistance.

## 8. SPECIFICATIONS

Feature	Description
Brand	iClever
Model Number	BK20 Clavier Bluetooth
Color	Gray
Keyboard Description	AZERTY French Bluetooth Keyboard, Scissor Switch, Compact Size
Power Source	Battery Powered (300mAh Lithium Battery)

Feature	Description
Connectivity Technology	Bluetooth
Hand Orientation	Ambidextrous
Compatible Devices	Devices with Bluetooth capabilities (PC, Laptops, MacBook, iMac, iPad, iPhone, Tablets, Smartphones)
Dimensions (L x W x H)	36 x 12 x 1.4 centimeters
Product Weight	450 Grams
Special Features	Shortcut and multimedia keys, USB-C Charging, Multi-device, Laptop-like typing experience, Multi-OS, Rechargeable
Number of Keys	101
Recommended Uses	Multimedia, Office, Home, Business, Personal, Programming


## 9. WARRANTY AND SUPPORT

iClever products come with a standard warranty. For detailed warranty information, please refer to the warranty card included in your package or visit the official iClever website. If you require technical support, have questions about your product, or need to claim warranty service, please contact iClever customer support through their official channels. Please have your product model number and purchase details ready when contacting support.

For the latest information and support, please visit: [www.iclever.com](http://www.iclever.com)

© 2025 iClever. All rights reserved.

### Related Documents - BK20 Clavier Bluetooth

	<a href="#">iClever DK05 Combo Wireless Keyboard and Mouse User Manual</a> Comprehensive user manual for the iClever DK05 Combo, detailing setup, pairing, features, and troubleshooting for this wireless keyboard and mouse set. Includes specifications, system requirements, and FCC statement.
---	--

	<p><a href="#"><b>iClever BK09 Foldable Bluetooth Keyboard User Manual</b></a></p> <p>User manual for the iClever BK09 foldable Bluetooth keyboard. Learn how to connect and use this portable, USB-C rechargeable keyboard with a number pad for up to 3 devices across iOS, Android, Windows, and macOS. Includes setup, features, and specifications.</p>
	<p><a href="#"><b>iClever IC-BK10 Wireless Keyboard User Manual</b></a></p> <p>User manual for the iClever IC-BK10 wireless keyboard, covering setup, pairing, functions, system requirements, and troubleshooting.</p>
	<p><a href="#"><b>iClever IC-GK20 2.4G Keyboard User Manual</b></a></p> <p>User manual for the iClever IC-GK20 2.4G Keyboard, providing instructions on setup, features, and troubleshooting for Windows and Mac operating systems.</p>
	<p><a href="#"><b>iClever IC-BK10 Multi-Device Wireless Keyboard User Manual</b></a></p> <p>Comprehensive user manual for the iClever IC-BK10 Multi-Device Connection Wireless Keyboard. Learn about pairing, functions, specifications, and troubleshooting for this rechargeable Bluetooth keyboard.</p>
	<p><a href="#"><b>iClever DK03 Combo US: Wireless Keyboard and Mouse User Manual</b></a></p> <p>Comprehensive user manual for the iClever DK03 Combo US wireless keyboard and mouse. Learn about setup, features, troubleshooting, and connectivity for this rechargeable dual-mode device.</p>