

Stylecraft SC608M

Stylecraft Instinct-X Professional IN2 Vector Motor Cordless Hair Clipper User Manual

Model: SC608M

1. INTRODUCTION

The Stylecraft Instinct-X Professional Cordless Hair Clipper is engineered for precision hair cutting. It features an IN2 Vector Motor with Intuitive Torque Control, designed to adjust power based on hair resistance. This clipper is equipped with a Black Diamond DLC Fade fixed blade and a Black Diamond Shallow 2.0 cutting blade, providing efficient blending, fading, and bulk removal. The device is powered by a lithium-ion battery, offering extended cordless operation.



Image 1: Stylecraft Instinct-X Cordless Hair Clipper, showcasing its sleek design.

Key Features:

- **IN2 Vector Motor:** Operates at 8,500 RPM and can increase up to 11,500 RPM with Intuitive Torque Control to adapt to hair resistance.
- **Black Diamond Carbon DLC Blades:** Fade fixed blade and shallow 2.0 cutting blade for precise cuts.
- **Lithium-Ion Battery:** Provides up to 2 hours of cordless run-time, depending on usage.
- **Adjustable Blade:** Can be zero-gapped for the closest possible cut.
- **Ergonomic Design:** Lightweight and designed for comfortable handling.
- **Modular Lids:** Includes 3 interchangeable lids for customization.
- **Magnetic Guards:** Comes with 8 Dub magnetic guards for various cutting lengths.

2. SETUP AND FIRST USE

Unboxing and Initial Inspection:

Upon opening the package, verify that all components are present. The package should include the clipper, 8 Dub magnetic guards, a charging stand/cord, a micro-USB cord, 3 levers, 3 interchangeable lids, a showcase window, a cleaning/maintenance kit, and a mini screwdriver.



Image 2: Included components with the Stylecraft Instinct-X clipper.

Initial Cleaning:

Before the first use, it is recommended to clean the blades. Use the included blade brush to remove any manufacturing debris or test hairs. Wipe away any excess oil with a dry cloth or use a professional air spray.



Image 3: Demonstrating initial blade cleaning with the provided brush.

Charging the Clipper:

Connect the charging stand to a power source using the provided cord or directly connect the micro-USB cord to the clipper. Ensure the clipper is fully charged before its first use to optimize battery life. A full charge provides up to 2 hours of cordless operation.

Unboxing Video:



Video 1: An unboxing video of the Stylecraft Instinct-X clipper, showing the contents and initial setup.


3. OPERATING INSTRUCTIONS

Powering On/Off:

Press the power button located on the front of the clipper to turn it on or off.

Adjusting the Blade:

The blade can be adjusted using the lever on the side of the clipper. Move the lever up or down to change the cutting length. For the closest cut, the blade can be zero-gapped using the included mini screwdriver for fine adjustment.



SUPER COMPACT AND LIGHTWEIGHT

with an ergonomic design for
the ultimate comfort grip

Image 4: The Stylecraft Instinct-X clipper held in hand, highlighting its ergonomic design during use.

Using Magnetic Guards:

Attach the desired magnetic guard to the clipper blade for specific cutting lengths. The set includes 8 Dub magnetic guards: #0 (1/16"), #1 (1/8"), #1.5 (3/16"), #2 (1/4"), #3 (3/8"), #4 (1/2"), #5 (5/8"), and #6 (3/4").

Changing Modular Lids:

The clipper comes with 3 interchangeable modular lids. To change a lid, carefully remove the current lid and snap the new one into place. This allows for personalization of the clipper's appearance.



Image 5: The Stylecraft Instinct-X clipper displayed with its three modular lids.

Product Overview Video:



Video 2: A detailed overview of the Stylecraft PRO Instinct X clipper, highlighting its features and capabilities.

4. MAINTENANCE

Blade Cleaning and Oiling:

Regular cleaning and oiling of the blades are essential for optimal performance and longevity. After each use, brush off any hair clippings from the blades using the provided cleaning brush. Apply a few drops of clipper oil to the blades while the clipper is running to ensure smooth operation and prevent rust.

General Care:

Store the clipper in a dry, safe place. Avoid dropping the clipper, as this can damage the motor or blades. Keep the charging contacts clean.

5. TROUBLESHOOTING

Common Issues and Solutions:

- **Clipper not turning on:** Ensure the battery is charged. Connect the clipper to the charger and allow it to charge for at least 30 minutes before attempting to power it on again.
- **Blades getting hot during use:** This can occur with prolonged use. Ensure blades are properly oiled. Take short breaks during extended cutting sessions to allow the blades to cool. If the issue persists, ensure the blades are clean and free of hair buildup.
- **Clipper operating loudly:** A loud clipper can indicate a need for lubrication. Clean and oil the blades thoroughly. Check for any loose screws on the blade assembly and tighten them if necessary.
- **Reduced cutting performance or pulling hair:** This often indicates dull blades or insufficient lubrication. Clean and oil the blades. If performance does not improve, the blades may need to be sharpened or replaced. Ensure no hair is trapped between the blades.
- **Battery not holding a charge:** Ensure the charging cable and adapter are functioning correctly. If the battery life has significantly decreased over time, it may be reaching the end of its lifespan.

6. SPECIFICATIONS

Feature	Detail
Model Number	SC608M
Motor Type	IN2 Vector Motor with Intuitive Torque Control
RPM	8,500 (idle) up to 11,500 (max)
Blade Material	Black Diamond Carbon DLC (Fade fixed blade, Shallow 2.0 cutting blade)
Battery Type	Lithium-Ion
Run Time	Up to 2 hours (cordless)
Charging Interface	USB-C, Charging Stand
Product Dimensions	2.25 x 1.75 x 6 inches
Item Weight	2.31 Pounds (1.05 Kilograms)
Included Guards	8 Dub Magnetic Guards (#0, #1, #1.5, #2, #3, #4, #5, #6)
Material Type	Plastic (body)
Color	Multi-colored (with interchangeable lids)
UPC	810069131931

7. WARRANTY INFORMATION

The Stylecraft Instinct-X Professional IN2 Vector Motor Cordless Hair Clipper is covered by a **1 Year Limited Manufacturer Warranty**. This warranty typically covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims. For specific terms and conditions, refer to the warranty documentation included with your product or contact Stylecraft customer support.

8. CUSTOMER SUPPORT

For further assistance, technical support, or warranty inquiries regarding your Stylecraft Instinct-X Professional IN2 Vector Motor Cordless Hair Clipper, please contact Stylecraft customer service. Refer to the official Stylecraft website or product packaging for the most current contact information.