

[Manuals.plus](#) /

› [YESHOMY](#) /

› YESHOMY Fireplace TV Stand with Barn Doors and Storage for TVs up to 65 inches, Distressed Grey - Instruction Manual

YESHOMY YH-TS23-215-GY

YESHOMY Fireplace TV Stand with Barn Doors

Model: YH-TS23-215-GY

1. PRODUCT OVERVIEW

The YESHOMY Fireplace TV Stand is a versatile and stylish furniture piece designed to enhance your living space. It combines a functional media console with an integrated electric fireplace, offering both entertainment support and ambient warmth. The stand features a distressed grey finish and barn-style doors, providing a modern farmhouse aesthetic.

This unit is designed to accommodate televisions up to 65 inches and includes ample storage space behind two barn doors, along with open shelving for media devices. A convenient cable management hole helps keep wires organized.



Figure 1.1: YESHOMY Fireplace TV Stand with a television and illuminated electric fireplace.

2. SAFETY INFORMATION

Please read all instructions carefully before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- **General Safety:** Keep all small parts and packaging materials away from children. This product is intended for indoor use only.
- **Assembly:** Assembly typically requires two adults. Ensure all hardware is securely tightened before use.
- **Weight Capacity:** The top surface of the TV stand has a maximum load capacity of 300 lbs (approximately 136 kg). Do not exceed this weight limit.
- **Fireplace Safety:** The electric fireplace generates heat. Do not block the air vents. Maintain a safe distance from flammable materials. Ensure the fireplace is properly installed and connected to a suitable power outlet. The fireplace unit should not be covered during operation.
- **Electrical:** Do not overload electrical outlets. If the power cord is damaged, it must be replaced by a qualified service person.

3. PACKAGE CONTENTS

The YESHOMY Fireplace TV Stand is shipped in two separate packages. Please ensure you have received both packages and all components before beginning assembly.

Expected Components:

- TV Stand Wooden Panels (Top, Bottom, Sides, Shelves, Doors)
- Electric Fireplace Insert
- Assembly Hardware (Screws, Dowels, Hinges, Handles, etc.)
- Instruction Manual

4. SETUP AND ASSEMBLY

Assembly is required for this product. While instructions are designed to be clear, having a second person assist can make the process easier and safer.

Key Assembly Features:

- **X Wood Frame Structure:** Designed for enhanced stability.
- **Adjustable Shelves:** The interior shelves can be adjusted to different heights to accommodate various items.
- **Cable Management Hole:** A pre-drilled hole at the back of the stand allows for neat organization of power cords and media cables.
- **Magnetic Door Catches:** The barn doors feature magnetic closures to keep them securely shut.



Figure 4.1: Interior storage with adjustable shelves.

PRODUCT DETAILS ANALYSIS

Four selling points, reasons for choosing us

X wood frame structure
to ensure stability

Fits TVs Up to 65 Inches



Electric Fireplace Insert
Warms Up Your
Space and Boosts Ambiance

Keep Breakables Safe
Behind the Doors

Figure 4.2: Detail of the round cable management hole.




Proection Edge



Fireplace Button



Magnet Design



Adjustable Shelf

Figure 4.3: Adjustable shelf detail.

5. OPERATING INSTRUCTIONS (ELECTRIC FIREPLACE)

The integrated electric fireplace provides realistic flame effects and supplemental heat. It can be operated via the control panel on the unit or the included full-function remote control.

Controls and Features:

- **Power Button:** Turns the fireplace on or off.
- **Temperature Control:** Adjusts the heat output.
- **Flame Brightness:** Choose from three faux flame brightness settings to suit your preference.
- **Built-in Timer:** Set the fireplace to operate for a specific duration.



Figure 5.1: Fireplace control panel.



Figure 5.2: Remote control and flame brightness options.

6. MAINTENANCE

Regular maintenance will help prolong the life and appearance of your TV stand.

- **Cleaning the Stand:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Fireplace Care:** Ensure the fireplace is unplugged and cool before cleaning. Wipe the glass and exterior surfaces with a soft, lint-free cloth. Do not spray liquids directly onto the unit.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary.

7. TROUBLESHOOTING

If you encounter issues with your YESHOMY Fireplace TV Stand, refer to the following common solutions:

- **Fireplace Not Turning On:** Ensure the power cord is securely plugged into a working electrical outlet. Check if the circuit breaker has tripped. Verify the power button on the unit or remote is pressed.

- **No Heat Output:** Confirm the temperature setting is adjusted correctly. Ensure the heat function is enabled.
- **Wobbly Stand:** Check that all assembly screws are fully tightened. Ensure the stand is placed on a flat, level surface.
- **Doors Not Closing Properly:** Inspect hinges for proper alignment and tightness. Adjust if necessary. Check for any obstructions.

For issues not resolved by these steps, please contact customer support.

8. SPECIFICATIONS

Feature	Specification
Model Number	YH-TS23-215-GY
Dimensions (L x W x H)	147.32 x 38.1 x 60.45 cm (58 x 15 x 23.8 inches)
Weight	34.93 kg (77 lbs)
Material	Wood
Color	Distressed Grey
Maximum TV Size	Up to 65 inches
Table Load Capacity	300 lbs (136 kg)
Assembly Required	Yes
UPC	774816286544

Product size



Table material



Table load
300lbs

Figure 8.1: Product dimensions and load capacity.



Figure 8.2: TV size compatibility.

9. WARRANTY AND SUPPORT

Information regarding spare parts availability is not provided. For specific warranty details or customer support, please refer to the purchase documentation or contact the retailer where the product was acquired.

For general inquiries or assistance, you may also attempt to contact YESHOMY directly through their official website or customer service channels.

© 2025 YESHOMY. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CKQP8FVG>

More documents and user manuals: <https://manuals.plus/>