

CIQILY CWD-V06

CIQILY 15W Fast Wireless Charger Phone Charging Stand User Manual

Model: CWD-V06 | Brand: CIQILY

INTRODUCTION

This manual provides detailed instructions for the safe and efficient use of your CIQILY 15W Fast Wireless Charger Phone Charging Stand. Please read this manual thoroughly before operating the device and retain it for future reference.

PACKAGE CONTENTS

Upon opening the package, please verify that all items listed below are present and in good condition:

- 1 x CIQILY 15W Wireless Charging Stand
- 1 x USB-A to USB-C Charger Braided Cable (3ft)
- 1 x User Manual (this document)



Image: The CIQILY 15W Fast Wireless Charger Phone Charging Stand, showcasing its sleek black design and dual charging pads. The stand is connected to a USB-C cable.

SETUP INSTRUCTIONS

1. **Connect the Cable:** Insert the USB-C end of the provided braided cable into the Type-C input port located at the base of the wireless charging stand.
2. **Connect to Power Source:** Connect the USB-A end of the cable to a compatible power adapter. For optimal fast charging performance, a Quick Charge (QC) 2.0 or QC 3.0 wall charger (not included) is highly recommended.
3. **Power On:** Once connected to a power source, the LED indicator on the charging stand will illuminate, signifying that the device is ready for use.

OPERATING THE WIRELESS CHARGER

Placing Your Device for Charging

To begin charging, simply place your Qi-enabled smartphone or other compatible device directly onto the charging stand. The stand supports both vertical and horizontal placement, allowing for convenient viewing while charging.

- **Optimal Placement:** Ensure your device is centered on the charging pad for stable and efficient charging. Misalignment may result in intermittent or no charging.
- **Vertical Charging:** Ideal for video calls, browsing social media, or using facial recognition.
- **Horizontal Charging:** Perfect for watching videos or playing games.



Landscape Mode

Charge horizontally to enjoy videos.



Portrait Mode

Charge vertically to follow social media or use facial recognition.

Image: A smartphone being charged on the stand in both portrait and landscape orientations, demonstrating the versatility for viewing content or making calls.

Charging Indicator

The LED indicator on the charging stand provides visual feedback:

- The LED indicator will remain brightly lit when the power source is connected.
- The light is designed to be soft and weak, ensuring it does not disturb your sleep if used in a bedroom environment.



Image: The wireless charger in various settings (home, office, car), highlighting its compact size and the soft, sleep-friendly LED indicator light.

Compatibility and Power Output

This wireless charger supports various charging modes to ensure optimal charging for a wide range of Qi-enabled devices:

- **15W Max Fast Charge Mode:** For Google Pixel 10 Pro XL/9/9 Pro/9 Pro XL/Fold/8 Pro/8a/8/7a/7/7 Pro/6/6 Pro/5/5XL/4/4XL/3/3XL, Moto Edge 2024, Moto G 2024, G Power, G Stylus 5G 2024/2023, Edge 50 Ultra, X50 Ultra, Razr 50 Ultra, LG V60/V50/V40, Sony, and other compatible devices.
- **10W Max Fast Charge Mode:** For Samsung Galaxy S24 Ultra/S24+/S23 FE/S23+/S23 Ultra/S22+/S22 Ultra/S21/S21 FE/S21+/S20/S20+/S10/S10E/S10+, Samsung Galaxy Z Fold 7/6/5/4, Z Flip 7/6/5/4, Note 20 Ultra/Note 10/Note 10+/Note 9/S9/S9+/S8/S7 S6 Edge+.
- **7.5W Max Fast Charge Mode:** For iPhone 16/15/15 Plus/15 Pro Max/14/14 Max/14 Pro/14 Pro Max/13/13 Pro/13 Pro Max/13 Mini/12/12 Pro/12 Pro Max/12 Mini/11/11 Pro/11 Pro Max/SE/XS/XS Max/XR/X/8/8 Plus.
- **5W Standard Mode:** For any other Qi-enabled devices.



15W Max
Fast Charge Mode
for Google/LG



Pixel 8 7 6 Pro 5 5xl 4xl 3xl



LG V60 V50 G8 G7



S23 Ultra
S22 Ultra
S21 Ultra
S20 Ultra



Note 20 Ultra
Note 10
Note 9
Note 8



S10
S10 Plus
S10e
S10 5G



S9/S9 Plus
S8/S8 Plus
S7

10W Max
Fast Charge Mode
for Samsung



7.5W Max
Fast Charge Mode
for iPhone



15/15 Plus
15 Pro
15 Pro Max



14 Pro Max
13 Pro Max
12 Pro Max



11/11 Pro
11 Pro Max
XS Max/XS/XR



X/8/8 Plus
with latest iOS
System



Any Qi enabled devices

5W Max
Standard Mode



Image: A comprehensive chart illustrating the various charging modes (15W, 10W, 7.5W, 5W) and the wide range of compatible smartphone models from Google, Samsung, iPhone, and other brands.

Case Friendly Charging

The charger is designed to work directly through most protective cases up to 5mm thick. This means you typically do not need to remove your phone case before charging.

Important Considerations:

- Cases made of metal will interfere with charging.
- Attachments such as magnets, credit cards, and grips on the back of the phone case will interfere with charging. Please remove these before placing your device on the charger.

Case Friendly

Please use the mobile phone shell within 5mm thickness



Magnets



Metal Cases



Grips+Stands



Credit Cards

Image: An illustration showing a smartphone charging with a case up to 5mm thick, alongside examples of items that interfere with charging, such as magnets, metal cases, grips, and credit cards.

SAFETY INFORMATION

Your CIQILY wireless charger is designed with multiple safety features to protect your device and ensure a safe charging experience. It has passed CE, FCC, and RoHS official authorizations.

- **Over-Temp Protection:** Prevents overheating.
- **Over-Voltage Protection:** Safeguards against excessive voltage.
- **Over-Charge Protection:** Protects against overcharging.
- **Over-Current Protection:** Guards against excessive current.
- **Smart IC Chip Protection:** Integrated chip for intelligent and safe power management.

Actively Protect Your Safety



Over-Temp
Protection



Over-Voltage
Protection



Over-Charge
Protection



Over-Current
Protection



Smart IC Chip
Protection



Image: A visual representation of the charger's safety features, including icons for over-temperature, over-voltage, over-charge, over-current protection, and smart IC chip protection, all under a protective shield graphic.

MAINTENANCE

- **Cleaning:** Disconnect the charger from the power source before cleaning. Use a soft, dry cloth to wipe the surface. Do not use harsh chemicals or abrasive materials.
- **Storage:** When not in use for extended periods, store the charger in a cool, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

If you encounter issues with your wireless charger, please refer to the following common problems and solutions:

- **Device Not Charging or Intermittent Charging:**
 - Ensure your phone is centered on the charging pad.
 - Verify that your phone supports Qi wireless charging.
 - Check if the power adapter is a QC 2.0/3.0 adapter and properly connected.
 - Remove any metal attachments, magnets, credit cards, or overly thick cases (over 5mm) from your phone.
 - Try restarting your phone.
- **Slow Charging:**
 - Ensure you are using a QC 2.0 or QC 3.0 wall charger. Standard 5V/1A adapters will result in slower charging.
 - Confirm your device is capable of receiving fast wireless charging.
 - Avoid using your phone excessively while it is charging.
- **LED Indicator Not On:**
 - Check if the USB-C cable is securely connected to both the charger and the power adapter.
 - Try a different power outlet or USB port.

SPECIFICATIONS

Feature	Detail
Input	5V-2A / 9V-2A / 12V-1.5A
Output	5W / 7.5W / 10W / 15W (Max)
Input Interface	Type-C
Cable Length	3 Feet (USB-A to USB-C)
Item Model Number	CWD-V06
Item Weight	0.176 ounces
Package Dimensions	4.21 x 4.02 x 2.83 inches
Color	W-Black

WARRANTY AND SUPPORT

Your CIQILY wireless charger comes with a standard warranty. For any questions, concerns, or support needs regarding your product, please do not hesitate to contact CIQILY customer service. We are committed to replying to your inquiries within 24 hours.

Please refer to your purchase platform or the CIQILY official website for specific warranty terms and contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question