Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Klwenas Maec B0CKSBC7P6

Klwenas Maec Convertible Futon Sofa Bed Instruction Manual

Model: B0CKSBC7P6

1. Setup and Assembly

The Klwenas Maec Convertible Futon Sofa Bed is designed for straightforward assembly. All necessary tools and instructions are included to facilitate a quick setup process.

Assembly Steps:

1. **Unpack Components:** Carefully remove all parts from the packaging. Verify that all components listed in the parts list are present.
2. **Attach Legs:** Securely attach the metal legs to the base of the sofa frame using the provided hardware. Ensure all screws are tightened to prevent wobbling.
3. **Position Sofa:** Place the assembled sofa in your desired location.
4. **Add Pillows:** Place the two included throw pillows on the sofa for enhanced comfort.



This image illustrates key features of the futon sofa bed, including the sturdy metal legs, the adjustable backrest mechanism, and the two comfortable throw pillows. These components are crucial for both assembly and daily use.

2. Operating Instructions

The Klwenas Maec Convertible Futon Sofa Bed offers versatile functionality, easily transforming between a sofa, lounger, and bed to suit your needs.

Adjusting the Backrest:

The backrest can be adjusted to three different angles, providing optimal comfort for various activities.

- **Sofa Position:** For standard seating, ensure the backrest is in its upright position. This is ideal for conversations or general lounging.
- **Lounger Position:** To recline, gently push the backrest forward until you hear a click, then slowly lower it to the desired reclined angle. This position is suitable for reading or watching television.
- **Bed Position:** To fully convert to a bed, push the backrest forward until it clicks past the lounger position, then lower it

completely flat. This provides a comfortable sleeping surface.



This image displays the Klwenas Maec futon sofa bed in its standard upright sofa configuration, ready for seating.



This image shows the futon sofa bed with its backrest partially reclined, demonstrating the comfortable lounger position.



This image illustrates the futon sofa bed fully flattened, showcasing its transformation into a comfortable sleeping surface.

3. Maintenance and Care

Proper care and maintenance will ensure the longevity and appearance of your Klwenas Maec Convertible Futon Sofa Bed.

Fabric Care (Linen Fabric):

- **Regular Cleaning:** Vacuum the fabric regularly using an upholstery attachment to remove dust and loose debris.
- **Spot Cleaning:** For spills, blot immediately with a clean, dry cloth. For stubborn stains, use a mild fabric cleaner specifically designed for linen, testing on an inconspicuous area first. Avoid harsh chemicals or excessive rubbing.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fading. Position the futon away from direct sunlight or use curtains/blinds.

Frame and Legs:

- **Wipe Down:** Periodically wipe the solid wood frame and metal legs with a soft, damp cloth to remove dust. Dry immediately.
- **Check Connections:** Every few months, check all screws and bolts to ensure they are tight. Re-tighten if necessary to

maintain stability.



This image highlights the premium linen fabric of the futon sofa bed, emphasizing its wear-resistant, skin-friendly, breathable, and easy-to-clean properties, crucial for maintenance.

4. Troubleshooting

If you encounter any issues with your futon sofa bed, refer to the following common troubleshooting tips.

- **Sofa Feels Unstable:**
  Solution: Check all leg attachments and frame connections. Ensure all screws are securely tightened. If the issue persists, verify that the sofa is placed on a flat, even surface.
- **Difficulty Adjusting Backrest:**
  Solution: Ensure there are no obstructions behind the backrest. Apply gentle, even pressure when pushing the backrest forward to engage the adjustment mechanism. Avoid forcing the mechanism.
- **Squeaking Noises:**
  Solution: Squeaking can sometimes occur from loose connections. Re-tighten all bolts and screws on the frame and legs. If the

noise continues, apply a small amount of silicone lubricant to moving parts of the adjustment mechanism.

5. Specifications

Detailed specifications for the Klwenas Maec Convertible Futon Sofa Bed.

Feature	Detail
Model Number	B0CKSBC7P6
Material	Linen Fabric, Solid Wood Frame, Metal Legs, Memory Foam
Weight Capacity	600 lbs
Backrest Adjustment	3 Recline Angles (Sofa, Lounger, Bed)
Included Accessories	2 Throw Pillows

Dimensions:

- **Overall Length:** Approximately 70.47 inches
- **Overall Height (Sofa):** Approximately 31.29 inches
- **Overall Depth (Sofa):** Approximately 31.88 inches
- **Seat Depth:** Approximately 19.68 inches
- **Seat Height:** Approximately 16.73 inches
- **Bed Length (Flat):** Approximately 70.47 inches
- **Bed Width (Flat):** Approximately 47.00 inches (estimated from 25.00 + 37.4 - overlap)
- **Bed Height (Flat):** Approximately 23.81 inches



This diagram provides a comprehensive overview of the Klwenas Maec futon sofa bed's dimensions in both its sofa and fully flat bed configurations, along with its 600 lbs weight capacity.

For further assistance, please contact Klwenas Maec customer support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CKSBC7P6

More documents and user manuals: **https://manuals.plus/**