Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- > Phomemo /
- > Phomemo M08F Portable Thermal Printer User Manual

Phomemo Phomemo-M08F

Phomemo M08F Portable Thermal Printer User Manual

Model: Phomemo-M08F

Brand: Phomemo

1. PRODUCT OVERVIEW

The Phomemo M08F is a versatile portable thermal printer designed for convenience and efficiency. It supports 8.5" x 11" US Letter size paper and offers inkless printing technology, making it ideal for various applications including travel, office, and home use. Its compact and lightweight design ensures easy portability.



Figure 1.1: Phomemo M08F Portable Thermal Printer in operation, demonstrating its compact size and ease of use for printing documents.

Key Features:

- Multi-functionality: Functions as both a portable document printer and a tattoo stencil printer.
- **Lightweight & Wireless:** Weighs just 2 pounds, offering superior portability compared to traditional printers. Features a built-in rechargeable battery for on-the-go use.
- Exceptional Print Quality: Delivers crisp, dark, and sharp black and white images with smooth printing effects. Compatible with 8.5"x11" transfer tattoo paper.
- **Inkless Thermal Technology:** Eliminates the need for ink, toner, or ribbons, reducing mess and maintenance.
- Powerful Phomemo App: Enables one-click printing of images and documents directly from mobile devices
- Versatile Connectivity: Supports Bluetooth connection for iOS and Android devices, and USB connection for PC/Laptop (Windows, Mac, Linux, Chrome OS).

2. PACKAGE CONTENTS

Upon unboxing your Phomemo M08F printer, please ensure all the following items are included:

• M08F-Letter portable printer



Figure 2.1: The Phomemo M08F printer and its included accessories, such as the USB cable and sample thermal paper.

3. SETUP INSTRUCTIONS

3.1 Driver Installation (for PC/Laptop)

For optimal performance and compatibility when connecting to a PC or laptop, it is essential to install the correct drivers. Ensure your printer is connected and turned on before proceeding with driver installation.

Windows Installation:

Download the driver from tattoo.phomemo.com. Follow the on-screen installation steps until completion. Ensure the printer is connected via USB and powered on during the process.

Video 3.1: Step-by-step guide on how to install the Phomemo M08F printer driver on Windows operating systems.

macOS Installation:

Download the driver from m08f.phomemo.com. Follow the installation wizard, providing necessary permissions and ensuring your printer is connected via USB and powered on.

Video 3.2: Detailed instructions for installing the Phomemo M08F printer driver on macOS, including connection and printing steps.

Video 3.3: Operational guide for using the Phomemo M08F printer with macOS, covering common printing tasks.

3.2 Loading Thermal Paper

The Phomemo M08F uses specialized thermal paper. Ensure you load the paper correctly for clear prints.

- 1. **Prepare the Paper:** Thermal paper has a non-printing side (usually with words like "This side should face up"). Place the side without words facing downwards.
- 2. **Insert into Printer:** Gently insert the paper into the printer's entry slot, ensuring it is centered. The printer will automatically pull it in, and the indicator light will turn green once paper insertion is complete.
- 3. **Protective Paper:** If your printer model contains disposable protective paper, remove it along with the arrow direction before loading thermal paper. Close the printer's cover securely; a "click" sound indicates it's closed.

Operation Before Printing Use a ruler to peel off the yellow backing paper Remove the transparent paper 3 4 Lay the paper flat in the printer Turn the printer on *

Figure 3.1: Visual guide for correctly loading thermal paper into the Phomemo M08F printer, ensuring the correct side is facing

Video 3.4: Quick start guide demonstrating the paper loading process for the Phomemo M08F printer.

4. OPERATING INSTRUCTIONS

4.1 Mobile Printing (via Phomemo App)

The Phomemo App provides a seamless printing experience from your iOS or Android device.

- 1. **Download App:** Search for "Phomemo" on the App Store (iOS) or Google Play (Android) and download the official app.
- 2. Enable Bluetooth: Ensure Bluetooth is enabled on your mobile device.
- 3. **Connect Printer:** Open the Phomemo app, click the connect button (usually in the upper right corner), and select "M08F" from the list of available printers.
- 4. **Select Document/Image:** Choose "Document print" or "Print Images" within the app. You can open various file types like Word documents, PDFs, or images.
- 5. Print: Adjust print settings (e.g., density, number of pages) as needed, then click "Print".



Figure 4.1: Visual guide for Bluetooth connection and mobile printing using the Phomemo app.

Video 4.1: Demonstrates how to connect and print using the Phomemo M08F printer with a mobile phone.

4.2 PC/Laptop Printing (via USB)

After installing the necessary drivers (refer to Section 3.1), you can print directly from your PC or laptop via USB connection.

- Connect via USB: Use the provided USB cable to connect your Phomemo M08F printer to your computer.
- 2. **Open Document/Image:** Open the file you wish to print (e.g., Word document, PDF, image) on your computer.
- 3. **Select Printer:** Go to the print option in your application (usually File > Print). Select "M08F Printer" from the list of available printers.
- 4. **Adjust Settings & Print:** Check other settings like paper type (A4 or US Letter) and orientation. Confirm print to begin printing.



Figure 4.2: Visual guide for USB connection and computer printing with the Phomemo M08F.

5. MAINTENANCE

To ensure the longevity and optimal performance of your Phomemo M08F thermal printer, follow these maintenance guidelines:

- **Use Correct Paper:** Always use Phomemo-certified thermal paper for the best print quality and to prevent damage to the print head. Regular paper is not compatible for thermal printing.
- Clean Print Head: Periodically clean the print head with a soft, lint-free cloth lightly dampened with isopropyl alcohol. Ensure the printer is off and cool before cleaning.
- Avoid Direct Sunlight/Heat: Thermal prints can fade over time, especially when exposed to direct sunlight, high temperatures, or certain chemicals. Store printed documents in a cool, dark place.
- Proper Storage: When not in use, store the printer in a dry, dust-free environment.

6. TROUBLESHOOTING

If you encounter issues with your Phomemo M08F printer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Paper Misalignment / Ragged Edges	Paper inserted too slowly or incorrectly.	Insert thermal paper swiftly and straight until it butts against the roller bar. If misaligned, open the cover and re-insert.
Noisy Printing	Printer placed on a resonant surface.	Place the printer on a stable, non-resonant surface.

Problem	Possible Cause	Solution
Prints Fading Over Time	Exposure to UV light, heat, or improper storage.	Store printed documents in a cool, dark, and dry place Thermal prints have a limited lifespan (approx. 3 years).
Printer Not Connecting (Bluetooth)	Bluetooth not enabled, app permissions, or printer not discoverable.	Ensure Bluetooth is on, grant app location/Bluetooth permissions, and restart the printer.
Printer Not Connecting (USB)	Incorrect driver installation or loose cable.	Verify driver installation (refer to Section 3.1) and ensure the USB cable is securely connected.
Poor Print Quality (Light/Spotty)	Incorrect paper type, low battery, or dirty print head.	Use genuine Phomemo thermal paper, ensure printer is charged, and clean the print head.

7. SPECIFICATIONS

BrandPhomemoModel NamePhomemo-M08FPrinting TechnologyThermalConnectivity TechnologyBluetooth, USBPrinter OutputMonochromeMax Print Speed Monochrome12 ppmMaximum Black and White Print Resolution203x203 DPIMaximum Media Size8.5 x 11 inchSheet Size8.5x11 Inches
Printing Technology Connectivity Technology Bluetooth, USB Printer Output Max Print Speed Monochrome 12 ppm Maximum Black and White Print Resolution Maximum Media Size 8.5 x 11 inch
Connectivity Technology Bluetooth, USB Printer Output Max Print Speed Monochrome 12 ppm Maximum Black and White Print Resolution 203x203 DPI Maximum Media Size 8.5 x 11 inch
Printer Output Monochrome Max Print Speed Monochrome 12 ppm Maximum Black and White Print Resolution 203x203 DPI Maximum Media Size 8.5 x 11 inch
Max Print Speed Monochrome 12 ppm Maximum Black and White Print Resolution 203x203 DPI Maximum Media Size 8.5 x 11 inch
Maximum Black and White Print Resolution 203x203 DPI Maximum Media Size 8.5 x 11 inch
Maximum Media Size 8.5 x 11 inch
Sheet Size 8.5x11 Inches
Compatible Devices Smartphones, Tablets, Laptops
Item Weight 2 Pounds (0.91 kg)
Product Dimensions 2.56"D x 13.78"W x 1.38"H (6.5 x 35 x 3.5 cm)
Battery 1 Lithium Polymer battery required (included)

Feature	Detail
Memory Storage Capacity	64 MB
Scanner Type	Portable
Max Input Sheet Capacity	100


8. WARRANTY AND SUPPORT

The Phomemo M08F Portable Thermal Printer comes with a **Limited Warranty**. For specific details regarding warranty coverage, terms, and conditions, please refer to the official warranty documentation provided with your product or contact Phomemo customer support.

For additional support, including detailed installation guides, FAQs, and contact information, please visit the official Phomemo website or refer to the comprehensive user guide PDF:

- Official User Guide (PDF): Download Here
- Phomemo Support Website: www.phomemo.com

Related Documents - Phomemo-M08F





Phomemo P831 Portable Printer User Guide

Comprehensive user guide for the Phomemo P831 portable printer, covering package contents, printer components, button functions, indicator lights, precautions, app installation, paper usage, cleaning, and warranty information.

