

NUU GARDEN DS005

NUU GARDEN Patio Dining Chairs Instruction Manual

Model: DS005

1. INTRODUCTION

Thank you for choosing NUU GARDEN Patio Dining Chairs. This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your new chairs. Please read this manual thoroughly before assembly and retain it for future reference.

These chairs are designed for outdoor use, featuring all-weather textilene fabric and a powder-coated metal frame for durability and comfort. They are ideal for enhancing your patio, lawn, garden, or backyard.

2. PACKAGE CONTENTS

Your NUU GARDEN Patio Dining Chairs set includes components for two chairs. Please verify that all parts listed below are present before beginning assembly. If any parts are missing or damaged, please contact customer service.

Part	Description	Quantity (per chair)
A	Backrest	1
B	Left Arm/Leg Frame	1
C	Right Arm/Leg Frame	1
D	Seat	1
E	M6*35 Bolts	8
F	Washers	8
	Allen Wrench	1

3. ASSEMBLY INSTRUCTIONS

Follow these steps to assemble each chair. It is recommended to assemble on a soft, clean surface to prevent scratches. Do not fully tighten bolts until all are in place.

3.1 Assembly Video Guide

For a visual guide, please refer to the official assembly video:

Official NUU GARDEN Patio Chairs Assembly Instructions video. This video demonstrates the step-by-step process for assembling one chair, including attaching the seat and backrest to the frame and tightening all bolts.

3.2 Step-by-Step Assembly

1. Step 1: Attach Seat and Backrest to One Side Frame

Place one arm/leg frame (Part B) on a flat, protected surface. Align the seat (Part D) and backrest (Part A) with the corresponding holes on the frame. Insert four M6*35 bolts (Part E) with washers (Part F) into the holes. Hand-tighten them slightly, but do not fully tighten yet. This allows for adjustment in subsequent steps.



Image showing the chair's reinforced structure and non-slip foot pads, relevant for understanding the frame

components.

2. Step 2: Attach the Second Side Frame

Carefully attach the second arm/leg frame (Part C) to the other side of the seat (Part D) and backrest (Part A). Insert the remaining four M6*35 bolts (Part E) with washers (Part F) into the holes. Again, hand-tighten them slightly.

3. Step 3: Final Tightening

Once all eight bolts are in place and loosely secured, gently place the assembled chair upright on a flat, level surface. Apply slight pressure to the chair to ensure all parts are properly aligned and the chair sits evenly.

Then, use the provided Allen wrench to fully tighten all bolts. Ensure the chair is stable and does not wobble.

NOTE: Please only tighten any bolt once all bolts are placed correctly. If the product wobbles or feels loose, double-check all bolts and nuts are properly tightened and secured.

4. Step 4: Repeat for Second Chair

Repeat Steps 1-3 for the second patio dining chair.

4. OPERATING INSTRUCTIONS

Your NUU GARDEN Patio Dining Chairs are designed for straightforward use.

- **Placement:** Always place the chairs on a stable, level surface to ensure safety and prevent tipping.
- **Weight Capacity:** Do not exceed the maximum weight recommendation of 250 pounds per chair.
- **Outdoor Use:** These chairs are specifically designed for outdoor environments such as patios, gardens, and backyards.



The chairs are suitable for various outdoor settings, providing comfortable seating.

5. MAINTENANCE AND CARE

Proper care will extend the life and appearance of your NUU GARDEN Patio Dining Chairs.

- **Cleaning:** Wipe clean with a damp cloth. For stubborn dirt, use a mild soap solution and rinse thoroughly. Avoid harsh chemicals or abrasive cleaners.
- **Fabric Care:** The textilene fabric is breathable and UV resistant. Regular cleaning helps maintain its appearance.
- **Frame Care:** The powder-coated metal frame is resistant to rust and corrosion. However, to prolong its life, avoid prolonged exposure to standing water.
- **Seasonal Storage:** During off-seasons or extreme weather conditions, it is recommended to store the chairs indoors or cover them with protective outdoor furniture covers to prevent unnecessary wear and tear.
- **Bolt Check:** Periodically check all bolts and connections to ensure they remain tight. Re-tighten if necessary to maintain stability.



The premium textilene fabric is designed to be breathable, quick-drying, and UV resistant.

6. TROUBLESHOOTING

If you encounter any issues with your chairs, please refer to the following common solutions:

- **Chair Wobbles or Feels Loose:** This is typically due to bolts not being fully tightened. Place the chair on a flat, level surface and re-tighten all assembly bolts using the Allen wrench. Ensure even pressure is applied during tightening.
- **Difficulty Assembling:** Ensure you are using the correct parts for each step as indicated in the 'Package Contents' and 'Assembly Instructions' sections. Do not fully tighten bolts until all are in place, as this allows for necessary alignment.
- **Rust Spots:** While the frame is powder-coated for rust resistance, prolonged exposure to moisture can lead to minor rust. Clean any rust spots immediately with a rust remover and apply a touch-up paint designed for outdoor metal if desired.

If problems persist, please contact NUU GARDEN customer support for assistance.

7. SPECIFICATIONS

Feature	Detail
---------	--------

Feature	Detail
Brand	NUU GARDEN
Model Name	Patio Dining Chairs (DS005)
Color	Textilene Gray
Product Dimensions	22.44"D x 20.87"W x 38.98"H
Item Weight	26 pounds (per set of 2)
Maximum Weight Recommendation	250 Pounds (per chair)
Material	Powder-Coated Metal Frame, Textilene Fabric
Special Features	All Weather Premium Textilene, Ergonomic Back and Arms, Reliable Metal Structure, Non-slip Foot Pads
Product Care Instructions	Wipe Clean
Indoor/Outdoor Usage	Outdoor

8. SAFETY INFORMATION

Please observe the following safety guidelines to ensure safe use of your chairs:

- **Weight Limit:** Do not exceed the maximum weight limit of 250 lbs per chair.
- **Proper Assembly:** Ensure proper assembly for stability. All bolts must be securely tightened.
- **Level Surface:** Always use the chairs on an even and stable surface to prevent tipping.
- **Children:** Supervise children when they are near or using the chairs. Do not allow children to climb or play on the chairs unsupervised.
- **Standing:** Do not stand on the chairs. They are designed for seating only.
- **Heat Sources:** Keep chairs away from open flames or extreme heat sources.

9. WARRANTY AND SUPPORT

While specific warranty details are not provided in this manual, NUU GARDEN is committed to customer satisfaction. If you have any questions, concerns, or require assistance with your product, please contact NUU GARDEN customer service. Please have your model number (DS005) and purchase information ready when contacting support.

For additional information or to explore other NUU GARDEN products, please visit the official NUU GARDEN store.