Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Ariete 1450

Ariete Safira 1450 Super-Automatic Espresso Machine User Manual

Model: Safira 1450

1. Introduction

Thank you for choosing the Ariete Safira 1450 Super-Automatic Espresso Machine. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read these instructions carefully before first use and keep them for future reference.

2. Important Safety Instructions

- Read all instructions before using the appliance.
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting.
- Always unplug the appliance from the power outlet before cleaning, maintenance, or if it will be left unattended for a long period.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Keep children away from the appliance, especially when it is in operation, due to hot surfaces and steam.
- Use only cold, fresh water in the water tank.
- Never open the brewing unit or bean hopper during operation.
- Exercise caution when handling hot components and steam.

3. Product Overview

The Ariete Safira 1450 is a super-automatic espresso machine designed for convenience and quality. It features an integrated grinder, a touch-sensitive LED control panel, and a steam wand for milk frothing.

Components:

- Bean Hopper with Lid

- Water Tank (removable)
- LED Touch Control Panel
- Coffee Spout (adjustable height)
- Steam Wand / Hot Water Spout
- Drip Tray with Grid
- Used Coffee Grounds Container



This image displays the Ariete Safira 1450 espresso machine from the front, showing its sleek metallic design. Hot water is being dispensed from the main spout into a clear glass cup, highlighting its hot water function.

4. Setup

4.1 Unpacking

Carefully remove the machine from its packaging. Remove all packing materials and protective films. Place the machine on a stable, level surface away from heat sources and water.

4.2 Filling the Water Tank

1. Remove the water tank from the top of the machine.
2. Fill the tank with fresh, cold water up to the 'MAX' level indicator.
3. Replace the water tank securely into its position.



A hand is shown holding the clear, removable water tank of the Ariete Safira 1450, which is being lifted from the top of the machine. The 'MAX' fill line is visible, indicating the process of refilling the water reservoir.

4.3 Filling the Bean Hopper

1. Open the lid of the bean hopper located on top of the machine.
2. Pour fresh coffee beans into the hopper. Do not overfill.
3. Close the lid securely.

4.4 Initial Rinse Cycle

After filling the water tank and bean hopper, plug in the machine. The machine will perform an initial rinse cycle to prime the system. Follow any on-screen prompts on the LED panel. Place a container under the coffee spout to collect the water.

5. Operating Instructions

5.1 Brewing Coffee

1. Ensure the water tank is filled and the bean hopper contains coffee beans.
2. Place a cup under the coffee spout.
3. Select your desired coffee type (e.g., Espresso, Long Coffee) from the LED touch panel.
4. The machine will automatically grind the beans, brew, and dispense the coffee.



A close-up view of the Ariete Safira 1450's LED touch control panel. A hand is shown pressing one of the illuminated buttons, while coffee is being dispensed into a cup below, illustrating the brewing process.

5.2 Adjusting Grind Settings

The integrated grinder allows for adjustment of the grind fineness. Refer to the grinder adjustment dial inside the bean hopper. Turn the dial to a coarser setting for a faster flow and lighter coffee, or to a finer setting for a slower flow and stronger coffee. Adjustments should only be made while the grinder is operating.

5.3 Using the Steam Wand for Milk Frothing

1. Fill a pitcher with cold milk.
2. Position the steam wand into the milk.
3. Activate the steam function on the LED touch panel.
4. Move the pitcher up and down to create foam.
5. Once desired foam is achieved, deactivate the steam function and clean the wand immediately.



The Ariete Safira 1450 espresso machine is shown with its steam wand in use, frothing milk in a stainless steel pitcher. This illustrates the machine's capability to prepare milk-based beverages.

6. Maintenance and Cleaning

Regular cleaning ensures optimal performance and longevity of your Ariete Safira 1450.

6.1 Daily Cleaning

- **Empty Drip Tray and Grounds Container:** Empty and rinse the drip tray and the used coffee grounds container daily or when prompted by the machine.



This image shows a hand carefully removing the internal used coffee grounds container from the side of the Ariete Safira 1450 machine, demonstrating a key step in routine maintenance and cleaning.

- **Clean Steam Wand:** After each use, wipe the steam wand with a damp cloth to remove any milk residue. Briefly activate the steam function to clear any internal blockages.
- **Wipe Exterior:** Wipe the exterior of the machine with a soft, damp cloth. Do not use abrasive cleaners or solvents.

6.2 Descaling

The machine will indicate when descaling is required. Use a suitable descaling solution designed for espresso machines. Follow the instructions provided with the descaling solution and the machine's on-screen prompts for the descaling process.

7. Troubleshooting

Problem	Possible Cause	Solution
No coffee dispensed	Water tank empty; coffee beans empty; brewing unit blocked.	Refill water tank; refill bean hopper; clean brewing unit.
Coffee is too weak	Grind setting too coarse; insufficient coffee dose.	Adjust grinder to a finer setting; check coffee strength settings.
Machine leaks water	Water tank not properly seated; drip tray full.	Ensure water tank is correctly inserted; empty drip tray.
Steam wand not frothing milk	Steam wand blocked; insufficient steam pressure.	Clean steam wand thoroughly; allow machine to heat up fully.

If the problem persists after attempting these solutions, please contact customer support.

8. Specifications

- **Model:** Ariete Safira 1450
- **Voltage:** 110 Volts
- **Power:** 1470 Watts
- **Pump Pressure:** 19 Bar
- **Water Tank Capacity:** 1.2 Liters
- **Bean Hopper Capacity:** 150g (approx.)
- **Dimensions (D x W x H):** 40.5 x 18.5 x 21.5 cm
- **Weight:** 9.4 kg
- **Special Features:** Automatic shutdown, Integrated grinder, LED touch panel, Steam wand
- **Inmetro Registration:** BRA23/00632

9. Warranty and Support

Your Ariete Safira 1450 Super-Automatic Espresso Machine is covered by a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions. For technical support, spare parts, or service, please contact Ariete customer service through their official website or the contact information provided in your product documentation.

© 2023 Ariete. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CKTXDL1S

More documents and user manuals: **https://manuals.plus/**