

Prolux QX60

Prolux QX60 Pet Bagged Canister Vacuum User Manual

Model: QX60 | Brand: Prolux

1. IMPORTANT SAFETY INSTRUCTIONS

Read all instructions carefully before using this appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always disconnect the vacuum cleaner from the electrical outlet before cleaning, servicing, or when not in use.
- Do not use outdoors or on wet surfaces. This appliance is designed for indoor, dry use only.
- Do not allow the vacuum cleaner to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with a damaged cord or plug. If the appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use the cord as a handle, close a door on the cord, or pull the cord around sharp edges or corners. Keep the cord away from heated surfaces.
- Do not run the appliance over the cord.
- Do not unplug by pulling on the cord. To unplug, grasp the plug, not the cord.
- Do not handle the plug or appliance with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce air flow.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Use extra care when cleaning on stairs to prevent falls or damage to the unit.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not use the appliance in an enclosed space where explosive or toxic vapors are given off.
- Do not use to pick up hard or sharp objects such as glass, nails, screws, or coins, as these can damage the vacuum.
- Do not use without the dust bag and/or filters properly in place.
- Turn off all controls before unplugging.

2. PRODUCT OVERVIEW

2.1 Components

The Prolux QX60 canister vacuum comes with the following main components:

- Canister Unit
- Crush-Proof Hose (6 feet)
- Telescopic Wand
- Wessel Werk EBK250 Power Nozzle with LED Lights
- 8-Piece Tool Attachment Kit (includes Crevice Tool, Dusting Brush, Floor Tool, Maintenance Tool, Pet Hair Brushroll, Pet Hair Turbo Nozzle)
- 5-Layer HEPA Bags




Image 2.1: Prolux QX60 Canister Vacuum Components. This image displays the main canister unit, the hose, telescopic wand, power nozzle with LED lights, HEPA bags, and various tools included in the kit.

2.2 Key Features

The Prolux QX60 is designed with features to enhance your cleaning experience:

- **Sealed HEPA Filtration System:** Traps 99.97% of dust, airborne irritants, and particles, ensuring cleaner air.
- **5-Layer HEPA Bags:** Designed to contain fine dust and allergens effectively.

- **Powerful 5-Speed Motor:** A 1440 Watt motor provides 107 CFM of deep cleaning power, with adjustable settings for various tasks.
- **Wessel Werk EBK250 Power Nozzle:** Features an LED bar for improved visibility and is specifically designed for efficient pet hair removal and deep cleaning on both carpet and hard floor surfaces. The brushroll is easily removable for cleaning.
- **Maneuverable Design:** Equipped with a 4-wheel design and a 360-degree swivel hose for easy movement around furniture and obstacles.
- **Lightweight:** Weighs 14.6 lbs, making it easy to carry, especially for stairs, with an integrated handle.
- **Extended Reach:** Offers a 35-foot cleaning radius, including the 6-foot crush-proof hose.
- **Automatic Cord Rewinder:** For convenient storage of the power cord.
- **Low Noise Level:** Operates at 67 dB on its highest speed setting.

3. SETUP

3.1 Assembling the Vacuum

1. **Attach the Hose:** Insert the hose cuff into the suction inlet on the canister unit until it clicks securely into place.
2. **Connect the Wand:** Attach the telescopic wand to the hose handle. Ensure it locks firmly.
3. **Attach the Power Nozzle:** Connect the Wessel Werk EBK250 power nozzle to the end of the telescopic wand. Press the release button on the wand to extend or retract it to your desired length.



Image 3.1: A person demonstrating the assembly and use of the Prolux QX60 vacuum cleaner, showing the connection of the hose, wand, and power nozzle.

3.2 Installing the HEPA Bag

1. Open the dust bag compartment cover on the canister unit.
2. Carefully insert a new 5-layer HEPA bag, ensuring the cardboard collar is properly seated in the bag holder.
3. Close the compartment cover until it latches securely.



**TRUE HEPA Filter & 5 Layer HEPA Bags
contains 99.97% of Dust & Allergens.**

Image 3.2: A close-up view of the Prolux QX60 canister vacuum with its lid open, showing the internal HEPA filtration system and the placement of a 5-layer HEPA bag.

4. OPERATING INSTRUCTIONS

4.1 Powering On and Adjusting Suction

1. Plug the power cord into a suitable electrical outlet.
2. Press the power button on the canister unit to turn on the vacuum.
3. Use the '+' and '-' buttons on the canister to select one of the 5 available suction levels. Lower settings are suitable for delicate surfaces like drapes, while higher settings are for deep cleaning carpets and pet hair.

5 SPEED SUCTION SELECTOR



Image 4.1: A close-up of the Prolux QX60 canister unit, highlighting the 5-speed suction selector buttons and indicator lights.

4.2 Using the Power Nozzle

The Wessel Werk EBK250 power nozzle is designed for versatile cleaning:

- **Carpets:** The rotating brushroll effectively agitates carpet fibers to lift embedded dirt and pet hair. The LED lights illuminate the cleaning path, making hidden debris visible.
- **Hard Floors:** The power nozzle can be used on hard floors. For delicate hard floors, consider using a lower suction setting or the dedicated floor tool from the attachment kit.
- **Under Furniture:** The low-profile design of the power nozzle allows it to reach under most furniture for thorough cleaning.



Image 4.2: A detailed view of the Prolux QX60 power nozzle, showcasing its LED lights illuminating the cleaning path on a carpeted surface.

4.3 Using Attachments

The included 8-piece tool kit provides specialized tools for various cleaning tasks:

- **Crevice Tool:** Ideal for cleaning tight spaces, corners, and along edges.
- **Dusting Brush:** Use for delicate surfaces like blinds, lampshades, and furniture.
- **Floor Tool:** A non-motorized tool for general cleaning of hard floors.
- **Pet Hair Turbo Nozzle:** A smaller, air-driven brush tool effective for removing pet hair from upholstery, stairs, and car interiors.

TOOLS FOR EVERY JOB

Includes premium toolkit



Image 4.3: A hand using the Prolux QX60's pet hair turbo nozzle to effectively remove pet hair from a sofa, demonstrating its specialized cleaning capability.

4.4 Video Demonstrations

Video 4.4.1: This video demonstrates the Prolux QX60's effectiveness in picking up pet hair from various surfaces, including carpets and upholstery, highlighting its powerful suction and specialized tools.

Video 4.4.2: An overview of the Prolux QX60 HEPA Canister Pet Vacuum, showcasing its features, maneuverability, and ease of use in a home environment.

5. MAINTENANCE

5.1 Replacing the HEPA Bag

For optimal performance and filtration, replace the HEPA bag when it is full or when suction power noticeably decreases.

1. Ensure the vacuum is unplugged from the power outlet.
2. Open the dust bag compartment cover.
3. Carefully remove the full HEPA bag and dispose of it.
4. Insert a new Prolux 5-layer HEPA bag, ensuring it is properly seated.

5. Close the compartment cover securely.

5.2 Cleaning Filters

Regularly check and clean or replace filters as recommended to maintain suction and air quality.

- Refer to the filter access points on your specific model for instructions on removal and cleaning.
- Some filters may be washable, while others require replacement. Follow the instructions provided with your replacement filters.

5.3 Cleaning the Power Nozzle Brushroll

Hair and debris can wrap around the brushroll, reducing effectiveness. The Wessel Werk EBK250 power nozzle features an easy-to-clean brushroll:

1. Ensure the vacuum is unplugged.
2. Locate the brushroll release mechanism on the power nozzle (often a latch or button).
3. Remove the brushroll.
4. Carefully cut away any tangled hair or debris using scissors.
5. Reinsert the clean brushroll and secure the release mechanism.

6. TROUBLESHOOTING

If you encounter issues with your Prolux QX60, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Vacuum does not turn on	No power to the unit; Power button not pressed.	Check if the power cord is securely plugged into a working outlet. Press the power button firmly.
Loss of suction	Full dust bag; Clogged filters; Blockage in hose or attachments.	Replace the HEPA bag. Check and clean/replace filters. Inspect the hose, wand, and attachments for any obstructions and remove them.
Power nozzle brushroll not rotating	Hair or debris tangled in brushroll; Improper connection; Power nozzle motor issue.	Unplug the vacuum and clean the brushroll as described in Section 5.3. Ensure the power nozzle is securely connected to the wand. If the issue persists, contact support.
Poor cleaning performance	Incorrect suction level; Worn brushroll; Full dust bag/clogged filter.	Adjust suction to a higher setting. Check brushroll for wear and replace if necessary. Replace dust bag or clean filters.
Power cord does not retract	Cord mechanism jammed.	Gently pull the cord out a short distance and then press the automatic cord retractor button. Repeat if necessary. Do not force the cord.

7. SPECIFICATIONS

Detailed technical specifications for the Prolux QX60 Canister Vacuum:

Feature	Detail
Brand	Prolux
Model Name	QX60
Filter Type	5 Layer HEPA Bags, True HEPA Filtration

Feature	Detail
Included Components	Crevice Tool, Dusting Brush, Floor Tool, Maintenance Tool, Pet Hair Brushroll, Pet Hair Turbo Nozzle
Power Source	Corded Electric
Capacity	4.5 Liters
Wattage	1440 watts
Maximum Suction	107 CFM (Cubic Feet per Minute)
Hose Length	7 Feet (Crush-proof)
Cleaning Path Width	10 Inches (Power Nozzle)
Product Dimensions	21"L x 8"W x 12"H
Noise Level	67 Decibels (on highest speed)
Amperage	12 Amps
Motor Horsepower	1.933 horsepower
Number of Speeds	5
Item Weight	15 pounds
Surface Recommendation	All floors except plush thick carpet

8. WARRANTY AND SUPPORT

8.1 Warranty Information

The Prolux QX60 Canister Vacuum comes with a Lifetime Prolux Warranty. Please refer to the warranty card included with your product for specific terms, conditions, and registration details.

8.2 Customer Support

For any questions, technical assistance, or warranty claims, please contact Prolux Customer Support. Contact details can typically be found on the product packaging, the official Prolux website, or your purchase documentation.