Bellemave bed-frames

Bellemave Metal Bunk Bed Full Over Full Size Instruction Manual

Model: bed-frames

1. Important Safety Information

Please read all instructions carefully before assembling and using this bunk bed. Keep this manual for future reference.

- **Maximum Weight Capacity:** The upper bunk is designed to support up to 250 lbs. The lower bunk is designed to support up to 350 lbs. Do not exceed these limits.
- **Age Restriction:** The upper bunk is not suitable for children under six years of age.
- **Mattress Requirements:** Use only mattresses that comply with the recommended thickness: 6 inches for the upper bunk and 8 inches for the lower bunk. Ensure the mattress surface is at least 5 inches below the upper edge of the guardrails.
- **Guardrails:** Always use the guardrails on the upper bunk. Ensure they are properly installed and secure.
- **Ladder Safety:** Always use the ladder for entering and exiting the upper bunk. Do not jump on the bed.
- **Assembly:** Ensure all connections are tight before use. Periodically check and re-tighten hardware.
- **Ventilation:** Ensure adequate ventilation around the bed.
- **Splitting Feature:** This bunk bed can be separated into two individual full-size beds. Follow the disassembly instructions carefully if converting.

2. Setup and Assembly

The Bellemave Metal Bunk Bed is designed for easy home assembly. All necessary tools and hardware are included in one package. Please ensure all parts are present and clearly labeled before beginning assembly.

2.1 Unpacking and Part Identification

Carefully unpack all components and lay them out on a clean, soft surface to prevent scratches. Refer to the included parts list to identify each component.

2.2 Assembly Steps

Follow the step-by-step instructions provided in the separate assembly guide included with your product. Ensure all bolts and screws are tightened securely, but do not overtighten until all components are aligned.



Image: Fully assembled Bellemave Metal Bunk Bed, showcasing its structure and design.

2.3 Converting to Two Full Beds

This bunk bed can be separated into two independent full-size beds. To convert, carefully follow the reverse steps of the bunk bed assembly, then reassemble the individual bed frames as instructed in the manual. This process typically involves detaching the upper bunk from the lower bunk and reattaching the necessary support legs and end frames.

3. Operating Instructions

Using your Bellemave Metal Bunk Bed is straightforward, but adherence to safety guidelines is crucial.

3.1 Using the Ladder

The bunk bed features a sturdy vertical ladder with anti-slip widen pedals for safe access to the upper bunk.

Always face the ladder when climbing up or down. Ensure a firm grip on the ladder rails.

3.2 Utilizing Under-Bed Storage

The lower bunk provides approximately 12 inches of clearance underneath, offering convenient space for storage boxes, bins, or other items. This helps in organizing the room and maximizing space, especially in smaller environments.



Image: Illustration of the 12-inch under-bed storage space, showing a basket for organization.

4. Maintenance

Proper maintenance ensures the longevity and safety of your Bellemave Metal Bunk Bed.

- **Cleaning:** The metal frame features a wear-resistant, powder-coated finish. Clean the frame with a soft, damp cloth. Avoid using abrasive cleaners or harsh chemicals, as these can damage the finish.
- **Hardware Check:** Periodically (e.g., every 3-6 months) inspect all bolts, screws, and connections to ensure they are tight. Re-tighten any loose hardware to maintain structural integrity and prevent wobbling or noise.
- **Slats Inspection:** Check the bed slats regularly for any signs of damage or bending. Damaged slats

should be replaced immediately to ensure proper mattress support.



Image: Close-up of the metal bed frame, highlighting the sturdy slats and construction.

5. Troubleshooting

If you encounter any issues with your bunk bed, refer to the following common troubleshooting tips:

- **Wobbling or Instability:** If the bed feels unstable or wobbles, check all assembly hardware. Ensure every bolt and screw is securely tightened. Uneven flooring can also contribute to wobbling; try repositioning the bed or using shims if necessary.
- **Noise (Squeaking/Creaking):** Noise often indicates loose connections. Re-tighten all hardware. Ensure that the mattress is properly seated on the slats and not causing friction against the frame.
- **Difficulty Assembling:** If you are having trouble with assembly, double-check that you are using the correct parts for each step as indicated in the assembly guide. Ensure all parts are oriented correctly. Do not force components together.
- **Missing Parts:** If any parts are missing upon unpacking, do not proceed with assembly. Contact customer support immediately for assistance.

6. Specifications

Feature	Detail
Product Type	Bunk Bed
Size	Full-Over-Full
Color	Sliver
Material	Alloy Steel
Overall Product Dimensions	78"L x 56.4"W x 65.3"H
Upper Bed Weight Capacity	250 lbs
Bottom Bed Weight Capacity	350 lbs
Recommended Upper Mattress Thickness	6 inches
Recommended Bottom Mattress Thickness	8 inches
Number of Bed Slats	21 (Upper) + 21 (Lower)
Box Spring Required	No
Assembly Required	Yes
Under-Bed Clearance	12 inches
Item Weight	94.8 lbs




Image: Detailed diagram showing all key dimensions of the bunk bed in inches.

7. Warranty Information

This Bellemave Metal Bunk Bed comes with a**one-year product warranty** from the date of purchase. This warranty covers manufacturing defects and material flaws under normal use. It does not cover damage resulting from improper assembly, misuse, accidents, or normal wear and tear. Please retain your proof of purchase for warranty claims.

8. Customer Support

If you have any questions, concerns, or require assistance with your Bellemave Metal Bunk Bed, please do not hesitate to contact our customer support team. We are committed to ensuring your satisfaction.

For support, please refer to the contact information provided with your purchase or visit the official Bellemave brand store online.

Thank you for choosing Bellemave.