

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Cabilock](#) /

› [Cabilock Christmas Advent Calendar Boxes Instruction Manual](#)

Cabilock B0CKW2LLWX

Cabilock Christmas Advent Calendar Boxes Instruction Manual

Model: B0CKW2LLWX

INTRODUCTION

This manual provides instructions for the assembly and use of your Cabilock Christmas Advent Calendar Boxes. These cardboard boxes are designed for creating a personalized 12-day Christmas countdown experience by filling them with small items.



Image: Five Cabilock Christmas Advent Calendar Boxes, ready for assembly and filling.

SETUP AND ASSEMBLY

Follow these steps to assemble your Advent Calendar Boxes. Each box is designed to hold 12 small items for a countdown.

1. **Prepare the Base Box:** Insert the splices of the main box structure to form the base. Ensure all tabs are securely interlocked.
2. **Fold the Divider Card:** Take the divider card and fold it along the dotted lines.
3. **Insert Divider into Base:** Cut the middle part of the folded divider card as indicated, then place it into the assembled base box.
4. **Create Compartments:** Fold the remaining parts of the divider card and connect them with the card already in the box to create 12 individual compartments.
5. **Close the Lid:** Once the compartments are formed and filled, close the lid and secure it by inserting its splices into the corresponding slots on the base.

For a visual guide, please refer to the assembly video below:

Video: Step-by-step assembly guide for the Cabilock Advent Calendar Boxes.



how to
put it
together ?

Please see the steps

For details,
please watch the
video

Image: Visual steps for assembling the Advent Calendar Box.

OPERATING INSTRUCTIONS

These Advent Calendar Boxes are designed for a 12-day countdown. Each box features 12 numbered compartments on its lid, corresponding to the internal dividers.

- **Filling the Boxes:** Before closing the lid, place small gifts, candies, chocolates, or toys into each of the 12 compartments.
- **Countdown Use:** Starting 12 days before Christmas, open one numbered compartment each day to reveal the surprise inside.

Christmas DIY Surprise

candy

chocolate

Various toys

Blessings greeting card



Image: Examples of small items suitable for filling the Advent Calendar Boxes.



Image: An open box showcasing filled compartments.

MAINTENANCE

The Advent Calendar Boxes are made from sturdy cardboard and paper. To ensure their longevity and reusability:

- **Storage:** Store the boxes in a dry place away from moisture and direct sunlight.
- **Cleaning:** Wipe with a dry, soft cloth if needed. Avoid using liquids or abrasive cleaners.
- **Handling:** Handle with care to prevent bending or tearing of the cardboard.

TROUBLESHOOTING

| Problem | Solution |
|---|--|
| Difficulty with assembly. | Refer to the detailed step-by-step instructions in the 'Setup and Assembly' section and watch the provided assembly video for a visual guide. Ensure all folds are crisp and tabs are aligned correctly. |
| Compartments are too small for desired items. | The boxes are designed for small, individual items. Verify the dimensions of your items against the box specifications. Consider using smaller candies, miniature toys, or folded notes. |

SPECIFICATIONS

| Feature | Detail |
|--------------------|--|
| Product Dimensions | 6.69 x 5.12 x 1.57 inches (17 x 13 x 4 cm) |
| Item Weight | 7.4 ounces |
| Material | Cardboard, Paper |
| Occasion | Christmas |
| Number of Items | 1 (Pack of 5 boxes) |



Image: Product dimensions of the Advent Calendar Box.

WARRANTY AND SUPPORT

Information regarding product warranty and customer support is not provided within this instruction manual. Please refer to the product packaging or the retailer's website for details on warranty coverage and how to contact customer support for the Cabilock Christmas Advent Calendar Boxes.

© 2025 Cabilock. All rights reserved.