Gizoon TV Stand

Gizoon TV Stand Instruction Manual

Model: TV Stand

1. Product Overview

The Gizoon TV Stand is an entertainment center designed to accommodate televisions up to 65 inches. It features open storage shelves, providing ample space for media devices, consoles, and decorative items. Constructed from engineered wood with a sturdy metal frame, this TV stand offers both durability and a modern aesthetic.



Image 1.1: The Gizoon TV Stand with a television and various items on its shelves.

Key Features:

- **Rock-Solid Construction:** Engineered with premium wood and sturdy metal frames for durability and stability.
- **Ample Storage Space:** Features wide-open sides and three versatile shelves for media devices, consoles, DVDs, and remote controls.
- **Versatile Design:** Functions as a TV stand, TV cabinet, or entertainment center, suitable for living rooms, bedrooms, or offices.
- **Easy to Clean and Maintain:** Designed for simple cleaning of dust and spills.
- **Simple Yet Chic:** Combines a sturdy black metal frame with a smooth antique wood finish for a contemporary look.

2. Safety Information

Please read and understand all safety instructions before assembly and use. Failure to follow these instructions may result in injury or product damage.

- Always follow the assembly instructions carefully to avoid injury.
- Ensure the product is properly secured to the wall to prevent tip-over, especially when heavy items are placed on it.
- Be cautious when handling the product as it may have sharp edges or surfaces.
- Always use a damp cloth to clean the product to avoid damage or injury.

3. Assembly Instructions

The Gizoon TV Stand is designed for straightforward assembly. All necessary accessories are clearly numbered, and easy-to-follow instructions are included. An adequate workspace is recommended for assembly.



Image 3.1: Assembly requirements and recommendations.

Before You Begin:

- Unpack all components and verify against the parts list provided in your package.
- Ensure you have a clean, spacious area for assembly.
- A screwdriver is included; an electric screwdriver can be used for efficiency (not included).
- Wearing gloves during assembly is recommended to prevent injury.

Follow the step-by-step pictorial directions provided in the included manual. If you encounter any questions during assembly, do not hesitate to reach out to Gizoon customer support.

4. Operating Instructions

The Gizoon TV Stand is designed for simple and functional use. Once assembled, it provides a stable platform for your television and organized storage for your media components.

Placement of Television:

- Carefully place your television on the top surface of the stand. Ensure the TV's base is centered and stable. This stand is suitable for TVs up to 65 inches.
- Distribute the weight evenly to maintain stability.

Utilizing Storage Shelves:

- The central shelves are 3-level adjustable, allowing you to customize the height to fit various media devices such as soundbars, gaming consoles (e.g., Xbox Series X, PS5), or Blu-ray players.
- The open side compartments are ideal for larger speakers, decorative items, or additional storage.
- Use the integrated cable management holes on the back panel of the central shelves to route and organize power cords and audio/video cables, keeping your setup tidy.



Image 4.1: Features including cable management, adjustable feet, and adjustable shelves.

Adjustable Feet:

- The TV stand is equipped with adjustable feet. Rotate these feet to level the stand on uneven floors, ensuring maximum stability and preventing wobbling.

Your browser does not support the video tag.

Video 4.1: A demonstration of the Gizoon TV Stand's features, including cable management and adjustable feet.

5. Maintenance

Proper care and maintenance will ensure the longevity and appearance of your Gizoon TV Stand.

Cleaning:

- Wipe the surfaces with a damp cloth.
- Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish.
- Promptly clean up any spills to prevent staining.



Image 5.1: The durable MDF boards and easy-to-clean surface of the TV stand.

General Care:

- Periodically check all screws and fasteners to ensure they are tight. Retighten if necessary.
- Avoid exposing the stand to excessive moisture or direct sunlight for prolonged periods.
- Do not place extremely hot or cold items directly on the surface without protective coasters.

6. Troubleshooting

This section addresses common issues you might encounter with your TV stand.

Wobbling or Instability:

- **Solution:** Ensure all screws and fasteners are securely tightened. Adjust the leveling feet at the bottom of the stand to compensate for uneven floor surfaces.

Missing Parts or Damaged Components:

- **Solution:** If you find any parts missing or damaged upon opening the package, please contact Gizoon customer support immediately for assistance. Do not attempt to assemble with missing or damaged parts.

Difficulty During Assembly:

- **Solution:** Review the assembly instructions carefully, paying close attention to the diagrams. Ensure you are using the correct hardware for each step. If problems persist, contact customer support.

7. Specifications

Feature	Detail
Brand	Gizoon
Model Number	TV Stand
Color	Grey
Material	Engineered Wood
Product Dimensions (L x W x H)	55 x 15 x 24 inches
Item Weight	46.3 pounds (21.05 Kilograms)
Number of Shelves	2 (plus top surface and bottom shelf)
TV Size Compatibility	Up to 65 inches
Special Feature	Durable, Open Storage, Adjustable Shelves, Cable Management, Adjustable Feet



Image 7.1: Product dimensions and weight capacities.

8. Warranty and Support

Gizoon is committed to providing high-quality products. For specific warranty information, please refer to the documentation included with your purchase or visit the official Gizoon website.

Customer Support:

If you have any questions, concerns, or require assistance with your Gizoon TV Stand, please contact our customer support team. Contact details can typically be found on the product packaging, the Gizoon website, or through your retailer's support channels.

When contacting support, please have your product model number (TV Stand) and purchase information readily available to expedite assistance.

© 2026 Gizoon. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question