JOYOUNG Y1

Joyoung Y1 Intelligent Soymilk Machine User Manual

Model: Y1-US02 | Brand: JOYOUNG

Important Safety Precautions

Please read all instructions carefully before using the Joyoung Y1 Intelligent Soymilk Machine to ensure safe and optimal operation. Keep this manual for future reference.

- **Burn Hazard:** Do not open the lid during the blending or heating process to avoid burns from hot contents or steam. After preparation, the blending cup, outlet, mixer, and mixer lid will be hot. Avoid direct contact.
- **Temperature Considerations:** When room temperature exceeds 30°C (86°F), do not set the timer for more than 12 hours to prevent spoilage.
- **Heat Sources:** Avoid placing the blending cup over an open flame or heating it on an induction cooker. This appliance is designed for its specific heating functions only.
- **Ingredient Processing:** If there are uncrushed ingredients inside the blending cup, select the speed adjustment function on the control panel to crush and release them.
- **Recipe Adherence:** Strictly follow recommended recipes and ingredient quantities to ensure proper function and prevent overflow or damage.
- **Cleaning Cycle:** Do not disconnect the power during the automatic cleaning cycle. Interrupting the cycle may affect cleaning effectiveness or machine operation.
- **Electrical Safety:** Always ensure the machine is unplugged before cleaning or performing any maintenance. Do not immerse the main unit in water.
- **Child Safety:** Keep the appliance out of reach of children. Supervise children if they are near the appliance during operation.

Product Overview

The Joyoung Y1 Intelligent Soymilk Machine is a versatile and automatic appliance designed for preparing a variety of healthy beverages and foods. It integrates blending, heating, and self-cleaning functions to simplify your kitchen tasks.



The Joyoung Y1 Intelligent Soymilk Machine in white, showcasing its compact and modern design.

Components



An exploded view illustrating the main components: Water tank, water tank lid, mixing cup lid, patented spoiler hole design blade, receiver cup, and water container.

- **Main Unit:** Houses the motor, heating element, and control panel.
- **Mixing Cup:** Where ingredients are processed. Features a patented spoiler hole design blade for efficient blending.
- **Receiver Cup:** Collects the finished beverage. Made of glass for safety and easy cleaning.
- **Water Tank:** Holds water for heating and steam generation.
- **Control Panel:** Digital touch interface for program selection and settings.
- **Lids:** Separate lids for the mixing cup and water tank to ensure secure operation.

Setup

Follow these steps to set up your Joyoung Y1 machine for first use:

1. **Unpack:** Carefully remove the machine and all its components from the packaging. Retain packaging for future storage or transport.
2. **Placement:** Place the main unit on a stable, flat, and heat-resistant surface, ensuring adequate ventilation around the appliance.
3. **Assembly:** Ensure the mixing cup is correctly seated within the main unit and the receiver cup is placed underneath the dispensing spout.
4. **Power Connection:** Plug the power cord into a standard 120V AC electrical outlet. Ensure the outlet is grounded and suitable for the appliance's power requirements.
5. **Initial Cleaning:** Before first use, it is recommended to run a self-cleaning cycle with clean water to remove any manufacturing residues.

Operating Instructions

The Joyoung Y1 offers various functions for preparing different types of beverages and foods.



The Joyoung Y1 is capable of making a variety of items including oat milk latte, hot soup, vegan cheese, and frozen fruit smoothies.

Basic Operation

1. **Add Ingredients:** Open the mixing cup lid and add your desired ingredients (e.g., soybeans, nuts, fruits, vegetables) and water into the mixing cup. Ensure ingredients do not exceed the maximum fill line.
2. **Fill Water Tank:** Fill the separate water tank with clean water up to the required level for your chosen recipe.
3. **Secure Lids:** Close both the mixing cup lid and the water tank lid securely. The machine will not operate if lids are not properly closed.
4. **Select Program:** On the digital touch control panel, select the desired program (e.g., "Soymilk", "Nut Milk", "Juice", "Soup").
5. **Start:** Press the Start button. The machine will begin the automatic blending and heating process according to the selected program.
6. **Collection:** Once the program is complete, the finished beverage will be dispensed into the receiver cup.

Advanced Features


24-Hour Advanced Scheduling

The Joyoung Y1 allows you to set a delayed start time for your convenience, up to 24 hours in advance. This feature is ideal for preparing fresh beverages to be ready at a specific time.

1. Prepare all ingredients and water as you normally would for your recipe.
2. Select your desired program on the control panel.
3. Activate the timer function and use the controls to set the desired delay time in hours.
4. Confirm the setting. The machine will display the countdown and automatically begin the selected program once the delay time has elapsed.

Speed Adjustment

If you find that ingredients are not fully crushed or blended to your desired consistency, you can utilize the speed adjustment function on the control panel to provide additional processing.



The Joyoung Y1 offers a capacity range from 0.3L to 1L, suitable for 1 to 6 people.

Cleaning and Maintenance

Proper cleaning and maintenance will extend the lifespan of your Joyoung Y1 machine and ensure hygienic operation.

Automatic Self-Cleaning

The Joyoung Y1 features a patented triple cleaning technology for comprehensive internal cleaning:



The patented self-cleaning technology includes 3D Flushing, High Temperature Sterilization, and High Speed Washing for thorough cleaning.

- **3D Flushing:** Precisely and quickly flushes every corner of the mixing cup.
- **High Temperature Sterilization:** Steam sterilization in the blender jar eliminates up to 99.99% of bacteria.
- **High Speed Washing:** High-speed stirring (up to 12,000 RPM) effectively removes food residue from the pitcher walls.

To initiate self-cleaning:

1. Ensure the mixing cup is empty of ingredients and filled with clean water up to the designated cleaning level.
2. Select the self-cleaning program on the control panel.
3. Press Start. The machine will automatically perform the cleaning cycle. Do not disconnect power during this cycle.

Manual Cleaning

For external surfaces and removable parts:

- **Main Unit:** Always unplug the machine before cleaning. Wipe the exterior of the main unit with a soft, damp cloth. Do not immerse the main unit in water or rinse it under running water.
- **Receiver Cup:** The glass receiver cup is designed for easy cleaning. It can be washed with warm soapy water or placed in a dishwasher.
- **Lids and Blades:** Wash the mixing cup lid and blades carefully with warm soapy water. Use a brush if necessary to remove any stubborn residue. Rinse thoroughly.
- **Drying:** Ensure all parts are completely dry before reassembling the machine or storing it.



The glass receiver cup is made from safe materials, resists staining, and is easy to clean.

Troubleshooting

This section provides solutions to common issues you might encounter with your Joyoung Y1 machine.

Problem	Possible Cause	Solution
Machine does not power on.	Not plugged in; power outage; faulty outlet.	Check power cord connection; verify power supply to the outlet; try a different electrical outlet.

Problem	Possible Cause	Solution
Blending process stops unexpectedly.	Lid not properly secured; overheating; E25 error code.	Ensure the mixing cup lid and water tank lid are securely closed; allow the machine to cool down for 15-20 minutes if it feels hot; if E25 error persists, contact customer support.
Ingredients not fully blended or smooth.	Too many ingredients; insufficient liquid; incorrect program selected; hard ingredients.	Reduce ingredient quantity; add more liquid as per recipe; select the appropriate program or use the speed adjustment function for additional blending.
Strong plastic smell during operation.	New machine odor; residue from previous use.	This can be normal for new appliances. Run several self-cleaning cycles with clean water. Ensure thorough cleaning after each use. If the smell persists, contact support.
Processing time is longer than expected.	Specific program characteristics; ingredient density; comparison to older models.	Processing times can vary based on the selected program and ingredients. Refer to the recipe guidelines. This model may have different processing durations compared to previous versions.

Product Specifications

- **Brand:** JOYOUNG
- **Model:** Y1
- **Color:** White
- **Capacity:** 0.3 Liters to 1 Liters (suitable for 1 to 6 people)
- **Product Dimensions:** 15.75"D x 7.25"W x 15.25"H
- **Item Weight:** 16.06 pounds
- **Power Source:** DC
- **Voltage:** 120 Volts
- **Controls Type:** Digital Touch
- **Blade Material:** Stainless Steel
- **Special Features:** Portable, Programmable, Automatic Self-Cleaning, Steam Sterilization, High-Speed Blending (up to 32,000 RPM).
- **Included Components:** Cook book, User manual (this document).

Warranty and Support

For detailed warranty information, terms, and conditions, please refer to the warranty card or documentation included with your original product packaging. You may also visit the official JOYOUNG website for the most up-to-date warranty policies.

If you require technical assistance, have questions about product operation, or need to report an issue, please contact

JOYOUNG customer support. For purchases made through Amazon, you may also reach out to the seller, CuisineTalent, via the Amazon platform for assistance.

Joyoung Y1 Intelligent Soymilk Machine User Manual | © 2024 JOYOUNG. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question