

[Manuals.plus](#) /

› [N-one](#) /

› N-one NPad Plus Android Tablet User Manual

N-one NPad Plus

N-one NPad Plus Android Tablet User Manual

MODEL: NPAD PLUS

1. Introduction

Welcome to the N-one NPad Plus Android Tablet user manual. This guide provides essential information for setting up, operating, maintaining, and troubleshooting your new device. Please read this manual thoroughly to ensure optimal performance and longevity of your tablet.

What's in the Box:

- 1 * Tablet
- 1 * User Manual
- 1 * Charge
- 1 * Type-C Cable

2. Product Overview

Design and Build

The NPad Plus features a sleek, ultra-thin 7.5mm design with a light metal body, weighing approximately 439g. It comes in a stylish Sky Grey color.



Image: The N-one NPad Plus tablet highlighting its thin profile and light weight.

Key Features

- **Display:** 10.36-inch In-cell Full Lamination IPS display with 2000x1200 HD resolution and 380 nits brightness.
- **Processor:** Octa-Core MediaTek MT8183 (2 GHz) for smooth performance.
- **Memory & Storage:** 16GB RAM (8GB physical + 8GB expandable) and 128GB UFS2.2 ROM, expandable up to 1TB via MicroSD card.
- **Cameras:** 5MP front camera and 13MP rear camera.
- **Battery:** 7500mAh lithium battery providing up to 8 hours of video playback.
- **Connectivity:** Dual-Band AC Wi-Fi (2.4GHz/5GHz), GPS, and Bluetooth 5.0.
- **Operating System:** Android 13, GMS Certified.



Image: An overview of the N-one NPad Plus tablet's main features.

Physical Components

The tablet features conveniently placed volume keys and a power button. It includes a USB-C port for charging and data transfer, a 3.5mm headphone jack, and a slot for Nano SIM and MicroSD cards. The device is equipped with dual speakers for enhanced audio experience.



Image: Various views of the N-one NPad Plus tablet's physical design.

3. Setup

Initial Charging

Before first use, fully charge your NPad Plus tablet using the provided Type-C cable and power adapter. Connect the Type-C cable to the tablet's charging port and the adapter to a power outlet.

Powering On/Off

- To power on: Press and hold the power button located on the side of the tablet until the N-one logo appears.
- To power off: Press and hold the power button, then select 'Power off' from the options that appear on the screen.

SIM/MicroSD Card Installation

Locate the SIM/MicroSD card tray on the side of the tablet. Use the provided SIM ejector tool to open the tray. Carefully place your Nano SIM card and/or MicroSD card (up to 1TB) into the designated slots on the tray. Insert the tray back into the tablet until it clicks into place.

Video: A brief overview of the N-one Android Tablet, including a glimpse of its physical features and unboxing.

4. Operating the Tablet

Basic Navigation

Navigate your tablet using standard Android touch gestures: tap to select, swipe to scroll, pinch to zoom, and long-press for additional options.

Screen Modes (Art Space)

The tablet offers various screen modes to optimize your viewing experience:

- **Standard Mode:** Delivers balanced colors for an enhanced video and viewing experience.
- **Ink Mode:** Ideal for reading e-books, offering a paper-like experience with reduced color.
- **Pastel Mode:** Reduces screen power usage and color richness, suitable for comics and graphic content.

Connectivity

Connect to the internet via Dual-Band AC Wi-Fi (2.4GHz/5GHz) and pair accessories using Bluetooth 5.0. The integrated GPS allows for accurate location services.



Image: Visual representation of the tablet's WiFi and Bluetooth 5.0 capabilities.

Cameras

Utilize the 5MP front camera for video calls and selfies, and the 13MP rear camera for capturing photos and videos.



Image: The tablet's dual camera system, featuring a 5MP front and 13MP rear camera.

Advanced Features

- **Split Screen:** Multitask efficiently by running two apps side-by-side.
- **Screen Cast:** Share your tablet's display wirelessly to compatible screens.
- **Global Positioning:** Use GPS for navigation and location-based services.
- **Parental Control:** Manage and restrict content for younger users.

Split Screen



Image: The tablet displaying two apps in split-screen mode.

Screen Cast



Image: The tablet's screen cast feature showing content mirrored on various devices.

Global Positioning




Image: The tablet showing its global positioning feature with a map.

Parental Control



Image: A child using the tablet, indicating parental control features.

Gestures

The tablet supports various gestures for quick actions, such as the three-pointer screenshot feature.

Video: Demonstration of the three-pointer screenshot gesture on the tablet.

5. Maintenance

Battery Care

The 7500mAh battery is designed for long-lasting performance. To maximize battery life, avoid extreme temperatures and fully charge the device before it completely drains. For optimal performance, use the provided charger and cable.




Image: The tablet's 7500mAh battery capacity and estimated usage times.

Cleaning the Device

Use a soft, lint-free cloth to clean the screen and body of the tablet. Avoid using harsh chemicals or abrasive materials that could damage the device.

System Updates

Ensure your tablet's operating system is kept up-to-date by regularly checking for and installing system updates. This ensures you have the latest features, security patches, and performance improvements.

6. Troubleshooting

If you encounter any issues with your N-one NPad Plus tablet, try the following basic troubleshooting steps:

- **Restart the device:** A simple restart can often resolve minor software glitches.
- **Check connections:** Ensure Wi-Fi, Bluetooth, and charging cables are securely connected.
- **Free up storage:** If performance is slow, check your storage usage and delete unnecessary files or apps.
- **Factory Reset:** As a last resort, you may perform a factory reset. Be aware that this will erase all data on your device, so back up important information beforehand.

7. Specifications

Feature	Detail
Standing screen display size	10.36 Inches
Screen Resolution	2000x1200
Max Screen Resolution	2000x1200 MP
Processor	2 GHz mediatek_mt8183
RAM	16 GB
Hard Drive	128 GB
Graphics Coprocessor	Mali-G72
Chipset Brand	Mali
Wireless Type	802.11bgn
Average Battery Life (in hours)	8 Hours
Brand	N-one
Series	NPad Plus
Item model number	MTK8183
Operating System	Android 13
Item Weight	1 pounds

Feature	Detail
Product Dimensions	9.49 x 5.98 x 0.3 inches
Color	NPad Plus
Rear Webcam Resolution	13 MP
Processor Brand	MediaTek
Number of Processors	8
Computer Memory Type	DDR3 SDRAM
Power Source	AC & Battery
Batteries	1 Lithium Ion batteries required. (included)

8. Warranty and Support

For warranty information and customer support, please refer to the documentation included in your product packaging or visit the official N-one website. Keep your proof of purchase for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question