

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [UrbanX](#) /
- › [UrbanX M190 Bluetooth Speaker Instruction Manual](#)

UrbanX FM0190

UrbanX M190 Bluetooth Speaker Instruction Manual

Model: FM0190

1. INTRODUCTION

Thank you for choosing the UrbanX M190 Bluetooth Speaker. This manual provides essential information for the safe and efficient use of your new speaker. Please read it thoroughly before operation and retain it for future reference.

The UrbanX M190 is a portable Bluetooth speaker designed to deliver powerful stereo sound with the convenience of wireless connectivity. It features IPX7 waterproofing, True Wireless Stereo (TWS) pairing for an enhanced audio experience, and a durable, compact design suitable for various environments.

POWERFUL AUDIO

Features 1.69 inch driver with electric car motor equivalent material and exclusive BASSBOOST technology



Image: The UrbanX M190 Bluetooth Speaker in red, highlighting its compact and portable form factor.

2. PACKAGE CONTENTS

Please check the package for the following items:

- UrbanX M190 Bluetooth Speaker
- USB Type-C Charging Cable
- User Manual

3. PRODUCT FEATURES

- **Powerful Stereo Sound:** Equipped with a full-frequency unit and exclusive BASSBOOST technology for clear, robust audio.
- **IPX7 Waterproof & Dustproof:** Designed to withstand immersion in water up to 1 meter for 30 minutes, making it suitable for outdoor and wet environments.

- **True Wireless Stereo (TWS) Pairing:** Connect two UrbanX M190 speakers wirelessly to a single source for an immersive surround sound experience.
- **Bluetooth V5.2 Connectivity:** Ensures a stable and efficient wireless connection with your devices.
- **Long Battery Life:** Built-in 1800mAh rechargeable lithium-ion battery provides up to 20 hours of continuous playback.
- **Multiple Playback Options:** Supports Bluetooth, 32GB SD/TF card playback, and AUX input.
- **Integrated Microphone:** Allows for hands-free calling.
- **Compact & Portable Design:** Measuring 140mm x 120mm, crafted from durable ABS plastic, nylon fabric, rubber oil, and metal, with a fixed loop for easy carrying.



Image: Illustration of the speaker's internal driver technology, emphasizing powerful audio output.

WIRELESS STEREO PAIRING

Enjoy The 360° Surround Sound Of The Cinema



Image: The UrbanX M190 speaker in a wet environment, showcasing its IPX7 waterproof design.

4. SETUP

4.1 Charging the Speaker

1. Connect the provided USB Type-C charging cable to the charging port on the speaker.
2. Connect the other end of the cable to a USB power adapter (not included) or a computer's USB port.
3. The charging indicator light will illuminate during charging. It typically takes 3-4 hours for a full charge.
4. The indicator light will change or turn off once charging is complete.

4.2 Powering On/Off

- **To Power On:** Press and hold the Power button (⏻) for approximately 3 seconds until you hear an audible prompt and the indicator light turns on.
- **To Power Off:** Press and hold the Power button (⏻) for approximately 3 seconds until you hear an audible prompt and the indicator light turns off.

4.3 Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth pairing mode (the indicator light will typically flash rapidly).
2. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
3. Select "UrbanX M190" from the list of found devices.
4. Once paired, you will hear an audible confirmation, and the indicator light will remain solid.

5. OPERATING INSTRUCTIONS

5.1 Basic Controls

- **Play/Pause:** Press the Power button (⏻) once to play or pause music.
- **Volume Up:** Press the "+" button to increase volume.
- **Volume Down:** Press the "-" button to decrease volume.
- **Next Track:** Press and hold the "+" button for 2 seconds.
- **Previous Track:** Press and hold the "-" button for 2 seconds.

5.2 Answering Calls

When connected to a smartphone via Bluetooth:

- **Answer Call:** Press the Power button (⏻) once.
- **End Call:** Press the Power button (⏻) once during a call.
- **Reject Call:** Press and hold the Power button (⏻) for 2 seconds.

5.3 SD/TF Card Playback

Insert a formatted SD/TF card (up to 32GB) with audio files into the designated slot. The speaker will automatically switch to SD/TF card mode and begin playback.

5.4 AUX Input

Connect an audio device to the speaker's AUX port using a 3.5mm audio cable (not included). The speaker will automatically switch to AUX mode.

6. TRUE WIRELESS STEREO (TWS) PAIRING

To achieve a surround sound experience, you can pair two UrbanX M190 speakers together.

1. Ensure both UrbanX M190 speakers are powered off.
2. Power on both speakers simultaneously. They will enter Bluetooth pairing mode.
3. On one of the speakers (this will be your primary speaker), double-press the Power button (⏻). The speaker will search for another UrbanX M190 speaker.
4. Once connected, you will hear an audible confirmation, and the indicator lights on both speakers will synchronize.
5. Now, connect your device to the primary speaker via Bluetooth as described in Section 4.3. Audio will play through both speakers in stereo.

ULTRA-COMPACT AND LIGHTWEIGHT

With a fixed loop for easy carrying



Image: Two UrbanX M190 speakers paired together, demonstrating the True Wireless Stereo function.

7. MAINTENANCE

7.1 Cleaning

Wipe the speaker with a soft, damp cloth. Do not use abrasive cleaners, alcohol, or chemical solvents, as these may damage the surface.

7.2 Waterproof Care (IPX7)

- Ensure the charging port cover is securely closed before exposing the speaker to water.
- Do not intentionally submerge the speaker for extended periods or beyond the specified depth (1 meter for 30 minutes).
- After exposure to water, dry the speaker thoroughly before charging or opening the port cover.

7.3 Storage

Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures. If storing for a long

period, charge the battery periodically to maintain its lifespan.

8. TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|---------------------------|---|---|
| Speaker does not power on | Low battery | Charge the speaker fully. |
| Cannot pair via Bluetooth | Speaker not in pairing mode; Device Bluetooth off; Speaker too far from device | Ensure speaker is in pairing mode. Turn Bluetooth on your device. Move speaker closer to device (within 5m). Forget device on your phone and re-pair. |
| No sound | Volume too low; Incorrect input mode; Device not playing audio | Increase speaker and device volume. Check if the correct input mode (Bluetooth, SD/TF, AUX) is selected. Ensure audio is playing on your device. |
| TWS pairing fails | Speakers not reset; Too far apart | Ensure both speakers are powered off before starting TWS pairing. Keep speakers close during pairing. |

9. SPECIFICATIONS

| Feature | Specification |
|----------------------|--|
| Model Number | FM0190 |
| Bluetooth Version | V5.2 |
| Battery Capacity | 1800mAh Lithium-ion |
| Playback Time | Up to 20 hours (at 50% volume) |
| Charging Time | 3-4 hours |
| Charging Port | USB Type-C |
| Waterproof Rating | IPX7 |
| Speaker Output Power | 5 Watts |
| Frequency Response | 20 Hz - 20 kHz (typical) |
| Wireless Range | Up to 5 meters (16 feet) |
| Dimensions (W x H) | 140mm x 120mm (5.5" x 4.7") |
| Weight | Approximately 15 ounces (425g) |
| Material | ABS Plastic, Nylon Fabric, Rubber Oil, Metal |
| Control Method | Touch Buttons |

10. WARRANTY AND SUPPORT

UrbanX products are designed and manufactured to the highest quality standards. This product is covered by a standard manufacturer's warranty against defects in materials and workmanship from the date of purchase.

For warranty claims, technical support, or any questions regarding your UrbanX M190 Bluetooth Speaker, please contact our customer support team through the retailer where the product was purchased or visit the official UrbanX website for contact information.

Please retain your proof of purchase for warranty service.

