

PayLessHere GD-L5809

PayLessHere L Shaped Gaming Computer Desk Instruction Manual

MODEL: GD-L5809

1. Safety Information

Please read all safety information before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- Ensure the desk is properly anchored to avoid tipping.
- Do not exceed the weight limit of the desktop (Maximum Weight Recommendation: 80 kg).
- Keep small parts away from children during assembly.
- Use the desk on a flat, stable surface.

2. Product Overview

The PayLessHere L Shaped Gaming Computer Desk is designed for home and work environments, offering a spacious and stable surface for various activities. Its L-shape design efficiently utilizes corner space, providing ample room for monitors, keyboards, and other equipment.



Easy to clean



Stable Structure



Multi Function

L Shaped Gaming Desk

Image: The L Shaped Gaming Computer Desk set up in a modern office or gaming environment.

Key Features:

- **L-Shaped Design:** Maximizes corner space for an expansive work or gaming area.
- **Durable Construction:** Made with 15mm P2 particleboard and a metal frame for stability.
- **Z-Shape Structure:** Ensures stable and even support, preventing wobbling.
- **Detachable Monitor Stand:** Provides an elevated surface for monitors, improving ergonomics and freeing up desktop space.
- **Easy to Clean:** The desktop is anti-scratching, waterproof, and easy to maintain.
- **Adjustable Foot Pads:** For stability on uneven floors.

3. Assembly Instructions

The PayLessHere L Shaped Gaming Computer Desk is designed for straightforward assembly. All necessary hardware and an illustrated manual are included in the package. It is recommended that two people assemble the desk for ease and safety.

Assembly Video Guide:

Your browser does not support the video tag.

Video: A step-by-step guide demonstrating the assembly process for the L-shaped computer desk.

Key Assembly Steps and Components:

- **Unpack Components:** Carefully remove all parts from the packaging and verify against the parts list in the included manual.
- **Assemble Frame:** Connect the metal frame components using the provided screws. Ensure all connections are secure but do not fully tighten until the desk is fully assembled.

Dimensions

UNIT:INCH




Image: Detailed dimensions of the L-shaped desk, including desktop length and height.

- **Attach Desktop Panels:** Secure the P2 particleboard desktop panels to the assembled frame.



Image: Illustration of the Z-shaped leg design and stable triangle structure for enhanced stability.

- **Install Monitor Stand:** The detachable monitor stand can be fixed on any table edge as needed.



Image: Detail of the removable monitor shelf, highlighting its adjustability.

- **Adjust Foot Pads:** Level the desk using the adjustable foot pads to ensure stability.



Image: The bottom baffle component, designed to provide stable support.

- **Final Tightening:** Once all parts are aligned and in place, fully tighten all screws.

4. Usage Guidelines

This L-shaped desk is suitable for various uses, including gaming, studying, and general office work. Its design allows for efficient organization of your workspace.

- **Ergonomic Setup:** Utilize the detachable monitor stand to position your screen at an optimal height, reducing neck and eye strain.
- **Cable Management:** Take advantage of the desk's design for cable routing to keep your workspace tidy.
- **Weight Distribution:** Distribute heavy items evenly across the desktop to maintain stability.




Image: A monitor positioned on the detachable stand, illustrating its use.

5. Maintenance

Proper maintenance will extend the life and appearance of your desk.

- **Cleaning:** Wipe with a damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the laminated finish.
- **Spills:** Clean up spills immediately to prevent staining or damage to the P2 particleboard.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.



Image: Close-up of the high-quality MDF board, showcasing its durable and easy-to-clean surface.

6. Troubleshooting

If you encounter any issues with your desk, please refer to the following common solutions:

- **Wobbling Desk:** Ensure all screws are fully tightened. Adjust the foot pads on the bottom of the legs to level the desk on uneven floors.
- **Missing Parts:** If any parts are missing upon arrival, please contact customer support immediately with your purchase details.
- **Difficulty Assembling:** Review the assembly video and the included instruction manual carefully. Ensure all parts are oriented correctly before tightening screws.

7. Product Specifications

Specification	Detail
Brand	PayLessHere
Model Number	GD-L5809-White
Shape	L-Shape
Product Dimensions (D x W x H)	50"D x 50"W x 29.5"H (Adjustable height up to 35"H with monitor stand)
Item Weight	42 pounds
Top Material Type	Wood (P2 grade particleboard)
Base Material	Metal
Finish Type	Laminated (Melamine)
Maximum Weight Recommendation	80 kg
Number of Shelves	1 (Detachable Monitor Stand)
Recommended Number of People for Assembly	2
Special Feature	Ergonomic, Adjustable Foot Pads

8. Warranty and Support

This PayLessHere L Shaped Gaming Computer Desk comes with a limited warranty covering parts and manufacturing defects.

- **Warranty Type:** Limited Warranty
- **Coverage:** Covers manufacturing defects and parts.
- **Customer Service:** If you have any questions, require assistance with assembly, or need to report a missing/damaged part, please contact PayLessHere customer service. Our team aims to respond within 24 hours to resolve any issues.

For support, please refer to the contact information provided with your purchase or visit the official PayLessHere website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question