nania MIGO

Nania MIGO 2-in-1 Playpen and Travel Cot

Instruction Manual

1. Important Safety Information

Please read and understand all instructions before assembling and using the Nania MIGO Playpen and Travel Cot. Keep this manual for future reference.

- **WARNING:** Risk of tipping if not properly secured. Always ensure the playpen is fully locked and stable before placing a child inside.
- Use the zippered door with caution to prevent any risk of entrapment. Always ensure the zipper is fully closed when the child is unsupervised.
- Follow all care instructions for the included mattress and transport bag.
- The playpen is designed for children from birth up to 15 kg (approximately 36 months).
- Always use the mattress provided by the manufacturer. Do not add an additional mattress, as this can create a suffocation hazard.
- Ensure all locking mechanisms are engaged before use.
- Never leave a child unattended in the playpen.

2. Product Overview

The Nania MIGO is a versatile 2-in-1 product designed to function as both a playpen and a travel cot. It features two adjustable height levels, mesh sides for visibility and ventilation, a convenient zippered side door, and wheels with brakes for easy mobility.

Key Features:

- **2-in-1 Functionality:** Serves as a playpen and a travel cot.
- **Age/Weight Range:** Suitable from birth up to 15 kg (approx. 36 months).
- **Adjustable Height:** Two height levels for different developmental stages (high position for infants 0-6 months, low position for 6-36 months).
- **Visibility & Ventilation:** Mesh sides provide clear visibility and optimal airflow.
- **Easy Access:** Equipped with a zippered side door for child entry and exit.
- **Portability:** Includes wheels with brakes for easy movement and a transport bag for travel.

- **Comfort:** Comes with a travel mattress.

3. Package Contents

Ensure all components are present before assembly:

- Nania MIGO Playpen/Travel Cot Frame
- Travel Mattress
- Transport Bag



Image: The Nania MIGO playpen shown with its folded transport bag and a close-up detail of the zippered side door.

4. Setup Instructions

4.1 Unfolding the Playpen

1. Remove the playpen from its transport bag.
2. Stand the playpen upright and separate the legs slightly.

3. Pull the two short sides upwards until they lock into place. You should hear a click.
4. Pull the two long sides upwards until they lock into place. Ensure all four sides are rigid.
5. Push the center of the base downwards until it lies flat and is fully extended.

4.2 Installing the Mattress and Adjusting Height

1. **For High Position (0-6 months):** If your model includes an elevated bassinet insert, attach it according to its specific instructions. Place the travel mattress on top of the bassinet insert.
2. **For Low Position (6-36 months):** Place the travel mattress directly on the lowest base of the playpen.




Image: A side view of the playpen illustrating the two possible mattress height settings.

5. Operating Instructions

5.1 Using the Zippered Side Door

- The playpen features a zippered side door for easy access.
- To open, locate the zipper pull and slide it downwards.

- To close, slide the zipper pull upwards until it is fully secured. Always ensure the door is closed when the child is inside and unsupervised.



Image: The playpen with its zippered side door open, revealing toys on the floor, demonstrating easy access.

5.2 Engaging and Disengaging Wheel Brakes

- The playpen is equipped with wheels on one side for mobility.
- To engage the brakes, push down on the lever located on each wheel.
- To disengage the brakes, lift the lever upwards.
- Always engage the brakes when the playpen is stationary to prevent accidental movement.



Image: A close-up side view of the playpen, highlighting a wheel with its brake mechanism.

6. Folding and Storage

6.1 Folding the Playpen

1. Remove the mattress and any other items from the playpen.
2. Pull the center of the base upwards until it is partially folded.
3. Locate the release buttons on the middle of each side rail (usually under the fabric). Press these buttons and push the side rails downwards to unlock and fold them.
4. Bring the four corners together to fully collapse the playpen.

6.2 Storing in the Transport Bag

1. Wrap the folded mattress around the collapsed playpen frame.
2. Place the wrapped playpen into the transport bag.
3. Zip the bag closed for compact storage and easy transport.



Image: The playpen in its compact, folded state, positioned next to the folded travel mattress, ready to be placed in the transport bag.

7. Maintenance

7.1 Cleaning the Fabric

- Wipe fabric surfaces with a damp cloth and mild soap.
- Do not use harsh detergents or abrasive cleaners.
- Allow to air dry completely before folding or storing.

7.2 Cleaning the Frame

- Wipe the metal and plastic parts of the frame with a damp cloth.
- Ensure all parts are dry to prevent rust or damage.

7.3 Mattress Care

- The travel mattress cover may be removable for washing. Refer to the care label on the mattress for specific washing instructions.
- If the cover is not removable, spot clean with a damp cloth and mild soap.
- Ensure the mattress is completely dry before use or storage to prevent mold and mildew.

8. Troubleshooting

- **Difficulty Unfolding/Folding:** Ensure the center of the base is either fully pushed down (for unfolding) or fully pulled up (for folding) before attempting to lock/unlock the side rails. The side rails must be unlocked before the base can be fully collapsed.
- **Playpen Not Stable:** Verify that all four side rails are securely locked into place. Push down firmly on the center of the base to ensure it is flat and stable.
- **Wheels Not Rolling Smoothly:** Check for any debris or obstructions in the wheels. Ensure brakes are fully disengaged.

9. Specifications

Feature	Specification
Brand	nania
Model	MIGO
Color	Gris (Grey)
Material Type	Fabric
Item Weight	9 Kilograms
Unfolded Dimensions (L x W x H)	100 cm x 100 cm x 76 cm
Folded Dimensions (L x W x H)	25 cm x 25 cm x 97 cm
Age/Weight Capacity	From birth up to 15 kg (approx. 36 months)
Components Included	Travel Mattress, Transport Bag




Image: A technical drawing illustrating the main dimensions of the Nania MIGO playpen when unfolded.

10. Warranty Information

Nania products are manufactured to high-quality standards. For specific warranty details, please refer to the warranty card included with your purchase or contact Nania customer support. Keep your proof of purchase for any warranty claims.

11. Customer Support

If you have any questions, require assistance, or need to report an issue with your Nania MIGO Playpen and Travel Cot, please contact Nania customer support. Contact information can typically be found on the product packaging, the Nania website, or through your retailer.

Nania is committed to providing excellent customer service and ensuring the safety and satisfaction of its users.

© 2026 Nania. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question