

[manuals.plus](#) /

› [Tribit](#) /

› [Tribit XSound Plus 2 Portable Bluetooth Speaker User Manual](#)

Tribit BTS65

Tribit XSound Plus 2 Portable Bluetooth Speaker User Manual

Model: BTS65 | Brand: Tribit

1. SETUP

1.1 Unboxing and Initial Charge

Upon opening the package, ensure all components are present:

- Portable Bluetooth Speaker
- User Manual
- Charging Cable
- Lanyard



Tribit XSound Plus 2 speaker and included accessories.

Before first use, fully charge the speaker using the provided charging cable. A full charge ensures optimal battery performance.

1.2 Powering On/Off

To power on the speaker, press and hold the power button located on the top panel until you hear an audible prompt. To power off, press the power button briefly. The speaker will indicate its power status.

1.3 Bluetooth Pairing

The Tribit XSound Plus 2 utilizes Bluetooth 5.3 for stable and efficient wireless connectivity, offering a range of up to 150 feet. Follow these steps to pair your device:

1. Ensure the speaker is powered on and in pairing mode (indicated by a flashing Bluetooth indicator).
2. On your device (smartphone, tablet, laptop), navigate to the Bluetooth settings.
3. Select 'Tribit XSound Plus 2' from the list of available devices.
4. Once connected, the Bluetooth indicator on the speaker will become solid, and you will hear a confirmation

tone.

Bluetooth 5.3

Optimizing Stability



Tribit XSound Plus 2 speaker connecting via Bluetooth 5.3.

Your browser does not support the video tag.

Official video demonstrating the Tribit XSound Plus 2 speaker's features and connectivity.

1.4 TWS (True Wireless Stereo) Pairing

For an enhanced audio experience, two Tribit XSound Plus 2 speakers can be paired together to create a true wireless stereo sound system. This feature provides distinct left and right audio channels.

1. Ensure both speakers are powered on and not connected to any other Bluetooth device.
2. Press the TWS button on both speakers. They will automatically search for and connect to each other.
3. Once connected, one speaker will act as the master (left channel) and the other as the slave (right channel).
4. Now, connect your device to the master speaker via Bluetooth as described in section 1.3.

24-Hour Extended Standby



*The actual battery life of the speaker may vary based on different volume levels and EQ modes.

Two Tribit XSound Plus 2 speakers paired for True Wireless Stereo.

2. OPERATING INSTRUCTIONS

2.1 Basic Controls

Speaker Button Functions

Button	Function
Power Button	Press and hold to Power On/Off. Brief press to turn off when on.
Volume +	Increase Volume
Volume -	Decrease Volume
Play/Pause	Play/Pause music, Answer/End calls

Button	Function
XBass/EQ Button	Cycle through EQ modes (XBass, Music, Audiobook, etc.)
Bluetooth Button	Enter pairing mode, Disconnect current device
TWS Button	Initiate/Cancel TWS pairing

The built-in microphone allows for hands-free calling when connected to a smartphone. Press the Play/Pause button to answer or end a call.

2.2 Sound Modes and Customization

The XSound Plus 2 offers versatile sound customization. It features 3 button-accessible modes and 6 default settings within the Tribit App, allowing for limitless personalized audio experiences. For users who prefer the sound profile of the MaxSound Plus, a specially designed 'Traditional EQ' setting is available. Ensure your speaker firmware and the Tribit App are updated to the latest versions to access all features.



Tribit XSound Plus 2 app interface showing various EQ modes.

2.3 XBass Technology

Experience deep, rich bass with Tribit's patented XBass algorithm. This technology, combined with neodymium full-range drivers and advanced DSP, enhances low frequencies to deliver powerful and clear audio. Activate XBass mode via the dedicated button on the speaker or through the Tribit App for an immersive listening experience.

30W Twilight Sound



Internal view of the Tribit XSound Plus 2 showcasing its 30W drivers and XBass technology.

2.4 Battery Life

The Tribit XSound Plus 2 is designed for extended listening sessions, offering up to 24 hours of playtime on a single charge thanks to its RunStretch technology. Actual battery life may vary based on volume levels, audio content, and usage of features like XBass or TWS pairing.

TWS

Stereo Fusion



Tribit XSound Plus 2 speaker with an overlay indicating 24-hour battery life.

3. MAINTENANCE

3.1 Waterproofing (IPX7)

The XSound Plus 2 boasts an IPX7 waterproof rating, meaning it can be submerged in up to 1 meter of water for 30 minutes. This makes it ideal for outdoor use, by the pool, or at the beach. To maintain its waterproof integrity:

- Ensure the charging port cover is securely closed before exposure to water.
- Do not expose the speaker to saltwater or other chemicals, as this may damage the seals.
- After exposure to water, especially chlorinated or saltwater, rinse the speaker with fresh water and dry thoroughly before charging.

3.2 Cleaning

To clean the speaker, use a soft, damp cloth. Avoid using abrasive cleaners, solvents, or harsh chemicals, as these can damage the speaker's finish or internal components.

3.3 Storage

When storing the speaker for extended periods, ensure it is fully charged and stored in a cool, dry place away from direct sunlight and extreme temperatures. Recharge the speaker every few months to maintain battery health.

4. TROUBLESHOOTING

If you encounter issues with your Tribit XSound Plus 2 speaker, refer to the common problems and solutions below. For more detailed troubleshooting, consult the full user manual PDF available online.

- Speaker will not power on:** Ensure the battery is charged. Connect the speaker to a power source using the charging cable.
- Cannot pair with Bluetooth device:** Make sure the speaker is in pairing mode (flashing Bluetooth indicator). Ensure Bluetooth is enabled on your device and it is within range. Try forgetting the device on your phone and re-pairing.
- No sound:** Check the volume levels on both the speaker and your connected device. Ensure the speaker is successfully paired.
- Sound distortion:** Reduce the volume on both the speaker and your device. Ensure the speaker is not too far from the connected device.
- TWS pairing issues:** Ensure both speakers are powered on and not connected to any other devices. Try resetting both speakers before attempting TWS pairing again.

Your browser does not support the video tag.

Official unboxing video for the Tribit XSound Plus 2, useful for initial setup and component verification.

Your browser does not support the video tag.

Official product overview video for the Tribit XSound Plus 2, providing insights into its features and operation.

5. SPECIFICATIONS

Feature	Detail
Model Name	XSound Plus 2
Speaker Type	Outdoor
Special Features	30W with XBass, IPX7 Waterproof, 24-Hour Playtime, Stereo Sound, Built-in Mic, Bluetooth 5.3
Product Dimensions	7.83"D x 2.63"W x 2.75"H
Item Weight	580 Grams (1.28 pounds)
Battery Life	24 Hours
Wireless Communication Technology	Bluetooth 5.3
Speaker Maximum Output Power	30 Watts

Feature	Detail
Waterproof Rating	IPX7
Included Components	User Manual, Lanyard, Charging Cable, Portable Bluetooth Speaker



Dimensions of the Tribit XSound Plus 2 speaker.

6. WARRANTY AND SUPPORT

The Tribit XSound Plus 2 comes with a Limited Warranty. For specific warranty terms and conditions, please refer to the detailed information provided in the included User Manual or visit the official Tribit website.

For technical support, troubleshooting assistance, or any product-related inquiries, please contact Tribit customer service through their official channels. You can often find contact information on the Tribit website or within the product packaging.

A digital version of this user manual is available for download at:[Tribit XSound Plus 2 User Manual \(PDF\)](#)