

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- > [MAGOLFIN](#) /
- > [MAGOLFIN X10 Golf Cart Speaker User Manual](#)

MAGOLFIN X10

MAGOLFIN X10 Golf Cart Speaker User Manual

Model: X10

INTRODUCTION

Thank you for choosing the MAGOLFIN X10 Golf Cart Speaker. This portable Bluetooth speaker is designed to enhance your outdoor activities, especially golf, with powerful sound, robust magnetic attachment, and durable waterproof construction. Please read this manual carefully to understand the features, setup, and operation of your new speaker.

WHAT'S IN THE BOX

- MAGOLFIN X10 Magnetic Golf Speaker
- Storage Case
- User Manual
- USB-C Charging Cable
- 3.5mm AUX-in Cable
- Hang Hook & Strap



Image showing the MAGOLFIN X10 speaker alongside its protective storage case.

Magnetic Attachment



MAGNETS ARE SUPER STRONG

Very strong magnet which really holds it on the metal rails of the golf cart even through cart cover


Powerful Magnetism

The speaker features a super strong built-in magnet, allowing for secure attachment to golf carts, bikes, or any magnetic surface. This ensures your speaker stays in place even during movement.

IPX7 Waterproof Rating

IPX7 WATERPROOF

Water and rain will not damage the speaker,
So if you get caught in the rain during your round, no worries!



IPX7

Designed with military-grade quality and IPX7 waterproofing, this speaker is built to withstand splashes, rain, and even submersion up to 1 meter for 30 minutes, making it ideal for outdoor use.

Extended Playtime

24H PLAYTIME

You can easily get 3-5 rounds out of a single charge, depending on how loud you listen to your music



Equipped with a 2500mAh high-capacity battery, the speaker provides up to 24 hours of continuous music playback on a single charge, ensuring your music lasts through multiple rounds of golf or extended outdoor adventures.

Immersive Stereo Sound (TWS)

STEREO SOUND

Pair with two bluetooth speakers to get Stereo experience



Utilize True Wireless Stereo (TWS) functionality to pair two MAGOLFIN X10 speakers for an immersive 360° stereo sound experience, transforming your environment into a personal concert hall.

SETUP

Charging the Speaker

Before first use, fully charge the speaker. Connect the provided USB-C charging cable to the speaker's charging port and the other end to a USB power adapter (not included) or a computer's USB port. The charging indicator light will show charging status and turn off when fully charged.



Image showing the charging port (Type-C) along with Micro SD and AUX IN ports.

Power On/Off

- To power on: Press and hold the Power button for 2-3 seconds until you hear an audible prompt.
- To power off: Press and hold the Power button for 2-3 seconds until you hear an audible prompt.

OPERATING INSTRUCTIONS

Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth pairing mode (indicated by a flashing LED).
2. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
3. Select "MAGOLFIN X10" from the list of devices.
4. Once connected, you will hear a confirmation sound, and the LED indicator will turn solid.

True Wireless Stereo (TWS) Pairing

For an enhanced stereo experience, you can pair two MAGOLFIN X10 speakers together.

1. Ensure both speakers are powered on and not connected to any other Bluetooth device.
2. On one speaker (this will be the primary speaker), double-press the TWS button (usually indicated by a chain link icon or similar). The speaker will enter TWS pairing mode.
3. The two speakers will automatically search for and connect to each other. You will hear a confirmation sound once paired.
4. Once TWS paired, connect your device to the primary speaker via Bluetooth as described in the "Bluetooth Pairing" section. Both speakers will now play audio in stereo.



Image illustrating two speakers wirelessly connected for a stereo sound experience.

Audio Playback Modes

- **Bluetooth Mode:** After successful Bluetooth pairing, audio from your connected device will play through the speaker.
- **AUX-in Mode:** Connect one end of the 3.5mm AUX cable to the speaker's AUX-in port and the other end to your audio source. The speaker will automatically switch to AUX mode.
- **TF Card Mode:** Insert a TF (Micro SD) card with audio files into the speaker's TF card slot. The speaker will automatically detect and play music from the card.

Button Functions

Button	Function (Short Press)	Function (Long Press)
Power Button	Play/Pause (in Bluetooth/TF mode), Answer/End Call	Power On/Off
Volume Up (+)	Increase Volume	Next Track
Volume Down (-)	Decrease Volume	Previous Track
TWS Button	(No function)	Enter TWS Pairing Mode (double press)

MAINTENANCE

- **Cleaning:** Wipe the speaker with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures. If storing for extended periods, charge the battery every 3-6 months to maintain battery health.
- **Water Exposure:** While IPX7 waterproof, ensure the charging port cover is securely closed before exposing the speaker to water. After water exposure, dry the speaker thoroughly before charging.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not turn on.	Low battery.	Charge the speaker fully.
Cannot pair with Bluetooth device.	Speaker not in pairing mode; device Bluetooth off; too far from speaker.	Ensure speaker is in pairing mode. Turn device Bluetooth on/off. Move device closer to speaker (within 10 meters).

Problem	Possible Cause	Solution
No sound.	Volume too low; incorrect input mode; device not playing.	Increase speaker and device volume. Check if correct mode (Bluetooth/AUX/TF) is selected. Ensure audio is playing on the connected device.
TWS pairing failed.	Speakers too far apart; one speaker already connected to a device.	Ensure speakers are close to each other. Disconnect any Bluetooth devices from both speakers before TWS pairing.

SPECIFICATIONS

Feature	Detail
Model Name	X10
Brand	MAGOLFIN
Speaker Type	Outdoor, Portable Bluetooth Speaker
Connectivity Technology	Bluetooth, Auxiliary, TF Card
Bluetooth Range	Up to 10 meters (33 feet)
Speaker Output Power	18 Watts
Battery Life	Up to 24 Hours (2500mAh)
Water Resistance	IPX7 Waterproof
Dimensions (L x W x H)	3.94"D x 2.28"W x 3.94"H
Item Weight	1.1 Pounds
Included Components	Speaker, Storage Case, Manual, Charging Cable, AUX Cable, Hang Hook & Strap

WARRANTY AND SUPPORT

The MAGOLFIN X10 speaker comes with a limited warranty. Please refer to the warranty card included in your package for specific terms and conditions. For technical support, troubleshooting assistance, or warranty claims, please contact MAGOLFIN customer service through the retailer where you purchased the product or visit the official MAGOLFIN website. For more information, visit the [MAGOLFIN Store on Amazon](#).