

[Manuals.plus](#) /

› [Wildgame Innovations](#) /

› Wildgame Innovations Terra XD Trail Camera User Manual

Wildgame Innovations WGI-TERAXD-2PK

Wildgame Innovations Terra XD Trail Camera User Manual

Model: WGI-TERAXD-2PK

INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, and maintenance of your Wildgame Innovations Terra XD Trail Camera 2-pack. Please read this manual thoroughly before using your cameras to ensure optimal performance and longevity.

PACKAGE CONTENTS

- 2 x Wildgame Innovations Terra XD Trail Cameras
- 2 x Mounting Straps



This image displays two Wildgame Innovations Terra XD trail cameras packaged together, highlighting key features like 20MP resolution, 60ft illumination range, and 0.7-second trigger speed. The packaging also shows the HuntSmart app logo and QR codes for app download.

SETUP

1. Battery Installation

The Terra XD cameras are battery-powered. Open the battery compartment located on the side or bottom of the camera. Insert the required number of AA batteries (not included), ensuring correct polarity (+/-). Close the compartment securely to maintain the camera's water resistance.

2. SD Card Installation

Locate the SD card slot. Insert a compatible SD card (up to 32GB, Class 4 or higher recommended) with the metal contacts facing down, until it clicks into place. Ensure the card is not write-protected. Formatting the SD card within the camera's settings is recommended for first-time use.

3. Mounting the Camera

Use the included mounting straps to secure the camera to a tree or post. Position the camera at an appropriate height and angle to capture the desired area. Ensure the camera is stable and not prone to movement from wind or wildlife. The camera is designed for outdoor use and features a tree mount type.



This image shows two Wildgame Innovations Terra XD trail cameras from a front-facing angle, alongside their included mounting straps. The cameras feature a camouflage-like texture and a compact design, ready for outdoor deployment.

4. HuntSmart App Integration

For enhanced management and connectivity, download the HuntSmart app on your smartphone. The app allows for remote management and viewing of your camera's data, utilizing the camera's cellular and Wi-Fi connectivity protocols.

Download on the App Store: [HuntSmart Trail Cam App](#)

OPERATION

1. Powering On/Off

Locate the power switch on the camera. Slide it to the 'ON' position to power on the camera. The camera will typically perform a brief self-check. To power off, slide the switch to the 'OFF' position.

2. Photo Modes

The Terra XD camera supports 20 Megapixel photography. You can configure the camera to capture single photos or a burst of 1-3 photos per trigger event. Refer to the camera's internal menu for specific settings adjustments.

3. Video Modes

The camera is capable of recording 720 HD video. Please note that video recordings do not include audio. Adjust video length and resolution settings via the camera's menu.

4. Trigger Speed

The Terra XD features a fast 0.7-second trigger speed, ensuring minimal delay between motion detection and image/video capture.

MAINTENANCE

1. Water Resistance

The camera has an International Protection Rating of IP54, meaning it is protected from dust and splashing water from any direction. While water-resistant, avoid submerging the camera in water.

2. Battery and SD Card Management

Regularly check battery levels and replace them when low to prevent interruption of camera operation. Periodically

remove and review the contents of your SD card, backing up important files and formatting the card to maintain optimal performance and storage capacity.

TROUBLESHOOTING

Common Issues

- **Camera not powering on:** Check battery installation and ensure batteries are fresh.
- **No images/videos captured:** Verify SD card is inserted correctly, not full, and not write-protected. Check motion sensor settings.
- **Poor image quality:** Ensure the lens is clean and free from obstructions. Check lighting conditions.
- **Connectivity issues:** Ensure the camera is within range of a cellular or Wi-Fi signal if using advanced features. Refer to the HuntSmart app for connection status.

PRODUCT SPECIFICATIONS

Feature	Specification
Model Name	WGI-TERAXD-2PK
Effective Still Resolution	20 MP
Video Capture Resolution	720p (no audio)
Trigger Speed	0.7 seconds
Photo Burst	1-3 photos
Power Source	Battery Powered (Batteries Required)
Mounting Type	Tree Mount
Indoor/Outdoor Usage	Outdoor
Water Resistance Level	Water Resistant (IP54)
Connectivity Protocol	Cellular
Wireless Communication Technology	Wi-Fi
Compatible Devices	Smartphone
Included Components	2 Trail Cameras
Product Dimensions	10 x 4 x 10 inches
Item Weight	1.94 pounds

WARRANTY AND SUPPORT

Wildgame Innovations products are manufactured by GSM Outdoors. For specific warranty information and customer support, please refer to the documentation included with your purchase or visit the official Wildgame Innovations website. Keep your proof of purchase for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CKY51L7T>

More documents and user manuals: <https://manuals.plus/>