

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Stealth Cam](#) /

› [Stealth Cam TS20 20MP Infrared Trail Cameras User Manual](#)

Stealth Cam TS20

Stealth Cam TS20 20MP Infrared Trail Cameras User Manual

Model: TS20 | Brand: Stealth Cam

INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, and maintenance of your Stealth Cam TS20 20MP Infrared Trail Cameras. Designed for outdoor surveillance, these cameras capture high-quality images and videos with a 60 ft. detection range and a rapid 0.8-second trigger speed. Please read this manual thoroughly before using your cameras to ensure optimal performance and longevity.

PACKAGE CONTENTS

Upon unpacking your Stealth Cam TS20 20MP Infrared Trail Cameras, please verify that all items listed below are present and in good condition:

- 2 x Stealth Cam TS20 20MP Infrared Trail Cameras
- Instruction Manual (this document)
- Mounting Straps (typically included with trail cameras)



An image showing the packaging for two Stealth Cam TS20 20MP Infrared Trail Cameras. The cameras are visible through the clear plastic packaging, highlighting their camouflage design. Key features like '20.0 MEGAPIXEL', '0.8 SECOND TRIGGER SPEED', and '60 FOOT RANGE' are printed on the packaging.

KEY FEATURES

The Stealth Cam TS20 cameras are equipped with advanced features for reliable outdoor monitoring:

- **Photo Resolution:** 20 Megapixels for clear still images.
- **Video Resolution:** 720P HD video recording.
- **Trigger Speed:** Ultra-fast 0.8-second trigger to capture fast-moving subjects.
- **Detection & IR Range:** 60 feet for both motion detection and infrared flash.
- **LED Flash Type:** Infrared for discreet night vision without visible light.
- **Burst Mode:** Captures 1-3 photos per trigger event.
- **Recovery Time:** Adjustable from 5 to 120 seconds between triggers.
- **Image Stamp:** Automatically stamps time, date, and moon phase on captured media.
- **Quick Set Programming:** Simplified setup for ease of use.
- **Water Resistance:** Designed to withstand outdoor elements.

SETUP

1. Battery Installation

1. Open the camera housing latch and swing open the front cover.

2. Locate the battery compartment.
3. Insert 8 new AA alkaline or lithium batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
4. Close the battery compartment securely.

2. SD Card Installation

1. With the camera powered off, locate the SD card slot.
2. Insert a formatted SD card (up to 32GB, not included) into the slot with the label facing up, until it clicks into place.
3. To remove, push the SD card in until it clicks, then release to eject.

3. Mounting the Camera

The Stealth Cam TS20 is designed for tree mounting. Follow these steps:

1. Select a sturdy tree or post at the desired height (typically 3-6 feet off the ground).
2. Thread the provided mounting strap through the slots on the back of the camera.
3. Securely fasten the strap around the tree, ensuring the camera is stable and pointed towards the desired detection area.
4. Adjust the camera angle as needed.

OPERATING INSTRUCTIONS

1. Powering On/Off

- To power on, slide the power switch to the 'ON' position. The status LED will illuminate briefly.
- To power off, slide the power switch to the 'OFF' position.

2. Quick Set Programming

The TS20 features a simple Quick Set programming switch for rapid deployment. Refer to the camera's internal display or specific Quick Set labels for available presets (e.g., Photo, Video, Burst). Select the desired mode using the switch.

3. Photo Mode

In Photo Mode, the camera captures still images at 20MP resolution when triggered by motion.

- Ensure the Quick Set switch is set to a Photo preset.
- The camera will automatically take a picture when motion is detected within its 60 ft. range.

4. Video Mode

In Video Mode, the camera records 720P HD video clips when triggered.

- Set the Quick Set switch to a Video preset.
- Video recording duration can be set to 5 or 30 seconds, depending on the Quick Set option selected.
- The camera will record a video clip upon motion detection.

5. Burst Mode

Burst Mode allows the camera to capture multiple photos in quick succession per trigger event.

- If enabled via Quick Set, the camera will take 1 to 3 photos per trigger.
- This feature is useful for capturing more detailed sequences of animal movement.

6. Image Stamp

All captured photos and videos will have a data stamp including the time, date, and moon phase, providing valuable contextual information for your observations.

MAINTENANCE

Cleaning

- Periodically clean the camera lens and IR array with a soft, lint-free cloth. Avoid abrasive materials.
- Wipe the camera exterior with a damp cloth to remove dirt or debris. Do not submerge the camera in water.

Storage

- When not in use for extended periods, remove all batteries to prevent leakage and damage.
- Store the camera in a cool, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

If you encounter issues with your Stealth Cam TS20, refer to the following common solutions:

- **Camera Not Powering On:**
 - Check battery orientation and ensure batteries are fresh.
 - Verify the power switch is in the 'ON' position.
- **No Photos/Videos Captured:**
 - Ensure an SD card is properly inserted and formatted.
 - Check if the camera is in the correct operating mode (Photo/Video).
 - Verify the detection area is clear of obstructions and within the 60 ft. range.
 - Adjust camera sensitivity if available.
- **Poor Image/Video Quality:**
 - Clean the camera lens and IR array.
 - Ensure the camera is stable and not subject to movement.
 - Check for sufficient lighting conditions (for day images) or proper IR function (for night images).

SPECIFICATIONS

Photo Resolution	20 Megapixels
Video Resolution	720P HD
Trigger Speed	0.8 Seconds
Detection & IR Range	60 Feet

LED Flash Type	Infrared
Burst Mode	1-3 Photos Per Trigger
Recovery Time	5 - 120 Seconds
Image Stamp	Time/Date/Moon Phase
Mounting Type	Tree Mount
Power Source	Battery Powered (8x AA, not included)
Water Resistance Level	Water Resistant
Material	Plastic
Item Dimensions (L x W x H)	30.48 x 10.16 x 30.48 cm
Weight	762 g
Model Number	STC-TS20-2PK

WARRANTY AND SUPPORT


For detailed warranty information, product registration, or technical support, please visit the official Stealth Cam website or contact GSM Outdoors customer service. Keep your purchase receipt as proof of purchase for any warranty claims.


Manufacturer: GSM Outdoors

Brand: Stealth Cam

Website: www.stealthcam.com

Related Documents - TS20

	<p><u>Stealth Cam 2024 Catalog: Cellular Trail Cameras & Accessories</u></p> <p>Explore the latest Stealth Cam 2024 lineup of cellular trail cameras, featuring advanced AI subject tagging, on-demand viewing, and robust accessories for optimal outdoor surveillance and hunting.</p>
	<p><u>Stealth Cam STC-E28 Instruction Manual</u></p> <p>Instruction manual for the Stealth Cam STC-E28 digital scouting camera, covering setup, operation, features, and warranty information.</p>

 <p>Fusion 8 Instruction Manual Fusion 8 Instruction Manual Version 1.0 Published on 10/10/2019 Archived on the web at www.chestnutcommand.com</p>	<p><u>Stealth Cam Fusion Instruction Manual: Setup, Features, and Support</u></p> <p>Comprehensive instruction manual for the Stealth Cam Fusion trail camera. Learn about setup, features like remote cellular connection and advanced lowlight sensitivity, camera configuration, and troubleshooting. Includes contact information and warranty details.</p>
 <p>Stealth Cam Digital Video Scouting Camera Model: STC-I540IR Version 1.0 Published on 10/10/2019 Archived on the web at www.chestnutcommand.com</p>	<p><u>Stealth Cam STC-I540IR User's Manual</u></p> <p>User's manual for the Stealth Cam STC-I540IR digital video scouting camera. This guide covers setup, programming, features like infrared capabilities and burst mode, operation, and technical specifications for optimal use.</p>
 <p>STEALTH CAM® INSTRUCTION MANUAL MODEL: STC-GXATW Version 1.0 Published on 10/10/2019 Archived on the web at www.chestnutcommand.com</p>	<p><u>Stealth Cam STC-GXATW Instruction Manual: Setup, Features, and Operation</u></p> <p>This comprehensive instruction manual provides detailed guidance for the Stealth Cam STC-GXATW digital scouting camera. Learn about camera setup, operational modes (PIR Photo, Time Lapse, PIR Video), advanced settings, cellular connectivity, app integration, memory card and battery management, troubleshooting FAQs, and warranty information.</p>
 <p>STEALTH CAM® INSTRUCTION MANUAL MODEL: STC-XV4 Version 1.0 Published on 10/10/2019 Archived on the web at www.chestnutcommand.com</p>	<p><u>Stealth Cam STC-XV4 Instruction Manual</u></p> <p>Comprehensive instruction manual for the Stealth Cam STC-XV4 digital scouting camera, covering setup, programming, operation, maintenance, and warranty information.</p>