

ZenStyle 0661

ZenStyle Fabric Dresser Instruction Manual

Model: 0661

Brand: ZenStyle

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your ZenStyle Fabric Dresser. Please read this manual thoroughly before assembly and use to ensure safe and proper functionality. Keep this manual for future reference.

SAFETY INFORMATION

Always follow basic safety precautions when assembling and using this product to reduce the risk of injury or damage.

- Ensure all parts are present and undamaged before assembly. Do not use if any parts are missing or broken.
- Assemble the dresser on a soft, clean surface to prevent scratches.
- Do not overtighten screws during assembly, as this may damage the material.
- Always attach the anti-tilt device to a wall stud to prevent tipping, especially in homes with children or pets.
- Do not exceed the maximum weight capacity for the desktop (44 lbs) or individual drawers (11 lbs).
- Keep small parts away from children during assembly.
- This product is intended for indoor use only.

PACKAGE CONTENTS

Verify that all components listed below are included in your package:

- 1 x Dresser Storage Tower Frame
- 8 x Fabric Drawers (Dark Grey)
- 1 x Accessory Kit (includes screws, tools, anti-tilt device)
- 1 x Instruction Manual

SETUP AND ASSEMBLY

Follow these steps carefully for proper assembly. It is recommended to have two people for assembly.

Step 1: Unpack and Identify Parts

Carefully remove all components from the packaging. Lay them out on a clean, soft surface to prevent damage. Identify each part by comparing it with the parts list in the accessory kit.



Image: The ZenStyle Fabric Dresser, fully assembled, showcasing its eight dark grey fabric drawers and black metal frame.

Step 2: Assemble the Metal Frame

Connect the metal frame components according to the diagrams provided in the accessory kit. Ensure all screws are finger-tightened initially, then fully tighten once the frame is stable. The frame includes a sturdy steel structure with a lacing bar design for added stability.

Larger Capacity, Organized Storage A Spacious Home For You



Image: Close-up view illustrating the anti-tilt device mechanism and the robust steel frame construction with lacing bar design.

Step 3: Attach the MDF Tabletop

Secure the MDF tabletop to the top of the assembled metal frame using the provided screws. Ensure it is aligned properly before tightening.

Step 4: Install Adjustable Feet

Screw the four adjustable feet into the bottom of the dresser frame. These feet help protect your floor from scratches and allow for leveling on uneven surfaces.

Step 5: Insert Fabric Drawers

Unfold each fabric drawer and insert the bottom panel to give it shape. Slide the assembled drawers into their respective slots in the metal frame. The drawers are designed for easy insertion and removal.



Image: The dresser frame with some fabric drawers removed, illustrating the empty slots where drawers are to be inserted during assembly.

Step 6: Secure Anti-Tilt Device

For safety, attach the anti-tilt device to the back of the dresser and secure it to a wall stud using the provided hardware. This prevents the dresser from accidentally tipping over.

OPERATING INSTRUCTIONS

The ZenStyle Fabric Dresser is designed for versatile storage in various rooms.

- **Drawer Usage:** The eight removable fabric drawers are ideal for organizing clothes, towels, toys, and other household items. Each drawer has an easy-to-pull arch handle for smooth operation.

- **Weight Capacity:** The MDF tabletop can support up to 44 lbs. Each individual fabric drawer has a capacity of 11 lbs. Do not exceed these limits to ensure stability and longevity of the dresser.
- **Placement:** This dresser is suitable for bedrooms, living rooms, closets, entryways, hallways, and nursery rooms. Its compact design helps maximize space utilization.



Image: Two drawers of the dresser are pulled open, revealing organized contents like folded shirts and rolled towels, demonstrating the large storage capacity.



Image: The ZenStyle dresser positioned in a bedroom, complementing the decor and providing functional storage next to a bed and armchair.

MAINTENANCE AND CARE

Proper care will extend the life of your dresser.

- **Cleaning:** Wipe the metal frame and MDF tabletop with a dry cloth. For the fabric drawers, wipe clean with a wet cloth and allow to air dry completely. Do not use harsh chemicals or abrasive cleaners.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- **Environment:** Avoid placing the dresser in direct sunlight or in areas with high humidity to prevent material degradation.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Dresser wobbles	Uneven floor; Loose connections	Adjust the leveling feet at the bottom of the frame. Check and tighten all screws.
Drawers do not slide smoothly	Drawer not fully unfolded; Obstruction in slot	Ensure the drawer's bottom panel is fully inserted and the drawer is properly shaped. Check for any items obstructing the drawer slot.
Missing parts	Packaging error	Contact ZenStyle customer support immediately with your purchase details.

SPECIFICATIONS

- **Model Name:** Dresser
- **Model Number:** 0661
- **Color:** Dark Grey
- **Material:** Metal Frame, MDF Tabletop, Non-woven Synthetic Fabrics
- **Overall Dimensions:** 38.77" W x 11.8" D x 38.77" H




Image: Diagram illustrating the overall dimensions of the dresser (38.77 inches width, 11.8 inches depth, 38.77 inches height) and the weight capacities for the desktop (44 lbs) and individual drawers (11 lbs).

- **Drawer Capacity:** 11 lbs (each drawer)
- **Desktop Capacity:** 44 lbs

- **Net Weight:** 26.1 lbs
- **Assembly Required:** Yes
- **Mounting Type:** Freestanding (with anti-tilt device)
- **Room Type:** Bedroom, Living Room, Closet, Entryway, Hallway, Nursery Room
- **Product Care:** Wipe with Dry Cloth (frame/top), Wipe with Wet Cloth (fabric drawers)
- **Special Features:** Space Saving, Sturdy Steel Frame, Anti-tilt Device, Adjustable Feet

WARRANTY AND SUPPORT

For any questions, missing parts, or issues regarding your ZenStyle Fabric Dresser, please contact ZenStyle customer support. We are committed to providing high-quality products and excellent customer service.

Contact Information:

- Refer to your purchase documentation or the ZenStyle official website for the most current contact methods.
- When contacting support, please provide your product model number (0661) and ASIN (B0CKYM23V2) for faster service.