

OLEVS G5869

OLEVS G5869 Couple Pair Quartz Watches - Instruction Manual

INTRODUCTION

Thank you for choosing the OLEVS G5869 Couple Pair Quartz Watches. This manual provides essential information for the proper setup, operation, maintenance, and troubleshooting of your new watches. Please read these instructions carefully to ensure optimal performance and longevity of your timepiece.



Image: OLEVS G5869 Couple Watches displayed on wrists.

SETUP

Package Contents

Upon opening the gift box, you should find the following items:

- OLEVS G5869 Quartz Watch (2 units)
- Gift Box

Setting the Time and Date

1. **Pull out the crown:** Gently pull the crown (the small knob on the side of the watch) to position 2.
2. **Set the date:** Rotate the crown clockwise or counter-clockwise to adjust the date. Ensure the date changes around midnight, not noon.
3. **Pull out the crown further:** Pull the crown to position 3.
4. **Set the time:** Rotate the crown to set the hour and minute hands. For accurate time setting, align the minute hand with the current minute when a time signal (e.g., from a radio or phone) reaches the exact minute.
5. **Push the crown back:** Once the time and date are set, push the crown back into position 1 (normal operating position) to start the watch movement.



Texture · Big three-hand dial

Ultra-thin to 6.5MM, Simple bar scale surface, with three-dimensional round head spine needle, 6 o'clock position calendar window, embossed English LOGO, highlighting the extraordinary



01

High hardness coated glass mirror

High hardness, scratch-resistant and wear-resistant, durable as new



Image: Close-up view of the OLEVS G5869 watch dial, showing the crown for time and date adjustment.

Strap Adjustment

The OLEVS G5869 features a Milanese steel strap. To adjust the strap length, locate the clasp and use a

small tool (like a thin screwdriver or spring bar tool) to lift the locking mechanism. Slide the clasp along the mesh band to the desired length, then press the locking mechanism back down firmly to secure it. Ensure the clasp is securely fastened before wearing.

PRODUCT PARAMETERS



PRODUCT SIZE

40 33 6.5 6.5

Case diameter(MM) Case thickness(MM)

20 16 23 23

Chain width(MM) Chain length(CM)

Brand model number: OLEVS/5869

Mirror: High hardness coated glass mirror

Watchband: Milanese steel strap

Movement: Japan quartz movement

Waterproof: 30 meters waterproof

Watch weight: Man 54G/ Woman 42G

* Tips: All sizes are manually measured, there is a reasonable error, please prevail in kind

Image: Detailed view of the Milanese steel strap and its adjustable clasp.

OPERATING

Basic Functions

Your OLEVS G5869 watch displays the time (hours, minutes, seconds) and the current date. The Japanese quartz movement ensures precise and accurate timekeeping.

Luminous Feature

The watch hands and hour markers are coated with a luminous material. This material absorbs light during the day and emits a glow in low-light conditions, allowing for visibility in the dark.

Water Resistance (3ATM / 30 Meters)

The OLEVS G5869 watch is water-resistant up to 30 meters (3ATM). This means it is suitable for daily use, such as hand washing, splashes, and rain. However, it is **not recommended** for swimming, showering, diving, or any related underwater activities where water pressure might exceed the watch's resistance capabilities. Avoid operating the crown while the watch is wet.




Image: OLEVS G5869 watches shown with water splashes, illustrating their water resistance for daily activities.

MAINTENANCE

Cleaning Your Watch

To maintain the appearance of your watch, wipe the case and strap regularly with a soft, dry cloth. For the Milanese steel strap, a slightly damp cloth can be used, followed by immediate drying. Avoid using harsh chemicals, solvents, or abrasive cleaners, as these can damage the watch's finish or seals.

Battery Replacement

The watch is powered by a button battery, which typically lasts 2 to 3 years. When the watch stops or runs erratically, it may be time for a battery replacement. It is recommended to have the battery replaced by a qualified watch technician to ensure the water resistance seal is properly maintained.

Storage

When not wearing your watch for extended periods, store it in a cool, dry place away from direct sunlight, extreme temperatures, and strong magnetic fields. The original gift box is suitable for storage.

Water Resistance Care

Regularly check the crown to ensure it is fully pushed in to maintain water resistance. If the watch is exposed to saltwater, rinse it gently with fresh water and dry it immediately.

TROUBLESHOOTING

- **Watch not running:** Ensure the crown is fully pushed into position 1. If it still does not run, the battery may need replacement.
- **Date not changing correctly:** Check if the date was set during the watch's AM hours instead of PM, causing it to change at noon. Reset the time and date, ensuring the watch passes 12 AM for the date change.
- **Condensation inside the watch:** This indicates a loss of water resistance. Immediately contact customer support or a professional watch repair service. Do not attempt to open the watch yourself.
- **Strap discomfort:** Re-adjust the Milanese strap to ensure it is not too tight or too loose. Refer to the 'Strap Adjustment' section.

SPECIFICATIONS

Feature	Specification
Brand	OLEVS
Model Number	G5869
Movement Type	Japanese Quartz Movement
Water Resistance	30 Meters (3ATM)
Case Diameter (Men's)	40 Millimeters
Case Diameter (Women's)	33 Millimeters
Case Thickness	6.5 Millimeters
Band Width (Men's)	20 Millimeters
Band Width (Women's)	16 Millimeters
Band Length	16.8 - 21.7 Centimeters (Adjustable)
Mirror Material	High Hardness Coated Glass
Band Material	Milanese Steel Strap
Power Source	Battery Powered
Special Features	Luminous Hands, Date Display, Ultra-Thin Design




Image: Visual representation of OLEVS G5869 product parameters including case diameter, thickness, and band dimensions.

WARRANTY AND SUPPORT

Warranty Information

Your OLEVS G5869 Couple Pair Quartz Watches come with a **ONE YEAR WARRANTY** from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage resulting from improper use, accidents, unauthorized repairs, or normal wear and tear.

Customer Support

If you encounter any issues with your watch or have questions not covered in this manual, please contact the seller or manufacturer's customer support. Provide your purchase details and a clear description of the issue for prompt assistance.