

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

> [AGOAL](#) /

> AGOAL 2500W Handheld Pressurized Steam Cleaner Instruction Manual

AGOAL 110

AGOAL 2500W Handheld Pressurized Steam Cleaner Instruction Manual

Model: 110

1. INTRODUCTION AND OVERVIEW

The AGOAL 2500W Handheld Pressurized Steam Cleaner is designed for deep cleaning various surfaces around your home and car. It utilizes hot steam up to 120°C (248°F) to effectively remove grease, grime, dust, and stains without the need for harsh chemicals. This manual provides essential information for safe and efficient operation of your steam cleaner.



Figure 1: AGOAL 2500W Handheld Pressurized Steam Cleaner in use.

2. SAFETY INSTRUCTIONS

- **Warm Tip:** Please do not aim the steam nozzle at people, animals, or electrical goods with this product.
- If you need to replace accessories, ensure the air vent is completely stopped and the unit has cooled down to prevent burns.
- Always use distilled or demineralized water to prevent mineral buildup and prolong the life of the appliance.
- Do not overfill the water tank.
- Keep the appliance out of reach of children.
- Unplug the appliance when not in use or before performing maintenance.

3. PACKAGE CONTENTS

Your AGOAL Handheld Pressurized Steam Cleaner package includes the following items:

- 1 x Steam Cleaning Machine (Main Unit)
- 1 x Extended Elbow Nozzle
- 3 x Brush Heads (Small Brush, Small Steel Brush, Large Brush)
- Power Cord
- Steam Tube



Figure 2: Included accessories and main unit.



Figure 3: Close-up of various brush heads and extended nozzle.

4. PRODUCT FEATURES

- **High Power:** 2500W heating element for rapid steam generation.
- **Fast Heating:** Produces hot steam (up to 120°C / 248°F) in approximately 15 seconds.
- **Large Water Tank:** 1L capacity for extended cleaning sessions (up to 1 hour working time).
- **Adjustable Steam Levels:** Features a dial to control the amount of steam output.
- **Versatile Attachments:** Comes with 3 different brush heads and an extended elbow nozzle for various cleaning tasks.
- **Portable Design:** Lightweight and handheld with a 2.5m power cord and 2.2m steam tube for increased mobility.



Figure 4: Long steam tube and power cord for extended reach.

5. SETUP

1. **Prepare the Unit:** Place the steam cleaner on a stable, flat surface.

2. **Fill the Water Tank:** Unscrew the water tank cap. Carefully pour clean water into the 1L tank. Do not overfill. Securely close the cap.
3. **Attach Desired Nozzle:** Select the appropriate brush head or extended elbow nozzle for your cleaning task. Screw it firmly onto the steam gun.
4. **Connect Power:** Plug the power cord into a standard 110V electrical outlet.

Your browser does not support the video tag.

Video 1: Demonstrates filling the water tank, attaching accessories, and powering on the steam cleaner.

6. OPERATING INSTRUCTIONS

1. **Power On:** Flip the main power switch to the 'ON' position. The indicator light will illuminate.
2. **Heat Up:** Allow approximately 15 seconds for the unit to heat up and generate steam.
3. **Adjust Steam Level:** Use the rotary dial on the top of the unit to select your desired steam intensity (6 levels available).
4. **Begin Cleaning:** Point the nozzle at the surface to be cleaned. Press the steam trigger on the handle to release steam. Move the nozzle slowly over the surface.
5. **For Stubborn Stains:** Use the appropriate brush head and apply direct steam. For best results, keep the sprayer head close to the machine as temperature decreases with distance.
6. **After Use:** Release the steam trigger, turn off the main power switch, and unplug the unit.



Figure 5: Visual guide for operating the steam cleaner.

Your browser does not support the video tag.

Video 2: Shows the steam cleaner in action, demonstrating steam output and various cleaning applications.



MULTIPLE SCENARIO USAGE



Figure 6: Multiple scenario usage examples.

7. MAINTENANCE

- **Empty Water Tank:** After each use, ensure the unit is cool, then empty any remaining water from the tank.
- **Clean Accessories:** Wash brush heads and nozzles with water and mild soap. Allow them to dry completely before storing.
- **Descaling:** To prevent mineral buildup, especially if using tap water, periodically descale the unit. Consult the full manual for detailed descaling instructions.
- **Storage:** Store the steam cleaner and its accessories in a cool, dry place.

8. TROUBLESHOOTING

If you encounter any issues with your AGOAL steam cleaner, please refer to the following common

problems and solutions:

Problem	Possible Cause	Solution
No steam or low steam output	Water tank empty; Unit not heated sufficiently; Nozzle blocked.	Refill water tank; Allow 15-20 seconds for heating; Clean nozzle with the provided needle.
Water leaking from nozzle	Nozzle not securely attached; Unit not fully heated.	Ensure nozzle is tightly screwed on; Allow unit to fully heat up before use.
Unit not turning on	Power cord not plugged in; Power switch off.	Check power connection; Ensure power switch is in 'ON' position.

If the problem persists, please contact customer support.

9. SPECIFICATIONS

- **Brand:** AGOAL
- **Model Name:** Handheld Steam Cleaner
- **Item Model Number:** 110
- **Wattage:** 2500 watts
- **Voltage:** 110V
- **Tank Volume:** 1000 Milliliters (1L)
- **Maximum Temperature:** 248 Degrees Fahrenheit (120°C)
- **Form Factor:** Handheld
- **Power Source:** Corded Electric
- **Item Weight:** 1.67 Kilograms (3.67 pounds)
- **Package Dimensions:** 9.81 x 7.95 x 6.93 inches
- **Color:** Red



Product specific dimensions



Figure 7: Product dimensions.

10. WARRANTY AND SUPPORT

If you have any questions or experience issues with your AGOAL Handheld Pressurized Steam Cleaner within 60 days of purchase, you are eligible for a replacement. Please contact the seller or refer to your purchase documentation for specific warranty claim procedures.