

[Manuals.plus](#) /

› [Shadowhawk](#) /

› Shadowhawk S1695 Flashlight User Manual

Shadowhawk AE-S1695

Shadowhawk S1695 Flashlight User Manual

Model: AE-S1695

1. INTRODUCTION

Thank you for choosing the Shadowhawk S1695 Rechargeable LED Flashlight. This powerful and versatile torch is designed for various applications, including camping, hiking, emergency situations, and general outdoor activities. This manual provides detailed instructions on how to set up, operate, maintain, and troubleshoot your flashlight to ensure optimal performance and longevity.

2. SAFETY INFORMATION

Please read and understand all safety warnings and instructions before using this product. Failure to follow these guidelines may result in injury or damage to the device.

- **Do Not Stare Directly into Light:** The flashlight emits a very bright beam. Avoid direct eye exposure to prevent temporary vision impairment or permanent eye damage.
- **Keep Out of Reach of Children:** This product is not a toy. Store it in a secure location away from children.
- **Battery Safety:**
 - Use only the specified rechargeable battery and AAA batteries.
 - Do not mix old and new batteries, or different types of batteries.
 - Do not dispose of batteries in fire; they may explode.
 - If the flashlight will not be used for an extended period, remove the batteries to prevent leakage.
- **Operating Temperature:** Avoid using the flashlight in extremely high or low temperatures.
- **Disassembly:** Do not attempt to disassemble or modify the flashlight. This will void the warranty and may cause damage.

3. PACKAGE CONTENTS

Carefully unpack your Shadowhawk S1695 Flashlight and verify that all items listed below are included:

- 1x Shadowhawk S1695 LED Super Bright Torch Light
- 1x Rechargeable Battery (pre-installed or separate)
- 1x USB Charging Cable
- 1x AAA Battery Holder and Plastic Tube

- 3x AAA Batteries
- 1x Lanyard
- 1x Holster
- 1x Instruction Manual
- 1x Gift Box



Image 3.1: The Shadowhawk S1695 flashlight kit, including the flashlight, rechargeable battery, USB cable, AAA battery holder, and protective case.

4. SETUP

4.1 Battery Installation

The Shadowhawk S1695 flashlight primarily uses a rechargeable Lithium Ion battery. It also supports AAA batteries as an alternative.

1. Unscrew the tail cap of the flashlight by turning it counter-clockwise.
2. **For Rechargeable Battery:** Insert the included rechargeable Lithium Ion battery with the positive (+) end facing

towards the head of the flashlight.

3. **For AAA Batteries:** If using AAA batteries, place three AAA batteries into the provided AAA battery holder, ensuring correct polarity. Insert the holder into the flashlight with the positive (+) end of the holder facing towards the head.
4. Screw the tail cap back on clockwise until it is securely tightened.

4.2 Initial Charging

Before first use, fully charge the rechargeable battery. The flashlight features a built-in USB-C charging port.

1. Locate the USB-C charging port on the flashlight (usually under a protective cover).
2. Connect the provided USB charging cable to the flashlight's USB-C port.
3. Connect the other end of the USB cable to a compatible USB power source (e.g., wall adapter, computer USB port, power bank).
4. The LCD power display will show the charging progress. Charge until the display indicates 100%.
5. Once fully charged, disconnect the cable and replace the protective cover over the USB-C port to maintain water resistance.

USB-C Fast Charging

no need to change batteries frequently



USB Output

used as emergency power supply



Image 4.1: The flashlight features a USB-C input for charging and a USB-A output for power bank functionality.



Image 4.2: The flashlight is equipped with an upgraded rechargeable battery offering multi-safety protection and extended runtime.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

Press the power button located on the body of the flashlight to turn it on. Press it again to cycle through modes or turn it off.

5.2 Mode Selection

The Shadowhawk S1695 features 5 lighting modes:

- **High:** Maximum brightness for powerful illumination.
- **Medium:** Balanced brightness for general use.
- **Low:** Lower brightness for extended runtime or close-range tasks.


- **Strobe:** Flashing light for signaling or disorientation.
- **SOS:** International Morse code signal for emergencies.

To cycle through modes, short press the power button. The brightness changes gradually to protect your eyes. To turn off the flashlight instantly from any mode, press and hold the power button for approximately 3 seconds.


5 Light Modes & 3-Second Instant Off

can meet your different lighting needs


High



Medium



Low



Strobe



SOS





Long Press and hold for **3s** to turn off the torch in any mode without cycling all modes.

Image 5.1: The flashlight offers five distinct lighting modes to suit various needs.

5.3 Zoom Function

The flashlight features a zoomable head to adjust the beam from a wide floodlight to a focused spotlight.

- **To adjust focus:** Gently pull the head of the flashlight outwards to narrow the beam into a spotlight for long-range illumination.
- **To widen beam:** Push the head inwards to expand the beam into a floodlight for wider area illumination.

Zoomable Focus & Long Range

beam range up to 1200m/3937ft



Floodlights for wider range

Pull/push the head to adjust the focus

Image 5.2: Adjust the beam from a wide floodlight to a focused spotlight by pulling or pushing the flashlight head.

5.4 LCD Power Display

The integrated LCD screen displays the remaining battery percentage, allowing you to monitor the power level at a glance.



Image 5.3: The upgraded LCD digital display provides an accurate percentage of remaining power.

5.5 Power Bank Function (USB Output)

The Shadowhawk S1695 can also function as an emergency power bank to charge small electronic devices.

1. Locate the USB-A output port (usually next to the USB-C input).
2. Connect your device's charging cable to the flashlight's USB-A output port.
3. The flashlight will begin charging your device.
4. Disconnect when charging is complete or when the flashlight's battery is low.



Image 5.4: The flashlight's USB output can be used as an emergency power supply for mobile devices.

6. MAINTENANCE

6.1 Cleaning

- Wipe the flashlight body with a clean, soft cloth.
- For stubborn dirt, use a slightly damp cloth and then dry thoroughly.
- Do not use abrasive cleaners or solvents, as they may damage the finish.

6.2 Storage

- Store the flashlight in a cool, dry place away from direct sunlight and extreme temperatures.
- If storing for an extended period (more than 3 months), remove the batteries to prevent leakage and charge the rechargeable battery to approximately 50% capacity.

6.3 Battery Care

- Recharge the battery regularly, even if not in use, to maintain its lifespan.
- Avoid fully discharging the battery frequently.

7. TROUBLESHOOTING

If you encounter issues with your Shadowhawk S1695 Flashlight, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Flashlight does not turn on.	Low or dead battery. Battery inserted incorrectly. Loose tail cap.	Charge the battery. Check battery polarity. Tighten the tail cap.
Light is dim or flickers.	Low battery. Loose connections.	Recharge the battery. Ensure tail cap is tight and battery is seated correctly.
Flashlight not charging.	Faulty USB cable or power source. Charging port obstruction.	Try a different USB cable and power source. Check charging port for debris.
Cannot change modes.	Button malfunction.	Ensure button is not stuck. If issue persists, contact support.

If the problem persists after trying these solutions, please contact Shadowhawk customer support for further assistance.

8. SPECIFICATIONS

The following table outlines the key specifications of the Shadowhawk S1695 Flashlight:

Super Bright 20000 Lumens

high lumens provide powerful illumination

Ours
Advanced Beads – Brighter & Stable

Others
Basic Beads – Weak & Unstable

Upgraded **30W XHM77.2** LED Chip

Image 8.1: The Shadowhawk S1695 features a powerful 20000 lumens output with an upgraded XHM77.2 LED chip.

Feature	Detail
Model Number	AE-S1695
Light Source	XHM77.2 LED Chip
Brightness	Up to 20000 Lumens
Light Modes	High, Medium, Low, Strobe, SOS
Beam Distance	Up to 1000 meters (3937 feet)
Power Source	Rechargeable Lithium Ion Battery (included), 3x AAA Batteries (included)
Runtime	Up to 12 hours (Low mode)
Charging Port	USB-C Input

Feature	Detail
Output Port	USB-A Output (for power bank function)
Material	Aviation Grade Aluminum Alloy
Water Resistance	IP67 Waterproof
Impact Resistance	Up to 10 feet
Dimensions	6.69 x 1.97 x 1.38 inches
Weight	1.23 pounds

9. WARRANTY AND SUPPORT

Shadowhawk products are manufactured with high-quality materials and undergo rigorous quality control. For any questions, concerns, or technical support regarding your Shadowhawk S1695 Flashlight, please refer to the contact information provided with your purchase or visit the official Shadowhawk website. Please retain your proof of purchase for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CKZ2J1ZM>

More documents and user manuals: <https://manuals.plus/>