Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Gizoon AP40

Gizoon 6 Drawer Dresser (Model AP40) Instruction Manual

Model: AP40

1. Product Overview

The Gizoon 6 Drawer Dresser is designed to provide ample storage and complement various room aesthetics. This modern wood dresser features six spacious drawers and a sturdy top surface, suitable for bedrooms, hallways, entryways, or living rooms.



Image: The Gizoon 6 Drawer Dresser, white with black metal handles, positioned in a bedroom next to a gold clothing rack.

- **Dimensions:** 47"L x 16"W x 30"H, offering generous storage capacity.
- **Storage:** Six extra-wide and deep drawers for organizing clothing, accessories, and other essentials.
- **Design:** Features easy-to-pull black metal handles and smooth-gliding drawer slides for convenient use. The paint-free board surface is smooth, wear-resistant, and easy to clean.
- **Versatility:** Can be used as a dressing table, console, storage solution, or even a TV stand.

2. Safety Information

To ensure safe use of your Gizoon dresser, please adhere to the following guidelines:

- **Anti-Tip Device:** Always install the included anti-tip device to secure the dresser to a wall. This prevents accidental tipping, which can cause serious injury.
- **Weight Capacity:** The top surface can support up to 50 pounds. Each drawer has a weight capacity of 30 pounds. Do not exceed these limits.

- **Even Weight Distribution:** Distribute weight evenly across drawers and the top surface to maintain stability.
- **Children Safety:** Do not allow children to climb on or play with the dresser. Keep heavy items in lower drawers.
- **Assembly:** Ensure all fasteners are securely tightened during assembly. Periodically check and re-tighten as needed.



Image: A detailed view highlighting the anti-tipping device installation point and the elegant, sturdy base design of the dresser.

3. Package Contents

Before beginning assembly, please verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Dresser Panels (Top, Bottom, Sides, Back)
- Drawer Fronts, Sides, and Back Panels
- Drawer Bottoms
- Black Metal Handles

- Drawer Slides (Rails)
- Assembly Hardware (Screws, Dowels, Cam Locks, etc.)
- Anti-Tip Safety Kit
- Instruction Manual

4. Assembly Instructions

Assembly is designed to be straightforward. Please follow these general steps. A detailed installation manual with labeled components is included in your package.

1. **Prepare the Area:** Clear a spacious, clean, and soft surface (like a carpet) to prevent scratching the furniture during assembly.
2. **Identify Parts:** Lay out all components and hardware. Match them with the parts list in the detailed manual.
3. **Assemble the Main Frame:** Connect the side panels to the top and bottom panels using the provided hardware. Ensure all connections are secure.
4. **Install Drawer Slides:** Attach the drawer slides to the inner sides of the dresser frame according to the manual's diagrams. Ensure they are level and correctly oriented.
5. **Assemble Drawers:** Construct each drawer by connecting the front, back, and side panels, then inserting the drawer bottom. Attach the remaining drawer slide components to the drawer sides.
6. **Attach Handles:** Secure the black metal handles to the front of each assembled drawer.
7. **Insert Drawers:** Carefully slide each assembled drawer into its corresponding slot in the dresser frame.
8. **Install Anti-Tip Device:** Securely attach the anti-tip device to the back of the dresser and to a wall stud using the provided hardware. This step is crucial for safety.



Image: Diagram illustrating the overall dimensions of the dresser (47"W x 30"H x 16"D) and individual drawer dimensions (21.3"W x 13.3"D x 5.2"H), along with weight capacities for the top board (50 lbs) and each drawer (30 lbs).

5. Operating Instructions

Using your Gizoon 6 Drawer Dresser is simple and intuitive:

- **Opening and Closing Drawers:** Use the black metal handles to smoothly pull drawers open and push them closed. The smooth-gliding drawer slides ensure effortless operation.
- **Loading Drawers:** Place items inside the drawers, ensuring not to exceed the 30-pound weight limit per drawer. Distribute items evenly to prevent strain on the drawer slides.
- **Top Surface Use:** The top surface can hold up to 50 pounds. It is suitable for decorative items, lamps, or media equipment. Avoid placing excessively heavy or unstable objects on top.



Image: An aerial view of the white 6-drawer dresser with several drawers pulled open, revealing various organized items such as clothing, accessories, and small boxes.



Image: Detailed close-up shots showing the ergonomic design of the easy-pull black metal handles and the smooth operation of the drawer rails.

6. Maintenance

Proper care will extend the life and appearance of your dresser:

- **Cleaning:** Wipe the surface with a dry, soft cloth. For stubborn stains, a slightly damp cloth can be used, followed immediately by a dry cloth. Avoid harsh chemicals or abrasive cleaners.
- **Dusting:** Regularly dust the dresser to prevent buildup.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they are tight. Re-tighten if necessary to maintain structural integrity.
- **Drawer Slides:** If drawers become stiff, clean the drawer slides with a dry cloth. Avoid lubricating with oil, as it can attract dust and debris.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fading or discoloration.

7. Troubleshooting

If you encounter any issues with your dresser, refer to the following common solutions:

- **Drawers Not Sliding Smoothly:**
  - Check if the drawer slides are properly aligned and free of obstructions.
  - Ensure all screws securing the slides to both the drawer and the dresser frame are tight.
  - Verify that the drawer is not overloaded, exceeding its weight capacity.
- **Dresser Wobbles:**
  - Confirm that all assembly fasteners are fully tightened.
  - Ensure the dresser is placed on a level surface. If not, use furniture levelers or shims under the feet.
  - Verify the anti-tip device is securely installed.
- **Missing or Damaged Parts:**
  - Carefully re-check the packaging for any overlooked components.
  - Contact Gizoon customer support with your purchase details and the specific part number(s) needed.

8. Specifications

Feature	Detail
Brand	Gizoon
Model Name	6 drawer dresser (AP40)
Product Dimensions	16"D x 47"W x 30"H
Color	White
Material	Wood, Metal
Finish Type	Painted
Number of Drawers	6
Top Board Weight Capacity	50 pounds
Drawer Weight Capacity	30 pounds (each)
Assembly Required	Yes
Product Care Instructions	Wipe with Dry Cloth

9. Warranty Information

Gizoon products are manufactured with quality and durability in mind. This product is covered by a manufacturer's warranty against defects in materials and workmanship. Please refer to your purchase documentation or contact customer support for specific warranty terms and conditions.

10. Customer Support

For any questions, assistance with assembly, or to report missing/damaged parts, please contact Gizoon customer support. Our team is available to provide warm, friendly, and professional service.

- **Online Support:** Visit the official Gizoon website for FAQs and support resources.
- **Email:** Refer to your purchase invoice or product packaging for customer service email.
- **Phone:** Refer to your purchase invoice or product packaging for customer service phone number.

© 2024 Gizoon. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CKZ65QN2

More documents and user manuals: **https://manuals.plus/**