gorsun E97

gorsun Wireless Bluetooth Headphones User Manual

Model: E97
Brand: gorsun

Introduction

Thank you for choosing the gorsun E97 Wireless Bluetooth Headphones. These over-ear headphones are designed to provide a high-fidelity audio experience with deep bass, extended playtime, and versatile connectivity. This manual will guide you through the setup, operation, and maintenance of your new headphones.



Image: The gorsun E97 Wireless Bluetooth Headphones in blue, showcasing their sleek over-ear design.

What's in the Box

Please check the package contents to ensure all items are present:

- gorsun E97 Wireless Bluetooth Headphones
- USB C Cable
- User Manual

Product Overview

Familiarize yourself with the key components of your gorsun E97 headphones.



Image: A close-up of the headphone earcup, highlighting its ergonomic design, 90-degree rotation, adjustable headband, and foldable mechanism for portability.

The headphones feature soft memory foam ear cups and an adjustable, stretchable headband for comfortable all-day wear. They are designed to be lightweight and foldable for easy storage and transport.




Image: An exploded view illustrating the internal high-definition audio components, designed for balanced and crystal-clear sound.

Setup

Charging the Headphones

Before first use, fully charge your headphones.

1. Connect the provided USB-C cable to the charging port on the headphones.
2. Connect the other end of the cable to a USB power source (e.g., computer, wall adapter).
3. The indicator light will show charging status (refer to the specific light behavior in your quick start guide).
4. A full charge takes approximately 2 hours and provides up to 55 hours of playtime.



Image: Close-up of the USB Type-C charging port on the headphone, indicating modern charging compatibility.

Bluetooth Pairing

Pair your headphones with your device for wireless audio.

1. Ensure the headphones are charged and powered off.
2. Press and hold the power button until the indicator light flashes, indicating pairing mode.
3. On your device (PC, phone, laptop), enable Bluetooth and search for available devices.
4. Select "gorsun E97" from the list of devices.
5. Once connected, the indicator light will change (refer to your quick start guide for specific light behavior).

The headphones utilize advanced Bluetooth 5.3 technology, ensuring a stable connection with a transmission range of up to 33 feet (10 meters).



Image: The gorsun E97 headphones positioned next to a smartphone, illustrating Bluetooth 5.3 connectivity and a 10m distance range for stereo sound.

Operating Instructions

Sound Modes (EQ)

Your gorsun E97 headphones offer three distinct EQ sound modes to customize your listening experience:

- **Bass Mode:** Enhances low frequencies for a powerful, thumping sound.
- **Voice Mode:** Optimizes mid-range frequencies for clear vocal reproduction.
- **Pop Mode:** Provides a balanced sound profile suitable for general music listening.

To switch between these modes, locate and press the EQ button on the headphone earcup.



Image: The gorsun E97 headphones with the EQ button clearly marked, demonstrating the three available sound modes: Pop, Bass, and Vocal.

Making Calls

The headphones feature a built-in microphone for hands-free calls.

- To answer an incoming call, press the multi-function button once.
- To end a call, press the multi-function button once again.

- To reject an incoming call, press and hold the multi-function button for 2 seconds.

Your browser does not support the video tag.

Video: An official product video demonstrating the features of the gorsun E97 Wireless Bluetooth Headphones, including their design, sound modes, and connectivity options.

Wired Connection

For situations where Bluetooth is not available or preferred, you can use the included 3.5mm audio cable for a wired connection.

1. Plug one end of the 3.5mm audio cable into the audio jack on the headphones.
2. Plug the other end into the 3.5mm audio output of your device.
3. The headphones will automatically switch to wired mode.



Image: Illustration showing the flexibility of the gorsun E97 headphones, offering both wireless Bluetooth freedom and a wired backup option via a 3.5mm audio jack.

Maintenance

To ensure the longevity and optimal performance of your gorsun E97 headphones, please follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the headphones. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use, store the headphones in a cool, dry place, away from direct sunlight and extreme temperatures. Utilize their foldable design for compact storage.
- **Water Resistance:** These headphones are not water resistant. Avoid exposure to liquids, moisture, or humidity.
- **Handling:** Avoid dropping the headphones or subjecting them to strong impacts.

Troubleshooting

If you encounter any issues with your headphones, please refer to the following common solutions:

Problem	Possible Solution
Headphones won't turn on	Ensure the headphones are fully charged.
Cannot pair with device	Ensure Bluetooth is enabled on your device. Make sure headphones are in pairing mode (flashing indicator light). Move headphones closer to your device (within 33 feet/10 meters). Forget the device in your phone's Bluetooth settings and try pairing again.
No sound or low volume	Adjust volume on both headphones and your connected device. Ensure headphones are properly connected (Bluetooth or wired). Try playing different audio sources.

Problem	Possible Solution
Poor call quality	Ensure the microphone is not obstructed. Move to an area with less background noise. Check Bluetooth connection stability.

Specifications

Feature	Detail
Model Name	GS-E97
Connectivity Technology	Wireless (Bluetooth 5.3)
Bluetooth Range	10 Meters (33 feet)
Headphones Jack	3.5 mm Jack
Battery Life	55 Hours
Charging Time	2 Hours
Control Type	Media Control, Touch
Earpiece Shape	Over Ear
Material	Acrylonitrile Butadiene Styrene (ABS)
Item Weight	14 ounces
Frequency Range	20 Hz - 20,000 Hz
Water Resistance Level	Not Water Resistant

Warranty and Support

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official gorsun website.
You can also visit the gorsun Store on Amazon for more product details and assistance.

© 2023 gorsun. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question