

[manuals.plus](#) /› [Joyway](#) /› [Joyway 24 Inch Checked Luggage Set Instruction Manual \(Model TR008\)](#)

Joyway TR008

Joyway 24 Inch Checked Luggage Set Instruction Manual

Model: TR008

1. INTRODUCTION

This manual provides detailed instructions for the Joyway 24 Inch Checked Luggage Set, Model TR008. Please read this manual thoroughly before using your luggage set to ensure proper handling and care. This set includes one 24-inch checked luggage, one travel bag, and one toiletry bag, designed for convenient and secure travel.

2. PACKAGE CONTENTS

Upon unpacking, please verify that all items listed below are present:

- 1 x Joyway 24 Inch Checked Luggage
- 1 x Joyway Travel Bag
- 1 x Joyway Toiletry Bag



Image 2.1: The complete Joyway 3-piece luggage set, including the 24-inch checked suitcase, a matching travel bag, and a toiletry bag.

3. KEY FEATURES

The Joyway luggage set is designed with several features to enhance your travel experience:

- **Durable Construction:** Made from lightweight and durable ABS hard shell material.
- **Expandable Capacity:** The main luggage features an expandable layer, providing approximately 15% more packing space.
- **TSA-Approved Lock:** Integrated TSA combination lock for enhanced security and ease of inspection.
- **Smooth Mobility:** Equipped with 360-degree multi-directional spinner wheels for effortless movement.
- **Ergonomic Handle:** Sturdy aluminum telescopic handle for comfortable maneuvering.
- **Organized Interior:** Features zipper dividers, cross-organizer pockets, and double-layered YKK zippers for efficient packing.
- **Accessory Bags:** Includes a travel bag and a toiletry bag for additional organization.



Image 3.1: Diagram highlighting key features such as the sturdy ergonomic aluminum telescopic handle, lightweight and durable ABS hard shell, TSA-approved lock, soft rubber handle, and smooth silent spinner wheels.

Expansion Layer

Provides more Capacity



Image 3.2: Illustration demonstrating the luggage's expansion layer, showing the suitcase before and after expansion, providing additional capacity.



Double Layer YKK Zippers

Strong X-type Elastic Strap

Closed Mesh Pockets

Image 3.3: View of the luggage interior, showcasing the double-layer YKK zippers, strong X-type elastic straps, and closed mesh pockets for organized packing.

4. SETUP

4.1 Setting the TSA Combination Lock

Your Joyway luggage is equipped with a TSA-approved combination lock. The default combination is 0-0-0. To set your personal combination, follow these steps:

1. Ensure the dials are set to the original combination (0-0-0).
2. Locate the reset button (a small, recessed button, usually on the side of the lock). Use a pen or a pointed tool to press and hold this button until you hear a "click" sound.
3. While holding the reset button, set your desired 3-digit combination by turning the dials. For example, 8-8-8.
4. Release the reset button. You will hear another "click" sound, indicating your new combination is set.

Test your new combination by scrambling the dials and then entering your set combination to open the lock. If you wish to reset the number again, repeat the steps above.



Image 4.1: Visual guide for setting the TSA combination lock, showing the steps from default 0-0-0 to setting a new combination.

5. OPERATING INSTRUCTIONS

5.1 Using the Telescopic Handle

To extend the telescopic handle, press the button located on the top of the handle and pull upwards. Release the button at your desired height. To retract, press the button and push the handle downwards until it is fully nested.

5.2 Maneuvering with Spinner Wheels

The 360-degree spinner wheels allow for smooth and easy movement in any direction. You can push, pull, or roll the luggage alongside you with minimal effort. For optimal performance, ensure the luggage is upright when rolling.



Wear Resistance



360° (Multi-directional Double Spinner Wheels)



Move Easily (Smooth Rolling Wheels)

Image 5.1: Close-up view of the multi-directional double spinner wheels, emphasizing their wear resistance and smooth rolling capability.

5.3 Expanding the Luggage

To expand the main luggage, locate the expansion zipper running along the perimeter of the suitcase. Unzip this zipper to release the additional fabric, increasing the internal volume for more packing space.

5.4 Attaching the Travel Bag

The travel bag is designed with a sleeve on its back that allows it to be securely attached over the telescopic handle of the checked luggage. This feature enables easy transport of both bags together.

bring your assistant

Pair it with the matching duffel bag and toiletry bag for a quick trip



Image 5.2: Illustration showing how the travel bag can be easily attached to the telescopic handle of the main luggage, providing extra room and convenience.

6. MAINTENANCE

6.1 Cleaning the Exterior

To clean the hard shell exterior, wipe with a soft cloth dampened with mild soap and water. Avoid abrasive cleaners or solvents that could damage the finish. Dry thoroughly after cleaning.

6.2 Cleaning the Interior

For the interior lining, spot clean with a damp cloth and mild detergent. Allow to air dry completely before closing the luggage or storing items inside.

6.3 Wheel and Zipper Care

Periodically check the spinner wheels for any debris and clean as needed. For zippers, ensure they are free from obstructions. Lubricate with a silicone-based spray if they become stiff.

7. TROUBLESHOOTING

- **Lock not opening:** Ensure you are using the correct combination. If you forgot your combination, you may need to contact customer support for assistance or a professional locksmith.

- Wheels not rolling smoothly:** Check for hair, lint, or debris caught in the wheel mechanisms. Clean thoroughly. If the issue persists, the wheels may require professional inspection.
- Telescopic handle sticking:** Ensure no items are obstructing the handle mechanism inside the luggage. Apply a small amount of silicone spray to the handle rails if it feels stiff.
- Zippers catching:** Check for fabric caught in the zipper teeth. Gently pull the fabric away and try zipping again. Avoid forcing the zipper.

8. SPECIFICATIONS

Feature	Detail
Product Dimensions	17.3 x 11.5 x 26 inches
Item Weight	7.3 Pounds
Model Number	TR008
Material	ABS Hard Shell
Wheel Type	360-degree Spinner Wheels
Lock Type	TSA Combination Lock


9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact Joyway customer service directly. Keep your purchase receipt as proof of purchase.

For further assistance, please visit the official Joyway website or contact their customer support channels.

© 2025 Joyway. All rights reserved.

Related Documents - TR008

	<p>Joyway Luggage Combination Lock Instructions</p> <p>Step-by-step guide on how to set and use the combination lock for Joyway carry-on luggage and suitcases.</p>
	<p>Tridon Automotive Relay Catalogue: Flasher and General Relays</p> <p>Comprehensive catalogue of Tridon automotive relays, featuring flasher relays (electro-mechanical, electronic, thermal, LED) and general relays. Includes detailed product specifications, pin identification guides, application lists, packaging information, and cross-reference guides for automotive electrical systems.</p>

