

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [ODK](#) /
- › [ODK L-Shaped Gaming Desk Instruction Manual, Model ZJZ-SZWJ](#)

ODK ZJZ-SZWJ

ODK L-Shaped Gaming Desk Instruction Manual

Model: ZJZ-SZWJ

INTRODUCTION

Thank you for choosing the ODK L-Shaped Gaming Desk. This manual provides essential information for the safe assembly, operation, and maintenance of your new desk. Please read these instructions carefully before assembly and retain them for future reference.

SAFETY INFORMATION

- Ensure all parts are present and undamaged before assembly. Do not proceed with assembly if any parts are missing or damaged.
- Assemble the desk on a soft, clean surface to prevent scratches.
- Always use the correct tools as specified in the assembly instructions.
- Do not overtighten screws during assembly to avoid damaging the material.
- Keep small parts away from children to prevent choking hazards.
- Place the desk on a level surface to ensure stability. Adjustable feet are provided for uneven floors.
- Do not exceed the maximum weight capacity of the desk surfaces and shelves.
- Avoid direct exposure to sunlight and moisture to prolong the product's lifespan.

PACKAGE CONTENTS

Before beginning assembly, please verify that all components listed below are included in your package:

- L-shaped desktop panels
- Metal frame components

- Adjustable monitor stand
- Two-tier storage shelves
- PC tower stand/compartment
- 2 Iron hooks
- Assembly hardware (screws, bolts, Allen wrench)
- Adjustable leg pads

SETUP AND ASSEMBLY

Follow these steps for proper assembly. It is recommended to have two people for assembly.

1. **Unpack and Identify Parts:** Carefully unpack all components and lay them out on a clean, soft surface. Refer to the parts list to ensure everything is present.
2. **Assemble the Metal Frame:** Begin by connecting the main metal frame components using the provided screws and tools. Do not fully tighten screws until all parts are aligned.
3. **Attach Desktop Panels:** Secure the L-shaped desktop panels to the assembled metal frame. Ensure the panels are correctly oriented.
4. **Install Storage Shelves:** Attach the two-tier storage shelves and the PC tower stand to the designated areas of the desk frame.
5. **Mount Monitor Stand:** Place the adjustable monitor stand on the desktop as desired. It is a movable component.
6. **Attach Hooks:** Secure the two iron hooks to the side of the desk frame for headphones or other accessories.
7. **Final Tightening and Leveling:** Once all components are in place and aligned, fully tighten all screws. Adjust the leg pads at the bottom of the desk to ensure stability on uneven floors.



Image: Fully assembled ODK L-Shaped Gaming Desk with various components. This image illustrates the overall structure and potential setup.

Product Dimensions:cm




Image: Detailed product dimensions of the ODK L-Shaped Gaming Desk, showing lengths, widths, and heights of different sections in centimeters.

OPERATING AND USAGE

The ODK L-Shaped Gaming Desk is designed for versatility and efficiency. Here's how to best utilize its features:

- **Spacious L-Shaped Desktop:** The large surface area accommodates multiple monitors (2-3 screens), keyboards, mice, and other peripherals, providing ample space for gaming, working, or studying.
- **Adjustable Monitor Stand:** The movable monitor stand can be positioned anywhere on the desktop to elevate your screen to an ergonomic height, reducing neck and eye strain. It can also be used for laptops or other small devices.
- **Two-Tier Storage Shelves:** Utilize the integrated shelves for organizing books, documents, speakers, or decorative items. These shelves help keep your workspace tidy and clutter-free.
- **PC Tower Compartment:** The dedicated compartment provides a secure and accessible space for your PC tower, keeping it off the floor and protected.
- **Iron Hooks:** Use the two included iron hooks to hang headphones, cables, or other accessories, keeping them within reach and off the desk surface.



Großzügige Ablagefächer





Image: Detailed view of the spacious storage compartments on both the left and right sides of the desk, designed to hold a PC tower, books, and other items.



Image: Illustration of key features including the movable monitor stand, shown with a laptop, and the two iron hooks for hanging items like headphones.

MAINTENANCE

To ensure the longevity and appearance of your ODK L-Shaped Gaming Desk, follow these maintenance guidelines:

- **Cleaning:** Wipe the desk surfaces with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish. For stubborn marks, a mild soap solution can be used, followed by drying with a clean cloth.
- **Spills:** Immediately wipe up any spills to prevent water damage or staining. The textured surface is designed to resist minor spills, but prompt cleaning is recommended.
- **Hardware Check:** Periodically check all screws and bolts to ensure they remain tight. Retighten if necessary to maintain stability.
- **Avoid Excessive Weight:** Do not place excessively heavy items on the desk or shelves beyond their intended capacity.
- **Environmental Conditions:** Keep the desk away from direct heat sources, extreme cold, and

prolonged exposure to direct sunlight to prevent warping or fading.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Desk is wobbly or unstable.	Screws are loose; desk is on an uneven surface.	Ensure all assembly screws are fully tightened. Adjust the leg pads at the bottom of the desk to level it on uneven floors.
Parts do not align during assembly.	Incorrect orientation of parts; screws overtightened prematurely.	Review the assembly instructions to ensure correct part orientation. Loosen all screws slightly, align parts, then retighten.
Scratches on the surface.	Sharp objects dragged across the surface; improper cleaning.	Use coasters or protective mats for items that might scratch. Clean with soft cloths and avoid abrasive materials.

SPECIFICATIONS

Brand	ODK
Model Number	ZJZ-SZWJ
Color	Vintage Brown
Material	Metal frame, P2 MDF panels
Overall Dimensions (L x W x H)	168 x 120 x 75 cm (approx. 66.1 x 47.2 x 29.5 inches)
Product Weight	24.1 Kilograms (approx. 53.1 lbs)
Shape	L-Shape
Components Included	Double shelves, 2 hooks, movable monitor stand
Assembly Required	Yes

WARRANTY AND SUPPORT

ODK is committed to providing high-quality products. For any questions regarding assembly, missing parts, or product defects, please contact our customer support team. Your satisfaction is our priority.

Please refer to your purchase documentation for specific warranty terms and conditions. For direct support, visit the official ODK website or contact the retailer where the product was purchased.

