

[Manuals.plus](#) /

> [dirocoro](#) /

> dirocoro Women's Analog Quartz Watch User Manual

## dirocoro D-AF03

# dirocoro Women's Analog Quartz Watch User Manual

Model: D-AF03

## 1. INTRODUCTION

---

Thank you for choosing the dirocoro Women's Analog Quartz Watch. This elegant timepiece features a unique starry sky dial and a comfortable stainless steel Milanese strap, designed to complement various styles for both casual and business occasions. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your watch to ensure its longevity and accurate performance.






Image 1.1: The dirocoro Women's Analog Quartz Watch, showcasing its elegant design and starry sky dial.

## 2. PRODUCT OVERVIEW AND FEATURES

---

The dirocoro watch is crafted with attention to detail, offering both aesthetic appeal and reliable functionality.

- **Starry Sky Dial:** The watch features a unique, shimmering dial that mimics a starry night sky, adding a touch of romance and elegance.

## Fashion Women Watch



Fashion Starry Sky Dial



The fine highlights are like stars in the night sky, giving you a sea of stars on your wrist

Image 2.1: Detailed view of the watch's starry sky dial, highlighting its unique shimmering effect.

- **Stainless Steel Milanese Strap:** The strap is made from high-quality stainless steel with a Milanese mesh design, providing comfort and durability. Its length is freely adjustable.

## Stainless Steel Milanese Strap



Image 2.2: View of the stainless steel Milanese strap, showing its fine mesh and adjustable clasp mechanism.

- **High-Quality Quartz Movement:** Equipped with a precise analog quartz movement for accurate timekeeping.
- **Ultra-Thin Design:** The watch boasts an ultra-thin profile, contributing to its sleek and lightweight feel.
- **Water Resistance:** Designed with 30m (3ATM) water resistance, suitable for daily use like hand washing or splashes, but not for swimming or showering.

### 3. SETUP

---

#### 3.1 Setting the Time

1. Locate the crown on the right side of the watch case.
2. Gently pull the crown outwards to the time-setting position. You may feel a small click.
3. Rotate the crown clockwise or counter-clockwise to adjust the hour and minute hands to the correct time.
4. Once the time is set, push the crown back into its original position to start the watch movement.

#### 3.2 Adjusting the Strap Length

The Milanese strap is adjustable to fit various wrist sizes. A strap adjustment tool is provided with your watch.

1. Locate the clasp on the strap. There is a small lever or tab on the underside of the clasp.
2. Using the provided strap adjustment tool (or a small, flat-head screwdriver), gently lift the lever/tab on the clasp. This will unlock the clasp mechanism.
3. Slide the clasp along the mesh strap to the desired length. Ensure the clasp is positioned securely in one of the

grooves on the strap.

- Once the desired length is achieved, press the lever/tab back down firmly until it clicks into place, securing the clasp.
- Test the fit on your wrist to ensure it is comfortable and secure.

## 4. OPERATING INSTRUCTIONS

---

Once the time is set and the strap is adjusted, your dirocoro watch is ready for use. The watch operates continuously, providing accurate timekeeping.

- Wear the watch comfortably on your wrist.
- Check the time periodically. If the time deviates, refer to Section 3.1 to reset it.

## 5. MAINTENANCE

---

Proper care will help maintain the appearance and functionality of your dirocoro watch.

### 5.1 Cleaning

- Wipe the watch case and strap regularly with a soft, dry cloth to remove dust and fingerprints.
- For stubborn dirt on the metal strap, a slightly damp cloth can be used, followed immediately by a dry cloth. Avoid using harsh chemicals or abrasive materials.

### 5.2 Water Resistance Precautions

Your watch has a 30m (3ATM) water resistance rating. This means it is suitable for:

- Daily use, such as hand washing or light rain.
- Avoid exposing the watch to hot water, steam (e.g., in a sauna or hot shower), or prolonged submersion.
- Do not operate the crown or pushers when the watch is wet.

### 5.3 Battery Replacement

The quartz movement is powered by a battery. When the watch stops or the hands move erratically, it may be time for a battery replacement. It is recommended to have the battery replaced by a qualified watch technician to ensure proper sealing and maintain water resistance.

## 6. TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Watch is not running.	Battery depleted. Crown is pulled out.	Replace battery (professional recommended). Push crown back in.
Time is incorrect.	Time not set correctly. Crown accidentally pulled out.	Reset the time (refer to Section 3.1). Push crown back in.
Condensation under crystal.	Exposure to extreme temperature changes or moisture.	Avoid extreme temperature changes. If condensation persists, seek professional service.

## 7. SPECIFICATIONS

---

Feature	Detail
Brand	dirocoro
Model Number	D-AF03
Movement	Analog Quartz
Case Diameter	36 mm
Case Thickness	8.5 mm
Watch Band Width	18 mm
Watch Circumference	230 mm (adjustable)
Weight	60 g
Strap Material	Stainless Steel (Milanese)
Mirror Material	High Hardness Mirror (Mineral Glass)
Water Resistance	30m (3ATM)
Country of Origin	China

## Product Parameters



Watch Circumference: 230 mm



Case Diameter: 36 mm



Case Thickness: 8.5 mm



Watch Band Width: 18 mm



Weight : 60 g



Material: Stainless steel

Image 7.1: Product dimensions and weight diagram.

## 8. WARRANTY AND SUPPORT

For any warranty claims, technical support, or inquiries regarding your dirocoro watch, please contact the seller or the official dirocoro customer service. Keep your purchase receipt as proof of purchase.

Manufacturer: dirocoro