

ODK XSD-CJJJZ02

ODK Computer Desk XSD-CJJJZ02 Instruction Manual

Model: XSD-CJJJZ02 | Brand: ODK

1. INTRODUCTION

Thank you for choosing the ODK Computer Desk, Model XSD-CJJJZ02. This manual provides essential information for the safe assembly, operation, and maintenance of your new desk. Please read these instructions carefully before beginning assembly and retain them for future reference.

The ODK Computer Desk is designed for versatility and stability, suitable for various home and office environments. It features a spacious desktop, a convenient side storage bag, and a headphone hook to help organize your workspace.



Image 1.1: The ODK Computer Desk (Model XSD-CJJZ02) in a typical workspace setup, showcasing its ample surface area and integrated storage features.

2. SAFETY WARNINGS

- **Assembly Caution:** Assemble the desk carefully. Ensure all screws and fasteners are tightened securely to prevent instability. Do not overtighten.
- **Weight Capacity:** Do not exceed the desk's maximum weight capacity. Distribute weight evenly across the desktop.
- **Cleaning:** Use a soft, damp cloth for cleaning. Avoid harsh chemicals or abrasive materials that could damage the surface.
- **Placement:** Place the desk on a level surface to ensure stability. Adjust foot pads as necessary.
- **Children:** Keep small parts away from children during assembly.

3. PACKAGE CONTENTS

Before assembly, verify that all components listed in the included parts diagram are present. If any parts are missing or damaged, please contact customer support.

- Desktop panels
- Metal frame components (legs, support bars)
- Side storage bag
- Headphone hook
- Assembly hardware (screws, bolts, Allen wrench)
- Adjustable foot pads
- Instruction manual (this document)

4. SETUP AND ASSEMBLY

Assembly typically takes 20-30 minutes. Follow the detailed step-by-step instructions provided in the separate assembly guide included with your product. The following provides a general overview.

4.1 Dimensions Overview



Image 4.1: Dimensional diagram of the ODK Computer Desk, illustrating its overall size and the integrated storage bag's dimensions.

4.2 General Assembly Steps

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches. Verify all parts are present against the included parts list.

2. **Assemble Frame:** Attach the metal legs to the support bars using the provided screws and Allen wrench. Do not fully tighten screws until all frame components are loosely connected.
3. **Attach Desktop:** Carefully place the desktop panels onto the assembled frame. Align the pre-drilled holes and secure the desktop to the frame using the appropriate screws.
4. **Install Accessories:** Attach the side storage bag to the designated area on the desk frame. Install the headphone hook as desired.
5. **Final Tightening:** Once all components are in place, gradually tighten all screws and bolts. Ensure the desk is stable and level.
6. **Adjust Foot Pads:** Adjust the foot pads at the bottom of the legs to ensure the desk is stable and level on uneven floors, reducing noise when moving.

5. OPERATING INSTRUCTIONS

The ODK Computer Desk is designed for straightforward use. Once assembled, it provides a stable and organized workspace.

5.1 Utilizing the Desktop

The spacious desktop (160 x 55 cm) can accommodate multiple monitors, a laptop, keyboard, mouse, and other office essentials. Its scratch-resistant and waterproof surface protects against daily wear.



Image 5.1: The desk surface is robust enough to support monitor clamps and other accessories, ensuring a secure setup.

5.2 Side Storage Bag

The integrated side storage bag offers convenient access to documents, notebooks, pens, and other small items, helping to keep your desktop clutter-free.



Image 5.2: The multi-pocket side storage bag provides easy organization for various items.

5.3 Headphone Hook

Utilize the metal headphone hook to hang your headphones, bags, or other accessories, keeping them within reach and off the desktop.



Image 5.3: The integrated headphone hook offers a convenient spot to store headphones or other items.

6. MAINTENANCE

Proper care will extend the life and appearance of your ODK Computer Desk.

- **Cleaning the Surface:** Wipe the desktop with a soft, damp cloth. For stubborn marks, a mild soap solution can be used, followed by wiping with a clean, dry cloth. Avoid abrasive cleaners or solvents.
- **Frame Care:** The metal frame can be wiped clean with a damp cloth. Ensure it is dried thoroughly to prevent rust.
- **Storage Bag:** The fabric storage bag can be spot cleaned with a mild detergent. Allow it to air dry completely.
- **Regular Checks:** Periodically check all screws and bolts to ensure they remain tight. Retighten if necessary to maintain stability.
- **Avoid Extreme Conditions:** Do not expose the desk to direct sunlight for prolonged periods or extreme temperature changes, as this may affect the material.

7. TROUBLESHOOTING

If you encounter any issues with your ODK Computer Desk, refer to the following common solutions:

- **Desk is Wobbly:**
 - Ensure all assembly screws are fully tightened.
 - Check that the desk is placed on a level surface. Adjust the foot pads on the bottom of the legs to compensate for uneven flooring.
- **Missing Parts:**
 - Carefully re-check all packaging materials. Small parts may be overlooked.
 - If parts are genuinely missing, contact ODK customer support with your purchase details.
- **Difficulty Assembling:**
 - Review the assembly instructions step-by-step. Ensure you are using the correct hardware for each step.
 - Do not force components together. If parts do not fit, re-examine the instructions and part orientation.
- **Surface Scratches/Damage:**
 - While the surface is scratch-resistant, it is not scratch-proof. Use coasters for drinks and mouse pads for prolonged mouse use to minimize wear.
 - For minor scratches, furniture repair kits may offer a solution.

8. SPECIFICATIONS

Feature	Detail
Brand	ODK
Model Number	XSD-CJJJZ02
Color	Brown
Dimensions (L x W x H)	160 x 55 x 73.5 cm
Weight	5.9 Kilograms
Material	Engineered Wood, Metal
Special Features	Compact, Side Storage Bag, Headphone Hook, Adjustable Foot Pads, Scratch-resistant, Waterproof
Design	Computer Desk, Rectangular, Modern Style

9. WARRANTY INFORMATION

ODK products are manufactured to high-quality standards. For specific warranty terms and conditions, please refer

to the warranty card included with your purchase or visit the official ODK website. Typically, warranty coverage addresses manufacturing defects under normal use.

10. CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact ODK customer support. Have your model number (XSD-CJJZ02) and purchase information ready when contacting support.

For the most up-to-date contact information, please visit the official ODK website or refer to your purchase documentation.

