

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Fr-A786N-38A

Fr-A786N-38A Ceiling Fan Remote Control Receiver User Manual

Brand: Generic

PRODUCT OVERVIEW

The Fr-A786N-38A is a specialized receiver designed for use with ceiling fan remote control systems. This unit facilitates wireless control of your ceiling fan's functions, such as fan speed and light operation, when paired with a compatible remote. It is crucial to note that this specific model, Fr-A786N-38A, is designed for particular systems and **will not work to replace any other dash number**. There are numerous variations that may appear similar but are not interchangeable. Always verify the exact model number before installation.



This image displays the Fr-A786N-38A Ceiling Fan Remote Control Receiver. It features a distinctive blue, horseshoe-shaped casing with integrated vents. Multiple colored wires (red, black, white, yellow, blue, green) extend from one end, terminating in white connectors. A

yellow circular sticker with 'QC 01 2023 OK' is visible on one side, indicating quality control. A white label on the front clearly states 'FR-A786N-38A' and a crucial caution: 'Caution: Will not work To replace other dash #'s', emphasizing its specific compatibility.

SETUP AND INSTALLATION

Proper installation is essential for the safe and correct operation of your ceiling fan receiver. If you are unsure about any step, it is recommended to consult a qualified electrician.

Safety Precautions:

- **ALWAYS turn off power** to the ceiling fan circuit at the main electrical panel (circuit breaker) before beginning installation. Verify power is off using a voltage tester.
- Ensure all wiring connections are secure and comply with local electrical codes.
- Do not exceed the electrical ratings of the receiver.

Installation Steps:

1. **Prepare Wiring:** Carefully identify the existing wiring from your ceiling fan and the ceiling junction box. Typically, these include Live (black), Neutral (white), Ground (green/bare copper), and Fan/Light wires.
2. **Connect Receiver:** Connect the wires from the receiver to the corresponding wires from the ceiling fan and the house wiring. Refer to the wiring diagram provided with your ceiling fan or the receiver for specific connections. Common connections are:
 - Receiver Input (from house): Live to Live, Neutral to Neutral, Ground to Ground.
 - Receiver Output (to fan): Fan Live to Fan Motor, Light Live to Light Kit, Neutral to Fan/Light Neutral.

Note: Wire colors on the receiver may vary. Match functions, not just colors, if unsure.

3. **Secure Receiver:** Carefully tuck the receiver and all wiring into the ceiling fan canopy. Ensure no wires are pinched and there is adequate space for air circulation.
4. **Reassemble Fan:** Reattach the fan canopy to the mounting bracket.
5. **Restore Power:** Turn the power back on at the main electrical panel.

OPERATING INSTRUCTIONS

Once the receiver is installed, you can operate your ceiling fan using a compatible remote control.

Pairing the Remote (if applicable):

Many remote control systems require pairing the remote with the receiver. The exact procedure varies by remote model. Typically, this involves:

1. Ensure power to the fan is off for at least 30 seconds, then turn it back on.
2. Within a short timeframe (e.g., 30-60 seconds) after restoring power, press and hold the "Learn" or "Pair" button on your remote control. Some remotes may require pressing a specific combination of buttons (e.g., "Light" and "High" fan speed).
3. The fan light may blink or the fan may briefly turn on to indicate successful pairing.

Refer to your specific remote control's manual for detailed pairing instructions.

Basic Functions:

- **Fan Speed Control:** Use the designated buttons on your remote to cycle through fan speeds (e.g., Low, Medium, High) or to turn the fan off.
- **Light Control:** Use the light button to turn the fan light on/off or to dim/brighten if your system supports dimming.

MAINTENANCE

The Fr-A786N-38A receiver is designed for long-term, maintenance-free operation once installed. However, general care of your ceiling fan system is recommended.

- **Cleaning:** Do not attempt to clean the receiver unit directly. For the ceiling fan and remote, use a soft, dry cloth. Avoid using harsh chemicals or abrasive cleaners.
- **Remote Battery Replacement:** If your remote control stops responding, check and replace its batteries as needed. Refer to your remote's manual for battery type and replacement instructions.
- **Periodic Checks:** Periodically check the ceiling fan for any loose screws or wobbling. Ensure the fan blades are clean to maintain balance and efficiency.

TROUBLESHOOTING

If you encounter issues with your Fr-A786N-38A receiver or ceiling fan system, try the following troubleshooting steps:

Problem	Possible Cause	Solution
Fan/Light not responding to remote.	No power to fan. Remote batteries are dead. Remote not paired with receiver. Incorrect receiver model.	Check circuit breaker. Replace remote batteries. Attempt to re-pair remote (see Operating Instructions). Verify the receiver is Fr-A786N-38A. This model is not interchangeable with others.
Fan operates, but light does not.	Light bulb is faulty or loose. Wiring issue to light kit.	Replace bulb or tighten. Check light kit wiring connections (power off first).
Intermittent operation.	Weak remote batteries. Interference from other devices. Loose wiring connection.	Replace remote batteries. Ensure receiver is not obstructed. Check all wiring connections (power off first).

If these steps do not resolve the issue, it may indicate a fault with the receiver, remote, or fan motor. Professional assistance may be required.

SPECIFICATIONS

Feature	Detail
Model Number	Fr-A786N-38A
Brand	Generic
Product Dimensions	4 x 4 x 1 inches
Item Weight	8 ounces
Manufacturer	Rhine
ASIN	B0CL2NCRDK
Special Feature	Ergonomic

Feature	Detail
Color	Blue
Compatible Devices	Fan
Connectivity Technology	Infrared

WARRANTY AND SUPPORT

Information regarding specific warranty terms or direct manufacturer support for the Fr-A786N-38A Ceiling Fan Remote Control Receiver was not provided in the product data. For warranty claims or technical assistance, please refer to the documentation included with your purchase or contact the seller directly.

For general inquiries or to find compatible remote controls, you may search for "Fr-A786N-38A remote" online or consult with a ceiling fan specialist.

© 2023 Generic. All rights reserved.
This manual is for informational purposes only.