

vidaXL 3187974

vidaXL 9 Piece Patio Dining Set Instruction Manual

Model: 3187974

INTRODUCTION

Thank you for choosing the vidaXL 9 Piece Patio Dining Set. This manual provides essential information for the safe assembly, operation, and maintenance of your new outdoor furniture. Please read these instructions carefully before use and retain them for future reference.

SAFETY INFORMATION

- Always ensure all components are securely fastened before use.
- Do not exceed the maximum weight capacity of 242.5 lbs per chair.
- Place the dining set on a flat, stable surface to prevent tipping.
- Protect the set with a waterproof cover during adverse weather conditions or when not in use to prolong its lifespan.
- Keep children away from the assembly area and ensure all small parts are out of their reach.

PACKAGE CONTENTS

Verify that all parts are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- 1 x Dining Table (Anthracite Steel)
- 8 x Garden Chairs (Anthracite Steel)



Image: The complete vidaXL 9 Piece Patio Dining Set, featuring a rectangular table and eight matching chairs.

SETUP AND ASSEMBLY

Assembly is required for this dining set. Follow these general steps. Specific fasteners and tools (not included) may be needed.

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a soft, clean surface to prevent scratches.
2. **Identify Parts:** Refer to the included parts list (if available) to identify all table and chair components, including legs, frames, and fasteners.
3. **Assemble Chairs:**
 - Attach the chair legs to the seat frame using the provided hardware.
 - Secure the backrest to the seat frame and armrests.
 - Hand-tighten all screws initially. Once all screws are in place, fully tighten them with the appropriate tool.
4. **Assemble Table:**
 - Attach the table legs to the tabletop frame.
 - Ensure all connections are aligned before tightening.
 - Hand-tighten all screws initially. Once all screws are in place, fully tighten them.
5. **Final Check:** Ensure all screws and bolts are securely tightened on both the table and chairs. Test the stability of each piece before use.



Image: A detailed view of one of the patio chairs, highlighting its construction and design.



Image: A close-up of the table corner, illustrating the mesh tabletop and robust frame construction.

OPERATING INSTRUCTIONS

This dining set is designed for outdoor use. Its stackable chairs offer convenient storage.

- **Placement:** Position the dining set on a level, stable outdoor surface such as a patio, garden, or balcony.
- **Chair Use:** The chairs are designed for ergonomic comfort. Use them for dining or relaxation.
- **Stacking Chairs:** To save space, the chairs can be stacked when not in use. Lift each chair and carefully place it on top of another, ensuring stability.
- **Tabletop Use:** The tabletop provides a durable surface for meals, drinks, and decorative items. Avoid placing excessively hot items directly on the surface without protection.



Image: The dining set arranged on an outdoor patio, demonstrating its typical use environment.

MAINTENANCE

Proper care will ensure the longevity and appearance of your dining set.

- **Cleaning:** Wipe the surfaces with a dry cloth regularly to remove dust and debris. For more thorough cleaning, use a mild soap solution and a soft cloth, then rinse with clean water and dry thoroughly.
- **Protection:** The steel frame has an e-coating and powder coating for protection. However, it is recommended to protect the set with a waterproof cover when not in use, especially during harsh weather conditions (rain, snow, strong sun).
- **Rust Prevention:** Periodically inspect the frame for any signs of rust or damage to the coating. Touch up any scratches or chips in the paint to prevent rust.
- **Fastener Check:** Routinely check all screws and bolts to ensure they remain tight. Re-tighten as necessary to maintain stability.




Image: A close-up view of the mesh material used for the chair backrest, illustrating its texture and finish.

TROUBLESHOOTING

Here are solutions to common issues you might encounter:

- **Wobbly Table/Chairs:** Ensure all assembly screws are fully tightened. If the surface is uneven, consider using furniture levelers or shims under the legs.
- **Minor Scratches/Chips:** For small cosmetic damages to the coating, use a rust-inhibiting paint touch-up specifically designed for metal outdoor furniture.
- **Difficulty Stacking Chairs:** Ensure chairs are aligned correctly before attempting to stack. Do not force them.

SPECIFICATIONS




Image: Dimensional drawing of a single chair, indicating height, width, and depth measurements.

Feature	Detail
Brand	vidaXL
Model Number	3187974
Color	Anthracite
Material	Alloy Steel (Powder-Coated)
Table Dimensions (L x W x H)	78.74 x 39.37 x 28.35 inches (200 x 100 x 72 cm)

Chair Dimensions (W x D x H)	23.6 x 21.7 x 34.6 inches (60 x 55 x 88 cm)
Tabletop Surface Height	0.8 inches
Chair Seat Depth	16.9 inches
Maximum Chair Weight Capacity	242.5 lbs (110 kg)
Item Weight (Total)	106 pounds (48.2 kg)
Assembly Required	Yes

CUSTOMER SUPPORT

For any questions, missing parts, or assistance with your vidaXL 9 Piece Patio Dining Set, please contact vidaXL customer support. Refer to your purchase documentation for specific contact details or visit the official vidaXL website.